



TEXTRON STAMPEDE

HALF DOOR REAR WINDOW

Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion.

Surface Preparation Instructions and Guidelines

Cleaning: To achieve a strong bond between Velcro adhesive and UTV surface, you must clean the surface. Use a mixture of 50% alcohol and 50% water to remove dirt, mud and dust from roll bars and plastic body components. Let dry. Repeat this process 3 times.

The adhesive hook should be applied at a temperature of 70 degrees or above.

Bond between UTV and adhesive hook is dependent upon the amount of adhesive to surface contact development. Firm application pressure develops a better adhesive contact and improves bond strength.

After application, the bond strength increases and approaches the ultimate bond strength after 72 hours. Bond strength build up: 20 min equals 50% bond strength, 1 hour equals 75% bond strength, one day equals 90% bond strength, and 3 days equals 100% bond strength.

More tips for installation.

Two is better than one: We recommend a second person be involved for the installation process. Getting the panel in the correct position takes some pulling and tugging, we find the process runs smoother when there are two people pulling.

Test adhesion: Use a small piece of Velcro, remove backing and adhere to roll bars. Wait 20 minutes, Velcro should already be difficult to remove.

Still having trouble with adhesion: If Velcro is still not adhering to the roll bars, use a piece of hook (rough side of Velcro) to "rough up" the surface of your roll bar. We do not recommend this for the plastic body of your UTV, it will scratch.

Unsure about Velcro placement: With-out removing the white backing, attach the Velcro to your enclosure panel. Hold panel up to the UTV and note the area that the Velcro should attach. You can use the double-sided straps with-out Velcro to help hold up the panel while you remove the white backing and adhere sticky Velcro. We will send extra Velcro that can be used to hold the enclosure to the cab frame for easy notation of Velcro placement.

Attaching panel: Attach the panel top first, then work your way around the panel pulling the tabs and sticking them to the corresponding adhesive Velcro. The Webbing (black trim) of the panel should align to the middle of the roll bar. You will attach your enclosure, rear panel first then the door panels.

Installing with Windshield and Hard Top.

If you have a windshield and or hard top on your UTV, you will need to remove them before installing the door and rear panel. After the installation of your enclosure is complete you will then reinstall the windshield and hard top.

If clamps for the windshield or hard top are interfering with the sewn-on Velcro tabs or straps on your enclosure you can modify the tabs and straps easily by cutting them to fit. Mark where the tabs need to be cut to accommodate your windshield or hard tops clamps or bolts. Cut the tabs and burn the edges with a lighter to prevent unraveling. Do not cut in to the binding (darker black trim around your door panel).

Installation Instructions

Step 1: Remove your 3SI UTV Cab Enclosure and Velcro kit from the shipping box.

Step 2: Remove existing hard top.

Step 3: Clean all surfaces on which you will be placing the adhesive Velcro according to the surface preparation instructions. Wait until the surfaces are dry.

Step 4: Remove the backing from the adhesive hook strips and install as indicated in the following adhesive hook table and pictures. Press firmly.

Step 5: Wait 72 hours! This step is very important to the life of your Velcro. Waiting the full 72 hours will ensure that your Velcro and enclosure will stay on in rain, sleet, snow or mud.

Step 6: After all adhesive Velcro strips are attached, begin attaching panel to the cab frame.

Step 7: After the panel is attached work your way around the UTV remove, pull, and reattach, each Velcro tab to achieve a tight fit. You may need to do this a few times.


Step 8: When your enclosure is in the correct position the binding or trim around the panels will rest in the center of the roll bar.

Step 9: Re-install your windshield and hard top.

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.

INSTALL BACK PANEL FIRST.

PICTURE SHOWS THE SEWN-ON VELCRO TABS THAT CORRESPOND TO THE VELCRO CHART.



BACK PANEL

ADHESIVE HOOK CHART

Reference	Qty/Size	Placement
A	2-15"	Attach horizontally to either side of the brake light on the top back roll bar, towards the inside of the cab. (Figure 1)
B	2-3"	Attach horizontally to the top of the rear roll bars, on either side of the rear cross bar. (Figure 2)
C	2-6"	Wrap around roll bar below Velcro strip B. (Figure 3)
D	2-17"	Attach vertically to the back side roll bar, facing outwards. (Figure 4)
E	2-6"	Left bed and wrap strips around the roll bars behind the bed. (Figure 5)
F	2-4"	With the bed still lifted place strip horizontally on the flat area behind the bed, between strips E. (Figure 6)




Figure 1: Shows placement of 15" Velcro strips A.



Figure 2: Shows placement of 3" Velcro strips B.



Figure 3: Shows placement of 6" Velcro strips C.




Figure 4: Shows placement of 17" Velcro strips D. One on each side of the UTV in the same position.




Figure 5: Shows placement of 6" Velcro strips E.





Figure 6: Shows placement of 38" Velcro strip F.




Figure 7: Upon completion of installation your back panel should be tight across the back of the UTV.

PICTURE SHOW SEWN-ON VELCRO TABS THAT CORRESPOND TO THE VELCRO CHART.



PASSENGER SIDE DOOR



DRIVERS SIDE DOOR



DOOR KIT

ADHESIVE HOOK CHART

Reference	Qty/Size	Placement
A	2-14"	Attach horizontally the top side roll bar facing the interior of the cab. (Figure 1)
B	16-6"	Wrap around the roll bar according to figure 2. (Figure 2)
C	2-14"	Attach vertically to the front roll bars facing slightly toward the interior. (Figure 3)
D	2-3"	Attach vertically to middle side roll bar behind the seat. (Figure 4)
E	2-16"	Attach to the back of the top roll bars from the middle bracket . (Figure 5)
F	2-5"	Attach diagonally to body of the UTV. (Figure 5)
G	2-7"	Attach vertically to body of the UTV below Velcro strip F. (Figure 5)
H	2-5"	(Figure 6)
I	2-12"	Attach vertically to the plastic body of the UTV. On the side. (Figure 7)
J	2-40"	Attach to the outside of the factory door. WARNING! Attaching the adhesive Velcro to the decals on your factory door may cause damage to the decals when removed. (Figure 8)
K	2-5"	Attach vertically to the inside of the factory door above the hinge. (Figure 9)
L	2-4"	Attach at an angle to the outside front fender. (Figure 10)
M	2-5"	




Figure 1: Shows placement of 14" Velcro strip A. Top side roll bar toward the inside of the cab. You will install the other 14" Velcro strip in the same position on the other side of the UTV.




Figure 2: Shows placement of 6" Velcro strips B. Wraps these strips around the roll bars on passenger and drivers side.



Figure 3: Shows placement of 14" Velcro strips C.



Figure 4: Shows placement of 4" Velcro strip D. You will install a Velcro strips in the same position on the opposite side of the UTV.



Figure 5: Shows placement of 16" Velcro strips E. These strips are installed on the top back roll bar extending down the curve.



Figure 6: Shows placement of Velcro on the back panel, if you only purchased a door kit then you will place this strip on the roll bars from the top all the way down the back of the roll bars. If you have a back panel you will not need this Velcro. If you have a lexan back panel, the adhesive Velcro is optional, the lexan back panel will go over the door panels Velcro tabs, tightening the Lexan back panel into place will hold your doors to the UTV frame.



Figure 7: Shows placement of 9" Velcro strip I.



Figure 8: WARNING! Attaching this strip of adhesive Velcro may damage the decals when removed. Attach horizontally to factory door, place an identical strip on the passenger side.





Figure 9: Shows placement of 3" Velcro strips K. Place strips on the inside of both doors, above the hinge.



Figure 10: Shows placement of 12" Velcro strips J and K. You will place the other Velcro strips on the opposite side in the same position as the drivers side.



Optional Snaps

Included in your order are buttons or snaps. To attach the snaps you will first need to install your door kit. After you have the door kit aligned properly you may then use the position of the snaps on the door to determine the best place for the snaps on the body of the UTV.




Figure 72: Snaps on the door kit. Included in your order are the male



Figure 13: After installing the doors on the UTV you can then use the female end of the snaps attached to the door kit to determine the best spot for male end on the UTV. Mark the area on which you will install your snap, use a Phillips head screw driver to twist it into place.



Figure 14: This flap on your door kit will wrap around to the inside of the door.




Figure 15: Shows the inside of the factory door. You will install the male end of the snap on the inside of the factory door and wrap the flap around the door and connect the snaps.



Figure 16: The edge of the door kit in the photo above also wraps around the to the inside of the factory door.



Figure 17: The photo above shows the general area on the inside of the factory door on which the male snaps should be placed. Remember to use the soft door as a guide when installing the snaps.



Figure 18: The snaps outlined in this photo will connect to snaps installed on the outside of the machine.



Figure 19: Install these snaps on the outside of the UTV.





Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**