



## Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

### SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

**PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.**



## Arctic Cat Wildcat 4

### Full Cab for Hard Windshield Installation Instructions

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Cab Enclosure**.

#### **PLEASE NOTE**

The enclosures for the Arctic Cat Wildcat 4 were designed to be modular. Each enclosure panel can be installed independent of the other panels. As a result, you choose your level of coverage. For cold weather, you have the option of full coverage. When warm, store the doors and back panel and leave only the top on.

Install your enclosure in the following order:

- Back Panel
- Doors
- Top or Windshield/Top

**Step 1:** Remove your 3SI UTV Cab Enclosure and Velcro kit from the shipping box.

**Step 2:** Install the adhesive hook for the back panel to the cab frame as indicated in the table and pictures below.

Reference	Qty-Size	Placement
A	1-15"	Attach vertically to the inside edge of the rear cross bar between the rear support bars. Wrap the top of the rear panel over the cross bar and attach the sewn-in loop to the adhesive strip.
B	2-3"	Attach vertically to the inside edge of the rear cross bar corresponding to the sewn-in loop on either side of the top of the rear panel. Wrap the top of the rear panel over the cross bar and attach the sewn-in loop to the adhesive strips.
C	2-3"	Attach to the front side of the rear roll bar uprights corresponding to the 3" webbing/loop tabs located in the top corner of the rear panel. Attach the sewn-in loop in the tab to the adhesive strips.
D	2-4"	Attach to the front side of the rear roll bar uprights corresponding to the 4" webbing/loop tabs located on the sides of the rear panel. Attach the sewn-in loop on the tab to the adhesive strips.

E	2-6"	Wrap horizontally around the rear roll bar uprights corresponding to the double-sided straps on each side of the rear panel. Wrap the straps around the adhesive strips.
F	2-4"	Attach to the front side of the rear roll bar uprights corresponding to the 4" webbing/loop tabs located on the sides of the rear panel. Attach the sewn-in loop on the tab to the adhesive strips.
G	2-6"	Wrap horizontally around the rear roll bar uprights corresponding to the double-sided straps on each side of the rear panel. Wrap the straps around the adhesive strips.
No Ref	1-8"	Attach horizontally to the plastic between the rear seats corresponding to the sewn-in loop along the bottom of the rear panel. Attach the sewn-in loop to the adhesive strip.





**Step 3:** Drape the windshield/top/doors over the cab frame. Note, the 5" webbing/loop tab is located in the FRONT visor. The two double-sided strap are on the rear visor. The top attaches to the cab frame with tension straps. Attach the adhesive hook strips per the table and pictures below.

Reference	Qty-Size	Placement
A	6-6"	Wrap horizontally around the roll bar uprights in the locations shown in the picture below. Allow enough distance between the adhesive hook strips and the bottom edge of the top to allow the tension straps to be pulled tight. Wrap the double-sided hook and loop straps at the bottom of the tension straps around the adhesive strips. DO NOT PULL TIGHT AT THIS TIME.
B	2-6"	Wrap around the 2 rear support bars corresponding with the double-sided straps at the edge of the rear visor. Wrap the straps around the adhesive hook strips.
C	1-5"	Attach to the bottom of the front cross bar corresponding to the 5" webbing/loop tab sewn into the edge of the front visor. Use the tab to pull the top from back to front. Wrap the tab around the cross bar and attach the sewn-in loop to the adhesive strip.





**Step 4:** Align the top to the cab frame as needed. When properly aligned, pull the loose strap on the tension straps to tighten the top to the frame. Work your way around the Wildcat. Little adjustments to each as you go around are best.

**Step 5:** Zip each door panel to the top. Note the location of the sewn-in loop, tabs, or straps on the door panels.

**Step 6:** Attach the adhesive hook strips as indicated in the table and pictures below.

Reference	Qty-Size	Placement
D	2-6"	Wrap horizontally around the front roll bar corresponding to the double-sided hook and loop straps just below the zipper. Wrap the straps around the adhesive strip.
E	2-4"	Attach vertically along the inside edge of the front roll bars corresponding to the 4" webbing/loop tab at the front of the door panel. Wrap the tab around the front roll bar and attach the sewn-in loop to the adhesive strip.
F	2-6"	Wrap horizontally around the front roll bar corresponding to the double-sided hook and loop straps near the middle of the front roll bar uprights. Wrap the straps around the adhesive strip.



G	2-3"	Attach vertically along the inside edge of the front roll bars corresponding to the 3" webbing/loop tab at the front of the door panel. Wrap the tab around the front roll bar and attach the sewn-in loop to the adhesive strip.
H	2-6"	Wrap horizontally around the front roll bar corresponding to the double-sided hook and loop straps at the bottom of the front roll bar uprights. Wrap the straps around the adhesive strip.



Reference	Qty-Size	Placement
-----------	----------	-----------


I	2-10"	Attach vertically to the body corresponding to the sewn-in loop along the front edge of the door panel. Attach the sewn-in loop to the adhesive strip.
J	2-6"	Wrap around front door latch. Run the double-sided straps thru the latch and around the door.



Reference	Qty-Size	Placement
K	2-6"	Wrap horizontally around the rear roll bar corresponding to the double-sided hook and loop straps near the bottom of the rear door panel. Wrap the straps around the adhesive strip.
L	2-6"	Wrap horizontally around the rear roll bar corresponding to the double-sided hook and loop straps just below the seat belt bracket. Wrap the straps around the adhesive strip.



M	2-6"	Wrap horizontally around the middle roll bar corresponding to the double-sided hook and loop straps near the top of the middle roll bar uprights. Wrap the straps around the adhesive strip.
N	2-6"	Wrap horizontally around the middle roll bar corresponding to the double-sided hook and loop straps near the bottom of the middle roll bar uprights. Wrap the straps around the adhesive strip.
O	2-6"	Wrap around roll bar corresponding to the sewn-in double-sided hook and loop straps below the back of the front door window. Wrap the straps around the adhesive strips.
P	2-4"	Wrap around handle bar corresponding to the sewn-in double-sided hook and loop straps near the bottom of the seam just behind the front door. Wrap the straps around the adhesive strips.





Reference	Qty-Size	Placement
Q	2-11"	Attach to the inside and outside edge of the support bar at the top of the rear doors. Wrap the detachable Velcro wrap around the bar. The sewn-in loop at the bottom of the door panels attach to the Velcro wrap.
R	2-7"	Attach to the inside and outside edge of the support bar at the top of the rear doors. Wrap the detachable Velcro wrap around the bar. The sewn-in loop at the bottom of the door panels attach to the Velcro wrap.
S	2-11"	Attach to the inside and outside edge of the support bar at the top of the front doors. Wrap the detachable Velcro wrap around the bar. The sewn-in loop at the bottom of the door panels attach to the Velcro wrap.
T	2-7"	Attach to the inside and outside edge of the support bar at the top of the front doors. Wrap the detachable Velcro wrap around the bar. The sewn-in loop at the bottom of the door panels attach to the Velcro wrap.



Reference	Qty-Size	Placement
Q	2-11"	Attach to the inside and outside edge of the support bar at the top of the rear doors. Wrap the detachable Velcro wrap around the bar. The sewn-in loop at the bottom of the door panels attach to the Velcro wrap.
R	2-7"	Attach to the inside and outside edge of the support bar at the top of the rear doors. Wrap the detachable Velcro wrap around the bar. The sewn-in loop at the bottom of the door panels attach to the Velcro wrap.
S	2-11"	Attach to the inside and outside edge of the support bar at the top of the front doors. Wrap the detachable Velcro wrap around the bar. The sewn-in loop at the bottom of the door panels attach to the Velcro wrap.
T	2-7"	Attach to the inside and outside edge of the support bar at the top of the front doors. Wrap the detachable Velcro wrap around the bar. The sewn-in loop at the bottom of the door panels attach to the Velcro wrap.
No Ref	2-20"	ONLY NEEDED IF BACK PANEL IS NOT INSTALLED. CUT TO SIZE. Attach vertically to the inside edge of the rear roll bar upright corresponding to the 3 sewn-in tabs along the back of the door panels. Attach the sewn-in loop to the adhesive strips.

**Step 6:** Repeat any steps necessary to achieve a snug fit on the cab frame.

**Step 7:** Re-install your windshield, back panel, and hard top if desired.

**See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.**



## Care Instructions

### Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

### Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

### Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

### Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**



