




# BISON SSR WINDSHIELD

## Hardware Kit

Hardware	Description	Qty
	12" VELCRO STRAP	8

**TOOLS NEEDED: NONE!**

**DO NOT REMOVE THE PROTECTIVE PAPER UNTIL INSTALLATION IS COMPLETE.**

## Remove protective paper from both side of the windshield!

Step 1:

Set bottom portion of windshield on the hood line. Peel back the paper to expose the pre-cut slots. Insert strap through the front of the windshield, wrap around the bar, insert end of strap through plastic buckle and pull tight. Repeat for all remaining straps.

Step 2:

Set top portion of windshield on the bottom portion. Peel back the paper to expose the pre-cut slots. Insert strap through the front of the windshield, wrap around the bar, insert end of strap through plastic buckle and pull tight. Repeat for all remaining straps.









**Periodic cleaning using correct procedures can help to prolong service life. For care and cleaning, it is recommended that the following instructions be adhered to:**

## **Lexan Cleaning Recommendations**

- Gently wash Lexan with a solution of mild soap and lukewarm water, using a soft, grid-free cloth or sponge to loosen any dirt or grime.
- Fresh paint splashes, grease and smeared glazing compounds can be removed easily before drying by rubbing lightly with a soft cloth using petroleum ether (BP65), hexane or heptanes. Afterwards, wash the sheet using mild soap and lukewarm water.
- Scratches and minor abrasions can be minimized by using a mild automobile polish. We suggest that a test be made on a small area of the Lexan sheet with the polish selected and that the polish manufacturer's instructions be followed, prior to using the polish on the entire sheet.
- Finally, thoroughly rinse with clean water to remove any cleaner residue and dry the surface with a soft cloth to prevent water spotting.

## **Important Instructions**

- Never use abrasive or highly alkaline cleaner on Lexan polycarbonate materials.
- Never use aromatic or halogenated solvents like toluene, benzene, gasoline, acetone or carbon tetrachloride on Lexan polycarbonate materials.
- Use of incompatible cleaning materials with Lexan sheet can cause structural and/or surface damage.
- Contact with harsh solvents such as methyl ethyl ketone (MEK) or hydrochloric acid can result in surface degradation and possible crazing of Lexan sheet.
- Never scrub with brushes, steel wool or other abrasive materials.
- Never use squeegees, razorblades or other sharp instruments to remove deposits or spots.
- Do not clean Lexan polycarbonate in direct sunlight or at high temperatures as this can lead to staining.
- For all mentioned chemicals consult the manufacturer's material safety datasheet (MSDS) for proper safety precautions.