




INDUSTRIES

CAN AM MAVERICK X3 WINDSHIELD

Hardware Kit

Hardware	Description	Qty
	1" BOLT	4
	NEOPRENE WASHER	4
	SMALL WASHER	4
	LOCK NUTS	4
	VELCRO STRAPS	6-12"

**DO NOT REMOVE PROTECTIVE
PAPER FROM THE WINDSHIELD.
THIS WILL PROTECT THE
WINDSHIELD DURING
INSTALLATION.**



BOTTOM PORTION



TOP PORTION



STEP 1: Peel back paper to expose holes in both pieces of the windshield.

STEP 2: Use neoprene washer /bolt assembly through the outside of the windshield to connect the visor to the lower portion of the windshield. Secure on the inside with small washer and lock nut.



STEP 3: Set windshield on roll bars. The bottom of the windshield will set down in the hood line.

STEP 4: Peel back protective paper enough to expose the slot hole, thread your straps through the slot in the windshield, around the bar and through the plastic clip. Then attach strap to itself.



STEP 5: The 4 12" straps are for the slots on the sides, the 10" straps are for the top slots.

STEP 6: Once you have installed all straps you may remove the protective paper from both sides of the windshield.





Periodic cleaning using correct procedures can help to prolong service life. For care and cleaning, it is recommended that the following instructions be adhered to:

Lexan Cleaning Recommendations

- Gently wash Lexan with a solution of mild soap and lukewarm water, using a soft, grid-free cloth or sponge to loosen any dirt or grime.
- Fresh paint splashes, grease and smeared glazing compounds can be removed easily before drying by rubbing lightly with a soft cloth using petroleum ether (BP65), hexane or heptanes. Afterwards, wash the sheet using mild soap and lukewarm water.
- Scratches and minor abrasions can be minimized by using a mild automobile polish. We suggest that a test be made on a small area of the Lexan sheet with the polish selected and that the polish manufacturer's instructions be followed, prior to using the polish on the entire sheet.
- Finally, thoroughly rinse with clean water to remove any cleaner residue and dry the surface with a soft cloth to prevent water spotting.

Important Instructions

- Never use abrasive or highly alkaline cleaner on Lexan polycarbonate materials.
- Never use aromatic or halogenated solvents like toluene, benzene, gasoline, acetone or carbon tetrachloride on Lexan polycarbonate materials.
- Use of incompatible cleaning materials with Lexan sheet can cause structural and/or surface damage.
- Contact with harsh solvents such as methyl ethyl ketone (MEK) or hydrochloric acid can result in surface degradation and possible crazing of Lexan sheet.
- Never scrub with brushes, steel wool or other abrasive materials.
- Never use squeegees, razorblades or other sharp instruments to remove deposits or spots.
- Do not clean Lexan polycarbonate in direct sunlight or at high temperatures as this can lead to staining.
- For all mentioned chemicals consult the manufacturer's material safety datasheet (MSDS) for proper safety precautions.