



# 3 STAR INDUSTRIES

## Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

### SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

**PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.**



## Honda Pioneer 700 -4 Full Cab with Vinyl Windshield

### Installation Instructions

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Cab Enclosure**.

The enclosures for the Honda Pioneer 700-4 were designed to be modular. Each enclosure panel can be installed independent of the other panels. As a result, you choose your level of coverage. For cold weather, you have the option of full coverage. When warm, store the doors and back panel and leave only the top on.

Install the modular cab enclosure in the following order:

- Back Panel
- Door Panels
- Windshield/Top

**Step 1:** Remove your 3SI UTV Cab Enclosure and Velcro kit from the shipping box.

**Step 2:** As each panel is to be installed, hold the panel to the vehicle's cab frame. Note the location of sewn-in loop strips in the enclosure. Adhesive hook strips will be attached to the cab frame corresponding to the loop strips. Remove the backing from the adhesive hook strips and install as indicated in the following adhesive hook table and picture.

Adhesive Hook Kit Contents/Placement		
BACK PANEL		
Reference	Qty-Size	Placement
A	2-6"	Wrap around the rear vertical role bar 1 ½" up from the corner corresponding to the double sided strap.
B	2-8"	Attach vertical along the rear vertical role bar 4" up from the top of the webbing seam, corresponding to the sewn in loop.
C	2-6"	Wrap around the bottom corner of the rear vertical role bar

		corresponding to the double sided strap.
D	2-10"	Attach horizontally to the rear overhead cross bar corresponding to the sewn in loop.
E	1-31"	Attach horizontally to the center of the rear overhead cross bar corresponding to the sewn in loop.
<b>DOOR PANEL</b>		
A	6-6"	Wrap around the front vertical role bars corresponding to the sewn in double sided straps.
B	2-8"	Attach vertically to the front vertical role bar corresponding to the sewn in loop.
C	4-5"	Attach to the front finders using 2 strips per side to make 2 rows corresponding to the sewn in loop.
D	2-10"	Attach vertically to the inside of the factory half doors, forward on the door but not interfering with the doors ability to close and corresponding to the sewn in loop.
E	4-5"	Attach to the dash just above the front of the doors using 2 strips per side to make 2 rows corresponding to the sewn in loop.
F	2-11"	Attach to the cab at the back of the front seats where the factory half door meets the cab corresponding to the sewn in loop.
G	2-6"	Wrap around the metal arm rest beside the front seats corresponding to the sewn in double sided straps.
H	2-5"	Attach vertically to the middle vertical role bar corresponding to the sewn in loop.
I	8-6"	Wrap around the middle vertical role bar starting at the top the first of these should be 1" down from the door zipper. Then moving down from there the second should be 7" down from the top piece, then the third should be 6" down from the second piece. The fourth of these will be 4" down from the third piece. All corresponding to the sewn in double sided straps.
J	2-35"	Attach horizontally along the side of the bed for the bottom of the rear doors corresponding to the sewn in loop.
K	2-17"	Attach vertically to the rear role bar corresponding to the sewn in loop. (If rear window is in use wrap over the exposed sewn in hook on back panel.)
L	2-6"	Attach vertically to the top of rear role bar corresponding to the sewn in loop. (If rear window is in use wrap over the exposed sewn

		in hook on back panel.)
M	2-6"	Wrap around the middle vertical role bar just above the rear door corresponding to the sewn in double sided strap.
<b>WINDSHIELD/TOP</b>		
A	2-4"	Attach to the front finder corresponding to the sewn in loop. (If doors are in use wrap over the exposed sewn in hook on door panel.)
B	2-6"	Wrap around the bottom of the front role bar corresponding to the sewn in double sided strap. (If doors are in use wrap over the exposed sewn in hook on door panel.)
C	2-6"	Wrap around the front role bar just below the vinyl windshield corresponding to the sewn in double sided strap. (If doors are in use wrap over the exposed sewn in hook on door panel.)
D	2-10"	Attach vertically to the front role bar beside the bottom corner of the vinyl windshield corresponding to the sewn in loop. (If doors are in use wrap over the exposed sewn in hook on door panel.)
E	2-5"	Attach vertically to the top of the front role bar just below the bend corresponding to the sewn in loop. (If doors are in use wrap over the exposed sewn in hook on door panel.)
F	2-10"	Attach to the top role bar running front to back just above the bend at the front of the cab, corresponding to the sewn in loop. (If doors are in use wrap over the exposed sewn in hook on door panel.)
G	2-5"	Attach to the top role bar running front to back just forward of the middle vertical role bar, corresponding to the sewn in loop. (If doors are in use wrap over the exposed sewn in hook on door panel.)
H	2-10"	Attach to the top role bar running front to back above the bed, corresponding to the sewn in loop. (If doors are in use wrap over the exposed sewn in hook on door panel.)
I	2-6"	Wrap around the top of the middle role bar corresponding to the sewn in double sided strap. (If doors are in use wrap over the exposed sewn in hook on door panel.)
J	2-6"	Wrap around the top of the rear role bar corresponding to the sewn in double sided strap. (If doors are in use wrap over the exposed sewn in hook on door panel.)

## Back Panel



## Door Kit



## Windshield Top




**Step 3:** After all adhesive hook strips are attached, begin attaching the enclosure to the cab frame. As you attach the hook and loop, square each panel to the frame. **PLEASE NOTE, FOR MAXIMUM ADHESION, ALLOW THE ADHESIVE HOOK TO ADHERE TO THE FRAME FOR 24 HOURS BEFORE PULLING AGAINST THE HOOK WITH THE LOOP STRIPS.**

**Step 4:** Fasten pre-attached Enclosure Front Hood Straps to the Vehicle front bumper as shown below. Bringing the end of the straps up to the latch buckle, run the end through the back of the top buckle opening first and then through the front of the lower buckle opening. **DO NOT FULLY TIGHTEN FRONT HOOD STRAPS AT THIS TIME.**



**Step 5:** With the enclosure properly aligned to the cab frame, tighten the front straps by pulling downward from the buckle on both strap ends at the same time as shown.





**Step 6:** Repeat any steps necessary to achieve a snug fit on the cab frame.

### **Full Cab Vinyl**



**See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.**



## Care Instructions

### Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

### Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

### Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

### Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**

