



Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.



John Deere Gator XUV S-4 Full Door/Rear Window

Installation Instructions

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Cab Enclosure**.

Install the cab enclosure in the following order:

- Back Panel
- Door Panels

Step 1: Remove your 3SI UTV Cab Enclosure and Velcro kit from the shipping box.

Step 2: With chalk, mark the location of the windshield clamps on the front roll bars. The webbing/loop that runs the length of the front roll bars must be cut to accommodate the windshield clamps. Instructions for cutting the webbing/loop follows below. Remove the windshield and hard top.

Step 3: Raise the bed to install the back panel. As each panel is to be installed, hold the panel to the vehicle's cab frame. Note the location of sewn-in loop strips in the enclosure. Adhesive hook strips will be attached to the cab frame corresponding to the loop strips. Remove the backing from the adhesive hook strips and install as indicated in the following adhesive hook table and picture.

Adhesive Hook Kit Contents/Placement		
BACK PANEL		
Reference	Qty-Size	Placement
A	1-35"	Attach horizontally to the inside edge of the rear cross bar. Wrap the top of the back panel over the cross bar and attach the sewn in loop to the adhesive hook strip.
B	2-8"	Attach vertically to the back side of the rear roll bar uprights corresponding to the 8" webbing/loop tabs on the sides of the rear


		panel. Use to hold back panel in place. <u>Use only if door panels are removed.</u>
No Ref	1-53"	Attach to the body corresponding to the sewn in loop at the bottom of the back panel. Attach the sewn in loop to the adhesive hook to hold the back panel in place.
DOOR PANELS		
C	2-28"	Attach horizontally to inside edge of side roll bars over the front seat corresponding to sewn in loop. Wrap the top of the door panel over the side bar and attach the sewn in loop to the adhesive hook strip.
D	2-12"	Attach horizontally to inside edge of side roll bars over the front seat corresponding to sewn in loop. Wrap the top of the door panel over the side bar and attach the sewn in loop to the adhesive hook strip.
E	2-12"	Wrap around upper portion of middle roll bar uprights corresponding to double-side straps. Wrap straps around the adhesive hook strips.
F	2-6"	Wrap around roll bars corresponding to double-side straps on the back corner of the door panel. Wrap straps around the adhesive hook strips.
G	2-5"	Attach to back/upper area of rear roll bar uprights corresponding to the 5" webbing/loop tabs. <u>Use only if back panel is removed.</u>
H	2-6"	Wrap around roll bars corresponding to double-side straps on the back of the door panel just above the zipper. Wrap straps around the adhesive hook strips.
I	2-6"	Wrap around roll bars corresponding to double-side straps on the top/front of the door panel. Wrap straps around the adhesive hook strips.
J	2-6"	Wrap around roll bars corresponding to double-side straps on the top of the front roll bar uprights. Wrap straps around the adhesive hook strips.
K	2-22"	Attach vertically to the back side of the rear roll bar uprights corresponding to the 22" webbing/loop tab. Attach sewn in loop strips in the middle/back of the door panels to hold in place.
L	2-10"	Attach vertically to the cab body on the back side of the door panels corresponding to the 10" sewn in loop strip. Attach sewn in loop strips in the middle/back of the door panels to hold in place.
M	2-6"	Wrap around middle roll bar uprights corresponding to double-side straps. Wrap straps around the adhesive hook strips.

N	2-6"	Wrap around middle roll bar uprights corresponding to double-side straps. Wrap straps around the adhesive hook strips.
O	2-24"	Attach horizontally to the back seat rocker panel area. Attach sewn in loop strips in bottom of door to the adhesive hook strips.
P	2-40"	Attach horizontally to the front seat rocker panel area. Attach sewn in loop strips in bottom of door to the adhesive hook strips.
Q	2-4"	Attach to body corresponding to the sewn in loop strips at the bottom of the wing.
R	2-32"	CUT to accommodate clamps. See instructions below. Attach between the clamps along the inside edge of the front roll bars.

BACK PANEL



DOOR PANEL



Step 3: After all adhesive hook strips are attached, begin attaching the enclosure to the cab frame. As you attach the hook and loop, square each panel to the frame. **PLEASE NOTE, FOR MAXIMUM ADHESION, ALLOW THE ADHESIVE HOOK TO ADHERE TO THE FRAME FOR 24 HOURS BEFORE PULLING AGAINST THE HOOK WITH THE LOOP STRIPS.**

Step 4: The webbing/Velcro strip that runs the length of the front roll bars will need to be cut to accommodate the windshield clamps and the grab handle. With chalk, mark the webbing strip where cuts will be made. **DO NOT CUT INTO THE BINDING.**



Step 5: Cut the webbing strip with household scissors. **AGAIN, DO NOT CUT INTO THE BINDING.** Seal the frayed edges with a lighter. Have a wet cloth handy to dab the edges if needed.



Cut the Tab being very careful not to cut the binding at the edge.



Seal Frayed Tab thread at the cut area using a lighter

Step 6: Pull the enclosure forward and wrap the enclosure around the front roll bars. Attach the webbing strip to the attached adhesive hook strips. When installed properly, the binding between the canvas fabric and the webbing strip should rest along the outer edge of the windshield.



Step 7: Repeat any steps necessary to achieve a snug fit on the cab frame.

Step 8: Re-install your windshield and top.

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



3 STAR INDUSTRIES

Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**