



## Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

### SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

**PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.**



## **Polaris Ranger Crew XP Summer Cab Enclosure Installation Instructions**

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Cab Enclosure**.

**Step 1:** Remove your 3SI UTV Full Cab Enclosure and Velcro kit from the shipping box.

Contents: 1 – Polaris Ranger Crew Summer Cab Enclosure

2 – 21” Velcro Strip: Rear of Cab Frame Lower - Drivers side and Passengers side

2 – 8” Velcro Strips: Front Windshield roll bar uprights – upper

2 – 4” Velcro Strips: Front Windshield roll bar uprights – bottom

2 - 8” Velcro Strips: Rear Roll Bar Uprights - center

4 – 6” Velcro Strips: 2 Front Windshield roll bar Uprights – middle, 2 Rear Roll Bar Post Uprights – bottom placed horizontally around the roll bar post

2 – 11” Velcro Strips: Center Roll Bar Uprights – top; placed horizontally around the Roll Bar Post

THE TECHNICAL NAME FOR VELCRO IS HOOK AND LOOP. HOOK IS THE ROUGH SIDE AND LOOP, THE SOFT SIDE. VELCRO LOOP HAS BEEN SEWN INTO THE ENCLOSURE IN VARIOUS LOCATIONS. IF YOU STRUGGLE WITH PLACEMENT OF THE ADHESIVE HOOK LISTED ABOVE, PLACE THE ENCLOSURE ON THE VEHICLE AND NOTE THE LOCATIONS OF THE SEWN IN VELCRO LOOP. THE ADHESIVE HOOK STRIPS CORRESPOND TO THE SEWN IN LOOP.

***Note: before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil. Clean vehicle surfaces with water or Windex only. Do not use solvents to prepare your vehicle surfaces for Velcro application.***

**Step 2:** Remove the clear plastic backing from the 21" Velcro strips and install along the bottom of the Rear Cab Frame on the Driver side and Passenger side as shown in figure 2.1




Figure 2.1 - attach 21" Velcro strips to Rear Cab Frame facing toward the rear of the vehicle

**Step 3:** Remove the clear plastic backing from the 8" Velcro strips and install vertically near the center of the Rear Roll Bar Uprights as shown in figure 3.1. Note Velcro Strips should face away from the center of the cab.




Figure 3.1 attach 8" Velcro strips vertically on the Rear Roll Bar uprights

**Step 4:** Remove the clear plastic backing from the 11" Velcro strips and install horizontally around the Center Roll Bar Uprights at the top as shown in figure 4.1. Note Velcro Strip seams should face the center of the cab.



Figure 4.1 - install 11" Velcro Strips horizontally around Center Roll Bar uprights at the top

**Step 5:** Remove the clear plastic backing from the 6" Velcro strips and install horizontally around the Rear Roll Bar Uprights at the bottom of the upright just above the bolt as shown in figure 5.1. Note Velcro Strip seams should face the center of the cab.



Figure 5.1 - install 6" Velcro strips horizontally around the bottom of the Rear Roll Bar Uprights

**Step 6:** Remove the clear plastic backing from the 8", 6" and 4" Velcro strips and install vertically along the upper, middle and bottom sections of the Front Windshield Roll Bar uprights as shown in figure 6.1, figure 6.2 and Figure 6.3.



Figure 6.1 - install 8" Velcro strips vertically along the upper section of the front windshield Roll Bar upright



Figure 6.2 – install 6" Velcro strips vertically along the middle section of the Front Windshield Roll Bar uprights



Figure 6.3 – install 4” Velcro Strips vertically along the bottom of the Front Windshield Roll Bar uprights

**Step 7:** Place Enclosure on top of the vehicle Roll Bar Cage making sure that top seams are aligned with the center of the Top Side Roll Bars as shown in figure 7.1. Keeping the Seams aligned with the Roll Bars and the rear of the Enclosure square to the rear of the vehicle cab frame attach the lower Rear Cab Frame 21” Velcro tabs as shown in figure 7.2. Pulling upward and outward on the rear 8” Enclosure Velcro tabs attach to installed 8” Rear Roll Bar Post Upright Velcro Strips as shown in figure 7.3. Also attach Rear Roll Bar upright post bottom horizontal Velcro tabs around installed 6” Velcro strips as shown in figure 7.4. Note these steps should straighten out the rear window panel.



Figure 7.1 - Put Summer Cab on top of vehicle roll bar frame



Figure 7.2 – Square back of enclosure to vehicle rear cab frame and attach 21” Velcro Tabs



Figure 7.3 – attach rear Roll Bar Post upright 8” Velcro tabs




Figure 7.4 – Attach Rear Roll Bar Upright bottom Velcro tabs around installed Velcro strips

**Step 8:** Pull the enclosure (each side of the front windshield) downward toward the front of the vehicle and attach the 8", 6" and 4" Windshield Upright Enclosure Velcro Tabs to the installed Front Windshield Roll Bar Post Velcro strips as shown in figure 8.1, 8.2 and 8.3. This Step is best performed with an assistant attaching the Windshield Velcro Tabs on each side of the Windshield at the same time.



Figure 8.1 – attach Top 8" Windshield Velcro Tabs





Figure 8.2 – attach Middle 6" Windshield Velcro Tabs



Figure 8.3 – attach bottom 4" Windshield Velcro tabs

**Step 9:** Fasten pre-attached Enclosure Front Hood Straps around the Vehicle front bumper as shown in figure 9.1. Bringing the end of the straps up to the latch buckle, run the end through the back of the top buckle opening first and then thread through the front of the lower buckle opening as shown in figure 9.2. Tighten Hood Straps firmly as shown in figure 9.3. These steps should straighten out the front windshield.



Figure 9.1 – guide front Hood straps around bumper




Figure 9.2 – thread straps through Hood Buckles



Figure 9.3 – Tighten Hood Straps by pulling down on the strap below the buckle

**Step 10:** Repeat Steps 7, 8, and 9 until the Enclosure fits snugly to the Vehicle Roll Bar structure as shown in figure 10.1 and 10.2.



Figure 10.1 - Enclosure should fit snug along the vehicle Top Roll Bar Structure and Windows should not have major wrinkles.



Figure 10.2 – Rear Panel should fit tightly across the back of the vehicle

**See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.**



## Care Instructions

### Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

### Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

### Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

### Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**

