



Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For best adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a one size fits all product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.



Polaris Ranger Crew 2009 Summer Cab Enclosure Installation Instructions

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Full Cab Enclosure**.

Step 1: Remove your 3SI UTV Full Cab Enclosure and Velcro kit from the shipping box. Along with the summer cab enclosure, the following contents are included...

Quantity	Description	Placement
1	1" Wide Adhesive Velcro Strip-30" Long	Inside of Hood-Between Hinges-Placed Horizontally
2	1" Wide Adhesive Velcro Strip-7" Long	Inside of Hood-Right & Left of Hinges-Placed Horizontally
4	2" Wide Adhesive Velcro Strips-10" Long	Middle & Top of Front Rollbar-Placed Vertically
2	2" Wide Adhesive Velcro Strips-5" Long	Bottom of Front Rollbar-Placed Vertically
2	2" Wide Adhesive Velcro Strips-8" Long	Middle of Back Rollbar-Placed Vertically
1	2" Wide Adhesive Velcro Strip-59" Long	Bottom of Back Panel-Placed Horizontally
2	2" Wide Adhesive Velcro Strip-6" Long	Top of Center Rollbars-Placed Horizontally

An additional strip of 2" Velcro has been included in your shipment if needed. The formal name for Velcro is hook and loop. The strips listed above are hook. The corresponding loop strips are sewn into your enclosure. If you struggle with placement of the adhesive hook strips, match the placement of the adhesive hook to the sewn in loop strips.

Note: before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil. Clean vehicle surfaces with water or Windex only. Do not use solvents to prepare your vehicle surfaces for Velcro application.

Step 2: Remove the clear plastic backing from the 59" Velcro strip and install along the bottom of the Rear Cab Frame as shown in figure 2.1



Figure 2.1 - attach 59" Velcro strips to Rear Cab Frame facing toward the rear of the vehicle

Step 3: Remove the clear plastic backing from the 8" Velcro strips and install vertically near the center of the Rear Roll Bar Uprights as shown in figure 3.1. Note Velcro Strips should face away from the center of the cab.




Figure 3.1 attach 8" Velcro strips vertically on the Rear Roll Bar uprights

Step 4: Remove the clear plastic backing from the **6" Velcro strips** and install horizontally around the **Center Roll Bar Uprights** at the top as shown in figure 4.1. Note **Velcro Strip seams** should face the center of the cab.



Figure 4.1 - install 11" Velcro Strips horizontally around Center Roll Bar uprights at the top

Step 5: Remove the clear plastic backing from the **10" and 5" Velcro strips** and install vertically along the upper, middle and bottom sections of the **Front Windshield Roll Bar uprights** as shown in figure 5.1, figure 5.2 and Figure 5.3.



Figure 5.1 - install 10" Velcro strips vertically along the upper section of the front windshield Roll Bar upright



Figure 5.2 – install 10" Velcro strips vertically along the middle section of the Front Windshield Roll Bar uprights



Figure 5.3 – install 5" Velcro Strips vertically along the bottom of the Front Windshield Roll Bar uprights

Step 6: Open the Hood of the Vehicle, remove the clear plastic backing from the 7" and 30" (1" wide) Velcro Strips and attach on the inside lip of the Hood support. 7" strips go the right and left of the 30" strip.

Step 7: Place Enclosure on top of the vehicle Roll Bar Cage making sure that top seams are aligned with the center of the Top Side Roll Bars. Keeping the Seams aligned with the Roll Bars and the rear of the Enclosure square to the rear of the vehicle cab frame. Attach the bottom of the rear panel to the 59" Velcro strip. Pulling upward and outward on the 8" Enclosure Velcro tabs, attach to the installed 8" Rear Roll Bar Post Upright Velcro Strips as shown in figure 7.1. Also attach Middle Roll Bar upright post Velcro tabs around installed 6" Velcro strips as shown in figure 7.2. Note these steps should straighten out the rear window panel.



Figure 7.1 – attach rear Roll Bar Post upright 8" Velcro tabs



Figure 7.2 - attach Center Velcro tabs to installed 6" Velcro Strips

Step 8: Pull the enclosure (each side of the front windshield) downward toward the front of the vehicle and **attach the 10" and 5" Windshield Upright Enclosure Velcro Tabs to the installed Front Windshield Roll Bar Post Velcro strips as shown in figure 8.1, 8.2 and 8.3.** This Step is best performed with an assistant attaching the Windshield Velcro Tabs on each side of the Windshield at the same time.



Figure 8.1 – attach Top 10" Windshield Velcro Tabs



Figure 8.2 – attach Middle 10" Windshield Velcro Tabs



Figure 8.3 – attach bottom 5" Windshield Velcro tabs

Step 9: Attach the 7" and 30" (1" wide) Front Hood Enclosure Velcro tabs underneath the Hood to the installed Velcro Strips. The Front of the vehicle Windshield should look like figure 9.1.



Figure 9.1 – Windshield should be tight at this step of the installation

Step 10: Repeat steps until the Enclosure fits snug to the Vehicle Roll Bar structure.

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS.