



POLARIS FULL SIZE 570 BACK PANEL

Hardware Kit		
Hardware	Description	Qty
	10" VELCRO STRAP	6
	1" BOLT	1
	SMALL WASHER	2
	LOCK NUT	1

DO NOT REMOVE PROTECTIVE PAPER FROM WINDSHIELD UNTIL AFTER IT HAS BEEN INSTALLED!

1: SET BACK PANEL ON THE ROLL CAGE.

2: PEEL PAPER ON WINDSHIELD BACK TO EXPOSE THE SLOT HOLES CUT IN THE WINDSHIELD FOR THE STRAPS.

3: INSERT STRAP THROUGH THE OUTSIDE OF THE WINDSHIELD, WRAP AROUND THE ROLL BAR AND PULL THE STRAP THROUGH THE ATTACHED CLIP. ATTACH STRAP TO ITSELF.

4: REPEAT THIS STEP FOR ALL OF THE STRAPS SLOTS.



5:

SET BRACKET ON REAR CROSS BAR. INSERT 1" BOLT WITH SMALL WASHER THROUGH THE OUTSIDE OF THE REAR PANEL, SECURE WITH SMALL WSHER AND LOCK NUT ON THE INSIDE.



REMOVE PROTECTIVE PAPER FROM BOTH SIDES OF THE WINDSHIELD .





Periodic cleaning using correct procedures can help to prolong service life. For care and cleaning, it is recommended that the following instructions be adhered to:

Lexan Cleaning Recommendations

- Gently wash Lexan with a solution of mild soap and lukewarm water, using a soft, grid-free cloth or sponge to loosen any dirt or grime.
- Fresh paint splashes, grease and smeared glazing compounds can be removed easily before drying by rubbing lightly with a soft cloth using petroleum ether (BP65), hexane or heptanes. Afterwards, wash the sheet using mild soap and lukewarm water.
- Scratches and minor abrasions can be minimized by using a mild automobile polish. We suggest that a test be made on a small area of the Lexan sheet with the polish selected and that the polish manufacturer's instructions be followed, prior to using the polish on the entire sheet.
- Finally, thoroughly rinse with clean water to remove any cleaner residue and dry the surface with a soft cloth to prevent water spotting.

Important Instructions

- Never use abrasive or highly alkaline cleaner on Lexan polycarbonate materials.
- Never use aromatic or halogenated solvents like toluene, benzene, gasoline, acetone or carbon tetrachloride on Lexan polycarbonate materials.
- Use of incompatible cleaning materials with Lexan sheet can cause structural and/or surface damage.
- Contact with harsh solvents such as methyl ethyl ketone (MEK) or hydrochloric acid can result in surface degradation and possible crazing of Lexan sheet.
- Never scrub with brushes, steel wool or other abrasive materials.
- Never use squeegees, razorblades or other sharp instruments to remove deposits or spots.
- Do not clean Lexan polycarbonate in direct sunlight or at high temperatures as this can lead to staining.
- For all mentioned chemicals consult the manufacturer's material safety datasheet (MSDS) for proper safety precautions.