



Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.



Polaris General Full Cab for Hard Windshield

Installation Instructions

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Cab Enclosure**.

Step 1: Remove your Adhesive Hook Kit, Back Panel, and Door Panels from the shipping box. The enclosures for the Polaris General are modular. Our modular cab system allows you to determine your level of coverage. When warm, just a windshield and top will do. Later add the back panel. When full coverage is needed, add doors. The modular cab system should be installed in the following order:

- Back Panel
- Door Panels
- Windshield/Top or Top

Step 2: Remove your windshield and hard top.


Step 3: As each panel is to be installed, hold the panel to the cab frame. Note the location of sewn-in loop strips in the enclosure. Adhesive hook strips will be attached to the cab frame corresponding to the loop strips. Remove the backing from the adhesive hook strips and install as indicated in the following adhesive hook table and pictures.

Adhesive Hook Kit Contents/Placement		
Reference	Qty/Size	Placement
REAR PANEL		
A	1-48"	Attach horizontally to the inside edge of the rear cross bar. Wrap the top of the rear panel around the cross bar. Attach the sewn-in loop at the top of the rear panel to the adhesive hook strip.
B	2-4"	Attach vertically to the outside edge of the rear roll bar uprights corresponding to the double-sided hook and loop straps at the

		top/sides of the rear panel. Wrap the double-sided hook and loop straps around the roll bar.
C	2-10"	Attach vertically to the outside edge of the rear roll bar uprights corresponding to the 10" webbing/loop tabs at the sides of the rear panel. Use the tabs to pull the rear panel tight from side to side. Attach the sewn-in loop in the tabs to the adhesive hook strips.
D	2-3"	Attach vertically to the outside edge of the rear roll bar uprights corresponding to the 3" webbing/loop tabs at the sides of the rear panel. Use the tabs to pull the rear panel tight from side to side. Attach the sewn-in loop in the tabs to the adhesive hook strips.
No Ref	2-20"	Attach horizontally to the body behind the seats corresponding to the sewn-in loop strips at the bottom of the rear panel. Attach the sewn-in loop strips to the adhesive hook strips.
DOOR PANELS		
A	2-12"	Attach horizontally to the inside edge of the side roll bars. The 12" webbing/loop tab attaches to the adhesive hook strip.
B	2-6"	Attach to the top of the front roof bracket. The sewn-in loop on the 6" flap attached to the adhesive hook strip.
C	2-4"	Attach to the front/side of the roof bracket. The sewn-in loop on the 6" flap attached to the adhesive hook strip.
D	2-10"	Attach vertically to the inside edge of the front roll bar. The sewn-in loop along the front of the door panels attach to the adhesive hook strip.
E	2-3"	Attach to the flat plastic beside the bolt at bottom of front roll bar. Attach the sewn-in loop on the edge of the 3" flap to the adhesive hook strip.
F	2-5"	USE THE ADHESIVE HOOK STRIPS ONLY IF THE BACK PANEL IS NOT INSTALLED. Attach horizontally to the inside edge of the side roll bars in the curve at the back of the side roll bars. The 5" webbing/loop tab attaches to the adhesive hook strip. IF THE BACK PANEL IS INSTALLED, ATTACH TO THE EXPOSED HOOK ALONG THE EDGE OF THE REAR PANEL.
G	2-3"	USE THE ADHESIVE HOOK STRIPS ONLY IF THE BACK PANEL IS NOT INSTALLED. Attach vertically to the back/top side of the rear roll bar uprights corresponding to the 3" sewn-in loop just above the door zipper. The 3" sewn-in loop attaches to the adhesive hook strip. IF THE BACK PANEL IS INSTALLED, ATTACH TO THE EXPOSED HOOK ALONG THE EDGE OF THE REAR PANEL.


H	2-15"	USE THE ADHESIVE HOOK STRIPS ONLY IF THE BACK PANEL IS NOT INSTALLED. Attach vertically to the back side of the rear roll bar uprights corresponding to the 15" sewn-in loop just below the door zipper. The 15" sewn-in loop strip attaches to the adhesive hook strip. IF THE BACK PANEL IS INSTALLED, ATTACH TO THE EXPOSED HOOK ALONG THE EDGE OF THE REAR PANEL.
I	2-5"	USE THE ADHESIVE HOOK STRIPS ONLY IF THE BACK PANEL IS NOT INSTALLED. Attach vertically to the back/bottom of the rear roll bar uprights corresponding to the 5" sewn-in loop. The 5" sewn-in loop strip attaches to the adhesive hook strip. IF THE BACK PANEL IS INSTALLED, ATTACH TO THE EXPOSED HOOK ALONG THE EDGE OF THE REAR PANEL.
J	2-6"	Attach diagonally to the outside of the door panel corresponding to the 6" sewn-in loop strip on the back side of the bottom door panel. The 6" sewn-in loop strip attaches to the adhesive hook strip.
K	2-30"	Attach horizontally to the outside of the door panel corresponding to the 30" sewn-in loop strip on the bottom of the door panel. The 30" sewn-in loop strip attaches to the adhesive hook strip.
L	2-5"	Attach vertically to the body corresponding to the sewn-in loop along the back edge of the lower door panel.
M	2-6"	Attach vertically to the front of the door panel corresponding to the sewn-in loop strip at the front of the bottom door panel. The 6" sewn-in loop strip attaches to the adhesive hook strip.
TOP		
A	1-39"	Apply to the underside of the front visor. Attach the sewn-in loop to the adhesive hook strip
B	4-10"	Attach horizontally near the bottom of the front and rear roll bars uprights. Wrap the sewn-in double-sided straps at the bottom of the tension strap around the adhesive hook strips. If needed, loosen the tension strap to extend the length of the strap. After the top is in place and aligned, reconnect the snap buckle. Pull down on the loose tension strap to pull the top tight to the roll bar.

REAR PANEL



DOOR PANELS





TOP






Step 4: After all adhesive hook strips are attached, begin attaching the enclosure to the cab frame. As you attach the hook and loop, square each panel to the frame. **PLEASE NOTE, FOR MAXIMUM ADHESION, ALLOW THE ADHESIVE HOOK TO ADHERE TO THE FRAME FOR 24 HOURS BEFORE PULLING AGAINST THE HOOK WITH THE LOOP STRIPS.**

Step 5: Wrap the double-sided strap at the bottom of the V on the back side of the door to the corresponding bar. The location is shown below.



Step 6: If the front tab needs to be cut to accommodate windshield clamps, please use the following instructions.



Mark windshield tabs where hard windshield clamps are located along the windshield Roll Bar



Cut the Tab being very careful not to cut the binding at the edge



Seal Frayed Tab thread at the cut area using a lighter

Step 7: Repeat any steps necessary to achieve a snug fit on the cab frame.

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



3 STAR INDUSTRIES

Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**