



Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little rubbing alcohol works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.



Polaris Ranger XP Full Cab Enclosure Installation

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Full Cab Enclosure**.

Step 1: Remove your 3SI UTV Full Cab Enclosure and Velcro kit from the shipping box.

Contents: 1 – Polaris Ranger XP Full Cab Enclosure

2 – 21" Velcro Strips - Rear Cab frame Lower driver's side and passenger side

1 – 17" Velcro Strip – Rear Cab frame Center; above breather

2 – 18 ½" Velcro Strips – Door - Rear Panel lower

2 – 28" Velcro Strips – Door – Rocker Panel lower

2 – 24 ½" Velcro Strips – Door – Front Cowl Panel Lower

2 – 4 ½" Velcro Strips – Door Front lower corner

4 - 8" Velcro Strips - 2 Front Windshield Roll Bar uprights – Top, 2 Rear Roll Bar Uprights - middle

2 – 6" Velcro Strips – Front Windshield Roll Bar uprights – middle

2 – 4" Velcro Strips – Front Windshield Roll Bar uprights - bottom

Note: before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil. Clean surfaces with water and mild soap only. Do not use solvents to prepare your vehicle surfaces for Velcro application.

Step 2: Remove the clear plastic backing from the **21" Velcro strips** and the **17" Velcro Strip** and adhere to the **Rear Cab Frame** as shown in figure 2.1. **Note you will need to raise the vehicle bed to perform this installation step**



Figure 2.1 – attach 21” Velcro strip to the Rear Cab Frame on Passenger and Drive side; attach 17” Velcro Strip above breather at center

Step 3: Remove the clear plastic backing from the 4”, 6” and 8” Velcro strips and adhere vertically along the Front Windshield Roll Bar Posts as shown in figures 3.1, 3.2 and 3.3. Remove the clear plastic backing from the remaining 8” Velcro Strips and place vertically along the rear Roll Bar upright as shown in figure 3.4. Velcro strips should face away from the center of the cab.



Figure 3.1 - attach 4” Velcro strips vertically at the front roll bar post cowl opening



Figure 3.2 - attach 6" Velcro strips vertically 7 1/2" above the front roll bar post cowl opening



Figure 3.3 - attach 8" Velcro Strips vertically 18 1/2" above the front roll bar post cowl opening



Figure 3.4 – attach Rear Roll Bar upright Velcro strips 4" above the arm rest bar

Step 4: Remove the clear plastic backing from the 18 ½" Velcro strips and attach vertically to the lower Rear Door Panel as shown in figure 4.1



Figure 4.1 - attach 18 ½" Velcro Strips vertically along the lower Rear Door Panel

Step 5: Remove the clear plastic backing from the 24 ½" Velcro strips and attach vertically to the Front Cowl Panel as shown in figure 5.1 Also attach the 4 ½" Velcro strips horizontally along the door lower front corner near the bottom of the 24 ½" Velcro strip.



Figure 5.1 – attach 24 ½" Velcro Strips vertically along the lower Front Cowl Panel

Step 6: Remove the clear plastic backing from the 28" Velcro strips and attach horizontally along the Rocker Panel as shown in figure 6.1.



Figure 6.1 – attach 28" Velcro Strips horizontally along the door Rocker Panel

Step 7: Place the Full Cab Enclosure on top of the Roll Bar Cab Frame as shown in figure 7.1 and adjust so that the enclosure seams are located near the center of the Roll Bars. The vehicle bed will need to be raised for this installation step.



Figure 7.1 - place enclosure on vehicle cab roll bar structure – align enclosure seams with center of roll bars

Step 8: Begin attaching Enclosure by first squaring the back of the Enclosure to the Rear of the Cab frame and attaching the lower Rear Cab Velcro tabs to the installed 21” Velcro strips and 17” Velcro strip as shown in figure 8.1. Pulling upward and outward on the rear side corners of the cab also attach the enclosure Velcro tabs to the installed 8” rear Roll Bar upright Velcro strips.




Figure 8.1 - square rear of enclosure to cab and attach rear enclosure Velcro tabs to installed Velcro strips

Step 9: Fasten pre-attached Enclosure Front Hood Straps to the Vehicle front bumper as shown in figure 9.1. Bringing the end of the straps up to the latch buckle, run the end through the back of the top buckle opening first and then through the front of the lower buckle opening as shown in figure 9.2. DO NOT FULLY TIGHTEN FRONT HOOD STRAPS AT THIS TIME.



Figure 9.1 - run front hood straps around front bumper




Figure 9.2 - thread front hood straps through the buckles

Step 10: Starting with the top Front Roll Bar Post Enclosure tabs pull outward and downward attaching tabs to the top 8" inch Velcro Strips as shown in figure 10.1. Repeat this process with the middle 6" and then lower 4" Front Roll Bar Enclosure Tabs as shown in figure 10.2 and 10.3 making sure that the Windshield is centered between the Roll Bar posts. Note: this step is best performed with an assistant attaching Tabs on both sides of the Windshield at the same time.



Figure 10.1 - attach top front Windshield roll bar 8" Velcro tabs



Figure 10.2 - attach middle front Windshield roll bar 6" Velcro tabs



Figure 10.3 - attach bottom front Windshield roll bar 4" Velcro tabs

Step 11: Tighten Front Hood Straps by pulling downward from the buckle on both strap ends at the same time as shown in figure 11.1



Figure 11.1 – Fully tighten both Hood Straps pulling downward on both at the same time

Step 12: Zip Doors closed and attach Door Rear Panel, Door Rocker Panel and Door Front Cowl Panel Velcro Tabs to respective Velcro Strips as shown in figure 12.1 , 12.2 and 12.3.



Figure 12.1 – attach Door Rear Panel Enclosure 18 ½" Velcro Tabs




Figure 12.2 – attach Door Rocker Panel Enclosure 28" Velcro Tabs



Figure 12.3 – attach Door Front Cowl Panel Enclosure 24½” & lower front 4 ½” Velcro Tabs

Step 13: Repeat Steps 10, 11 and 12 until the Enclosure fits snugly to the Vehicle Roll Bar structure and front and rear windows are tight as shown in figure 13.1



Figure 13.1 – Repeat Steps 10, 11 and 12 until the enclosure fits snugly to the vehicle roll bar cab and windows are tight

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**