



Wire Balustrade Kit A

Key Benefits

- ✓ Easy To Install
- ✓ Popular
- ✓ One-Person Install
- ✓ Versatile

Maximum Run Span

10 Metres

About This Kit

Metal Posts



✗ Not Suitable

Timber Posts



✓ Suitable

Post Material

This kit is suitable for timber posts only.

Horizontal Balustrade



✓ Suitable

Angled Balustrade



✓ Suitable

Post Type

This kit is suitable for both horizontal and angled balustrade.

1x19 Wire



✓ Suitable

7 x 7 Wire



✓ Suitable

Wire Type

This kit can be used with any wire.

Wire Balustrade Kit A

Bottle Screw



SSW050-6 or SSW051-6

Fork Terminal



SSW053-6

Coach Screws
x2



SSW054-6 or SSW055-6

Tools Required

3.2mm Wire



SSW001 or SSW020

Wire Cutters



IF122X

Wire Spanner



IF133X

Hydraulic
Swager



IF120X or IF119X

Drill Bit



IF114X

Instructions

Step 1



Pre-Drill Holes

Mark out and pre-drill holes on all end and intermediate posts. 80mm spacing is recommended.

Recommended hole size:

- 4mm holes for softwood end posts
- 4.5mm holes for hardwood end posts
- 4mm for intermediate posts

Step 2



Insert Coach Screws

Use the coach screw drive bit + an electric drill to drive the eye bolts into the pre-drilled post. Only the head of the eyebolt should be visible.

** This step can be completed by hand if you have not purchased the drive bit*


Step 3



Install Fork Terminal

Crimp one end of your wire into the fork terminal using the hydraulic swager. Then, remove the pin from the terminal and attach it to the eyebolt on one end of your posts.

Step 4



Pass Wire Through Posts

Pass the wire through your intermediate posts.

Step 5



Install Bottle Screw

Crimp the other end of your wire into the bottle screw and attach it to the eyebolt.

Step 6



Tension Wire

Use the spanner to tension the wire.

Lock the hex nuts against the body of the bottle screw to lock in place.