



Wire Balustrade Kit N

Key Benefits

- ✓ One Person Install
- ✓ No Hydraulic Tools Needed
- ✓ Slim/Streamline

Maximum Run Span

6 Metres

Maximum Wall Thickness of Post

3mm

About This Kit

Metal Posts



✓ Suitable

Timber Posts



✗ Not Suitable

Horizontal Balustrade



✓ Suitable

Angled Balustrade



✗ Not Suitable

Post Material

This kit is only suitable for metal posts.

Post Type

This kit is only suitable for horizontal balustrades.

1x19 Wire



✓ Suitable

7 x 7 Wire



✓ Suitable

Wire Type

This kit can be used with any wire.


Wire Balustrade Kit N



Tools Required




Instructions




Step 1

Pre Drill Holes
Mark out and pre-drill holes on all end and intermediate posts. 80mm spacing is recommended.
Recommended hole size:
- 11mm for end posts
- 4mm for intermediate posts



Step 2


Insert Rivet Nuts
Insert the rivet nuts into the posts (video tutorial available on our [youtube channel](#))



Step 3

Pass Wire Through End Post
Thread the stop bolt & one of the swage terminals onto one end of your wire.


Crimp the swage terminal 4 times to fix in place.



Step 4

Install stop end & pass through intermediates
Thread the stop bolt into the rivet nut.

Then, pass the wire through the intermediate posts



Step 5

Pass Wire Through & Repeat
Thread the finishing cap, tension rod & swage terminal (as above) onto the wire. Crimp the swage terminal four times



Step 6

Tension Wire
Thread the tension rod into the rivet nut and tighten using the spanner.

Soft jaw pliers can be used to tighten the finishing cap against the threaded insert