

SYMBOLS AND DEFINITIONS		
<b>⚠ DANGER ⚠</b>	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.	
<b>⚠ WARNING ⚠</b>	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.	
<b>⚠ CAUTION ⚠</b>	Indicates a hazardous situation which, if not avoided, could result in moderate injury.	

## ⚠ DANGER ⚠

- Do not submerge this item.
- Keep plugs and receptacles dry.

## ⚠ WARNING ⚠

- When using product, basic precautions should always be followed.
- Carefully read and understand the information given in this guide before using this light.
- Save this User Guide.
- Do not use in areas with temperature higher than 104°F Fahrenheit.

## ⚠ CAUTION ⚠

- Do not use in areas near a gas source. This light is not for use in potentially explosive environments. This is not a vapor proof light.
- This light is not a toy and is not suitable for use by children.
- Protect your eyes. Do not look directly at the LED lights for extended periods of time.
- Do not remove the lens protecting the LED. It is not possible to change the LED light source. The LED chips are not replaceable.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- Disassembling or modifying this unit will void the warranty.

### GT-WL-H300 300 Lumen LED Rechargeable Handheld Work Light



**GT-LITE LIMITED WARRANTY:** This product is guaranteed against failure due to factory defects in materials or workmanship for one (1) year from the date of purchase. This warranty is non-transferable and applies only to the original owner. Proof of purchase required for repair or replacement. Keep product receipt with this User Guide and save in a dry location. The warranty does not cover normal wear and tear of parts or damage resulting from misuse of the product. Misuse of the product includes but is not limited to: using in extreme weather conditions, opening the housing of the product, or alterations to the product.

SYMBOLS AND DEFINITIONS		
<b>⚠ DANGER ⚠</b>	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.	
<b>⚠ WARNING ⚠</b>	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.	
<b>⚠ CAUTION ⚠</b>	Indicates a hazardous situation which, if not avoided, could result in moderate injury.	

## ⚠ DANGER ⚠

- Do not submerge this item.
- Keep plugs and receptacles dry.

## ⚠ WARNING ⚠

- When using product, basic precautions should always be followed.
- Carefully read and understand the information given in this guide before using this light.
- Save this User Guide.
- Do not use in areas with temperature higher than 104°F Fahrenheit.


## ⚠ CAUTION ⚠

- Do not use in areas near a gas source. This light is not for use in potentially explosive environments. This is not a vapor proof light.
- This light is not a toy and is not suitable for use by children.
- Protect your eyes. Do not look directly at the LED lights for extended periods of time.
- Do not remove the lens protecting the LED. It is not possible to change the LED light source. The LED chips are not replaceable.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- Disassembling or modifying this unit will void the warranty.

### GT-WL-H300 300 Lumen LED Rechargeable Handheld Work Light



**GT-LITE LIMITED WARRANTY:** This product is guaranteed against failure due to factory defects in materials or workmanship for one (1) year from the date of purchase. This warranty is non-transferable and applies only to the original owner. Proof of purchase required for repair or replacement. Keep product receipt with this User Guide and save in a dry location. The warranty does not cover normal wear and tear of parts or damage resulting from misuse of the product. Misuse of the product includes but is not limited to: using in extreme weather conditions, opening the housing of the product, or alterations to the product.



**WORK LIGHT CONSTRUCTION:**

- A. Swivel hanging hook
- B. Spot beam flashlight (8 hour run time on flashlight)
- C. Flood beam work light (4 hour run time on high)  
(6.5 hour run time on low)
- D. Charging port cover
- E. Micro USB charging port
- F. Micro USB charging cable
- G. Battery level indicator
- H. On/Off Button
- I. Magnetic base and kickstand.

**TO USE:**

1. **CHARGE THE LIGHT FOR APPROXIMATELY 3 HOURS**
  - a. Insert the Micro End of the Micro Cable (F) into the Micro Port (E) on the side of the work light.
  - b. Insert USB end of the Micro Cable (F) into an AC or DC adapter.
  - c. This product must be charged with UL or ETL certified adapters or warranty will be void.
  - d. Plug the adapter into power.

2. Place the light on a sturdy surface. Ensure that hanging hook (A) kickstand, or magnetic base (I) is fully engaged.
3. Press on/off (H) to turn on flood beam 150LM low work light.
4. Press on/off (H) again to switch to 300LM high work light.
5. Press on/off (H) again to switch to spot beam flashlight.
6. Press on/off (H) again to turn all lights off.
7. Cycle through Low/High/Flashlight/Off by pressing On/Off (H).
8. Store in a cool dry place when not in use.

**TROUBLESHOOTING**


Problem		Solution
LED is not lighting up.	LED Light is not fully charged.	Charge battery for a full 3 hours and attempt again.
Questions, Warranty, Missing Parts	Email: info@gt-ind.com	Customer Service: 1-800-865-6799

**CARE AND CLEANING**

Your fixture is made from quality materials that will last an extended period of time with proper care—including periodically cleaning the surface of the fixture.

1. Use a mild, non-abrasive cleaner. Do not use any solvents or harsh cleaning agents.
2. Use a soft, non-abrasive cloth.
3. Lightly spray cleaner onto the cloth. Do not spray liquid cleaners directly onto LEDs, power cord, or any part of this product.
4. Lightly wipe down fixture with damp cloth. Allow product to dry completely before restoring power and using LED lights.

**NOTICE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.



**WORK LIGHT CONSTRUCTION:**

- A. Swivel hanging hook
- B. Spot beam flashlight (8 hour run time on flashlight)
- C. Flood beam work light (4 hour run time on high)  
(6.5 hour run time on low)
- D. Charging port cover
- E. Micro USB charging port
- F. Micro USB charging cable
- G. Battery level indicator
- H. On/Off Button
- I. Magnetic base and kickstand.

**TO USE:**

1. **CHARGE THE LIGHT FOR APPROXIMATELY 3 HOURS**
  - a. Insert the Micro End of the Micro Cable (F) into the Micro Port (E) on the side of the work light.
  - b. Insert USB end of the Micro Cable (F) into an AC or DC adapter.
  - c. This product must be charged with UL or ETL certified adapters or warranty will be void.
  - d. Plug the adapter into power.

2. Place the light on a sturdy surface. Ensure that hanging hook (A) kickstand, or magnetic base (I) is fully engaged.
3. Press on/off (H) to turn on flood beam 150LM low work light.
4. Press on/off (H) again to switch to 300LM high work light.
5. Press on/off (H) again to switch to spot beam flashlight.
6. Press on/off (H) again to turn all lights off.
7. Cycle through Low/High/Flashlight/Off by pressing On/Off (H).
8. Store in a cool dry place when not in use.

**TROUBLESHOOTING**

Problem		Solution
LED is not lighting up.	LED Light is not fully charged.	Charge battery for a full 3 hours and attempt again.
Questions, Warranty, Missing Parts	Email: info@gt-ind.com	Customer Service: 1-800-865-6799

**CARE AND CLEANING**

Your fixture is made from quality materials that will last an extended period of time with proper care—including periodically cleaning the surface of the fixture.

1. Use a mild, non-abrasive cleaner. Do not use any solvents or harsh cleaning agents.
2. Use a soft, non-abrasive cloth.
3. Lightly spray cleaner onto the cloth. Do not spray liquid cleaners directly onto LEDs, power cord, or any part of this product.
4. Lightly wipe down fixture with damp cloth. Allow product to dry completely before restoring power and using LED lights.

**NOTICE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.