



2-BIKE HITCH-TIGHTENING SYSTEM & FLEXIBLE WHEEL

Model:DB-HBS42




INSTRUCTION




INSTALLATION STEPS

STEP 1:




- 1 Two pieces of **K** are loaded into the inside of **A** in advance. (The two cylinders of **K** are inserted into the two small holes).
- ② Insert **B** into the interior of **A** and then connect in order with **I-J-H** fasteners.

STFP 2:




Insert C into figure B, the 4 holes on the side are connected with 4 sets of standard parts S-T-U locking respectively (Install the two inner holes first and then the outermost hole) .


STEP 3



Insert **D1** and **D2** into figure **C**, respectively, and lock the connection with their own hand screw nuts.




Insert the ${f G1}$ and ${f G2}$ components into the upper square opening of the assembled bike frame B and position the sliding position with the keys ${f X}$ carried on the ${f G1}$, ${f G2}$ components, adjust to suitable position, lock ${f G1}$ ${f G2}$ with key ${f X}$.




Insert the **V** at the place marked by the arrow above, and tighten it with a screwdriver.

STEP 6:




- 1 Insert **R** into the tariler bar.
- ② Lock the trailer lock (R) with the key (W) and keep the key
- ③ Pass **P**,**Q** through **O**,**M**,**N** and lock them with wrench.

DISASSEMBLY STEPS




- After the handle is locked, P and Q will be locked by M, N and O with a wrench.
- Remove the **O-M-N** with the handle and take off the **P-Q** and put it away.

TIGHTEN THE HANDLE




- •Hold **(b)** with your left hand and pull it outward slightly.
- •Squeeze ⓐ tightly with the right hand and tighten.
- •Loosen **b**.
- •Pull out **@** and rotate **c** to 90°.
- •Insert **(d)** and rotate the handle clockwise until tightened.
- •Pull out **(b) (c)** with force and rotate back to the initial state to tighten again.
- •Disassembly steps refer to tightening steps.


RACK FOLDING STEPS



Press the column slightly to the left, while pressing the pop-up buckle as shown, and fold the column to the right.



Press the downed column slightly downward, while pressing the pop-up buckle as shown in the picture, and lift the column to the left.




Pull out the T-pull, and rotate the frame 90 degrees, then fold and collect the T-pull after releasing it. And rotate it 90 degrees, and then snap the square into the sheet metal slot for positioning.

STEP 4:

Pull up the handle to fold up when not carrying bikes.

RACK TILT STEPS



GENERAL CONSIDERATIONS

WARNING WHEN INSTALLING THE FRAME

- 1.Every month new designs and bodies are introduced to the market.
- 2. While the FORWODE bike carrier design team strives to make most products universal to the cars on the market. It is impossible for a single bike carrier to fit all models of cars on the market.
- 3.Before you purchase a rack, please check if the rack fits your vehicle with an authorized FORWODE Bike Rack dealer or distributor.
- 4.Before installation, please read the instructions and then follow the attached instructions.
- 5.Before installation, please make sure all parts are preset and in working condition. For any missing or damaged parts, please contact your authorized FOR-WODE Bike Rack dealer or distributor.
- 6.Please always keep this manual for future reference.

- 1. When the vehicle is equipped with an electric rear fender, the power must be turned off when installing the rear carrier. If this option is not available, do not use the rear bike carrier.
- 2. Clean the receiver connector thoroughly before installing.
- 3. When the vehicle is equipped with a spoiler or similar item, it is necessary to change the mounting method of the bike carrier. If this happens, please contact an authorized FOR-WODE bike carrier verifying dealer or distributor.
- 4. When using the bike carrier, please observe local traffic laws.
- 5. When not in use, please remove the rack before washing your bike.

WARNING WHEN MOUNTING THE BICYCLE

1. When you ride your bicycle, make sure that it does not touch the vehicle, especially the pedals. Using protective foam pads may be helpful.

- 2. Remove all loose items before mounting the bike. For example, water bottles.
- 3. Bicycle tires must be kept away from vehicle exhaust fumes.
- 4. Always observe the weight of each bicycle (60 lbs. maximum per bicycle) and the capacity of the bicycle, according to the manufacturer's recommendations.
- 5. Bike mounts/bikes are mounted with different road behavior for vehicles. Use extreme caution when driving in high winds, sharp turns and on rough roads. Drive slowly over speed bumps (10 km/h)
- 6. Vehicles with bike racks installed have extra width and length. Also, make sure that the bicycle is mounted in the middle to avoid excessive protrusion.
- 7. When the vehicle is equipped with a bicycle rack, check the installation of the rack and the installation of the bicycle every 100 km while driving. It is the driver's responsibility to ensure the safety of passengers and others!

WARRANTY AND LIABILITY

- 1.FORWODE does not bother to assume any liability for any damages (to the vehicle, damage caused by incorrect installation and use of this product or its accessories, goods and/or persons in connection with the purchase, use or handling of this product).
- 2.If you have further questions about our limited lifetime warranty or need any support, you can start a conversation with us at service@forwodebike.com.

