


Jewenwils

Wi-Fi Low Voltage Transformer

SKU: HOSL05D2

[Instruction Manual]



Please pay attention to the warning signs
Read the instructions with caution before operating
and keep it properly

READ ALL INSTRUCTIONS before using the Wi-Fi Low Voltage Transformer.

Compatible with 2.4 GHz Wi-Fi networks.

If you have multiple routers in your home, especially under the same modem and using dynamic IP address mode, please notice the routers with same LAN IP address may cause IP address conflict and make the routers involved cannot access internet. which makes Wi-Fi Low Voltage Transformer cannot be discovered and controlled via internet (like user's cellular data service).

Status Indicator

Blinking Light: Ready to connect to Wi-Fi router.

Light continuously ON: Connection to Wi-Fi router is complete and Wi-Fi Low Voltage Transformer is ready for use via the app.

Light OFF: Check your internet connection or review the app FAQ.

①

③

Power Button


Press this button to manually override the Wi-Fi Low Voltage Transformer and turn the unit ON/OFF.

④

Reset Button

Power Indicator

②



IMPORTANT: Please refer to **INSTALLATION INSTRUCTION** before proceeding with Wi-Fi router connection. Wi-Fi Low Voltage Transformer must be installed before connecting to Wi-Fi router.

TO CONNECT THE Wi-Fi Low Voltage Transformer TO A WI-FI ROUTER

STEP 1: Software Installation

Download the "dewenwils" App: Scan QR Code or search "dewenwils" in Google Play or the App Store to download and install the app.

Note: All pictures shown are for illustration purpose only, the APP will be updated continuously, please refer to the latest APP interface to operate.



dewenwils



Free APP for android and IOS



STEP 2: Log in or Sign up

Log In

United States of America

Please enter your account

Password

Log In

[Forgot Password](#)

Register

United States of America

Email Address

Get Verification Code

I Agree [User Agreement](#) and [Privacy Policy](#)

Note: Each device can only be connected to one account. If anyone else needs to control it, please share your device via the app.

STEP 3: Add the Wi-Fi Low Voltage transformer

Note: The Wi-Fi Low Voltage transformer only support 2.4GHz network.

LED Status	Function
Red LED is on	Power is on
Red LED is off	Power is off
Green LED is blinks rapidly	Bluetooth provisioning network
Green LED is blinks slowly	Hotspot provisioning network
Green LED is on	Connect to the Internet successfully

Note:

- If the Wi-Fi Low Voltage transformer can't be connected to WiFi, Please press and hold the power button while pressing RESET button until the WiFi signal indicator flashes, then release the two buttons, the data has been cleared. Then remove the sub-device on the app, and re-add the device; or long press the RESET button again to enter the hotspot network and remove the device on the app, then add the device again.
- The Wi-Fi Low Voltage transformer only work with 2.4GHz network. If your router broadcasts both 2.4GHz and 5GHz, please select the 2.4GHz network with the app. If connection still fails), we recommend you call your ISP and had them completely shut off the 5GHz network on the router. You are free to change the network to 5GHz again after connecting.
- Please try to make the Wi-Fi Low Voltage transformer and router as close as possible.

1) Auto Add Mode (Bluetooth Mode)

- Turn on Bluetooth on the smartphone.
- Open the “dewenwils” APP (Figure 1) and click the “+” at the top right list, it will find the Wi-Fi Low Voltage transformer automatically. (Figure 2) Tap “Go to add”, the interface in Figure 3 will appear, click the button to switch to the appropriate WiFi signal source, then type in WiFi password and click “next” to enter the interface in Figure 4. At this time the device is connecting to your home WiFi automatically.




Figure 1




Figure 2




Figure 3




Figure 4

The prompt in Figure 5 will appear after connecting successfully.




Figure 5

- If the Wi-Fi Low Voltage transformer is not automatically discovered, select “Auto Scan” to automatically search for the Wi-Fi Low Voltage transformer. (Figure 6) After clicking “next”, Figure 3 will appear, then type in correct password and click “next”, Figure 7 and Figure 8 will appear in sequence to remind you that the connection is successful.



Figure 6




Figure 7




Figure 8

Note: Automatic connection time of devices varies depending on the strength of WiFi signal, so please do not operate the phone. If the connection fails, please reconnect, or switch to other stronger WiFi signal sources, or keep your phone closer to the device, or connect it by following the Manually Mode below.

2) Add Manually Mode

- Click the "+" icon at the right corner and then choose the "Wi-Fi Low Voltage transformer". (Figure 9)




Figure 9

- Follow ①②③ on the app to confirm in turn (in step ①), please check the mode on the left side of ↔ at the top right corner, if it is not "EZ Mode", please switch to "EZ Mode". In step ②, please press and hold the RESET button on the transformer for more than 5 seconds, and release the button when the indicator flashes. In step ③, click "Confirm the indicator is blinking rapidly", and click "Next"). As shown in Figure 10 to 12.



Figure 10




Figure 11



Figure 12

- Select 2.4GHz Wi-Fi Network and enter password, then click "NEXT". Wait for the connection to complete. (Figure 13)




Figure 13

- Wi-Fi Low Voltage transformer has been added successfully. (Figure 14)




Figure 14




Figure 15

STEP 4: Set the Function You Need

1. Interface Introduction




Figure 15

2. Timer Function Introduction

Tap "Timer", the interface of Timer Schedule will appear.(Figure 16)

Tap the plus icon to add tasks, including schedule, circulate, and random modes.(Figure 17)




Figure 16




Figure 17

3.Schedule

Tap "Schedule" to enter the interface as shown in Figure 18. You can set the Start/End time in a 7-day period with a 1 minute interval according to needs. Every program set before repeats weekly.(Figure 18, 19)Tap "Save" to return and review the overall schedule, (Figure 21).

Note: The device can only be turned on and off properly when selecting PerformSwitch as switch.(Figure 20)

Note: Please select Perform Action to open or close as needed. (Figure 18, 19)




Figure 18




Figure 19




Figure 20




Figure 21

4.Circulate

You can set the duration of each ON and OFF, Start and End time according to your needs. The ON/OFF schedule will repeat between the Start and End time. For example: Set a period from 9:00 AM to 3:00 PM on Monday through Friday, turn on your light for 1 hour, and off for 30 minutes. The outlet will repeat ON/OFF from 9:00 AM to 3:00 PM.(Figure 22, 23)

Note:The device can only be turned on and off properly when selecting PerformSwitch as switch. (Figure 20)




Figure 22




Figure 23

5.Random

Either +/-30 minutes than setting ON/OFF time, randomly control device when you are away from home.




Figure 24




Figure 25

6.Countdown

Tap "🕒" to set the hours and minutes, and then tap the "Confirm" button. The Wi-Fi Low Voltage transformer will maintain the current state (on or off) until the end of the countdown. It will exit countdown mode automatically if you turn on/off manually. (Figure 26, 27)




Figure 26



Figure 27

Work with Amazon Alexa

Easy and Fast Binding of Skills

Option 1: APP to APP (OEM App Redirects to Alexa to Bind)

Discover the corresponding OEM Alexa skills directly in your OEM APP, and easily complete the skill setting and account connection without opening multiple Apps, greatly shortening the user operation path

1. Find "Me" on the home page, tap More Services
2. Tap Alexa
3. Tap Login
4. Tap Link to complete skill binding

Option 2: APP to APP (Alexa Redirects to OEM App to Bind)

Search for the corresponding OEM Alexa skill in Alexa APP and directly redirect to bind your OEM APP, avoiding the failure of skill binding due to incorrect account password input, greatly improving the success rate of configuration.

1. Find corresponding skill in Alexa APP
2. Tap "Agree and link"
3. Complete the skill binding

Note: It is recommended to purchase all the functions together for the best experience (the above illustration are all based on Tuya Smart App)

Work with Google Home

Preparation

1. Make sure the smart device has been added to the dewenwils App and the device is online.
2. Make sure the Google Home App is installed.

Start

1. Click Me in the bottom right corner, click Google Assistant, click Link with Google Assistant.
2. The App will pull up the Google Home App, click Link.
3. Click agree Link.
4. Wait for it to finish loading, your smart devices will be synced to Google Assistant or Google Home App that can control them. Next, you can assign rooms to your devices in the Google Home App.

Other Functions




Figure 28

INSTALLATION INSTRUCTIONS

Important safety information to reduce risk of fire injury.

1. Do not install within 10 feet (3 m) of a pool, spa or fountain.
2. No serviceable parts inside the power supply unit. **DO NOT DISASSEMBLE.**
3. Do not repair or tamper with cord or plug.
4. Do not submerge transformer in water.
5. Do not mount the transformer onto combustible material.
6. Do not connect two or more transformers in parallel.
7. Do not use the transformer with a dimmer switch.
8. Plug the power supply unit directly into a GFCI outlet in wet location.
9. For low voltage outdoor landscape lighting system use only.
10. The maximum output of this transformer is 300 watts. Do not overload the transformer. Be sure that the total cumulative wattage of all 12 volt fixtures connected to the transformer be equal to or less than 300 watts.

CAUTION: This landscape light system must be installed in accordance with all local codes and ordinances. If you encounter problems, contact a qualified electrician.


CALCULATE LIGHTING CAPACITY

The 300 Watt transformer has 300 watt circuits which will power up to 300 watts of light. To make sure the maximum number of fixtures can be safely connected to this transformer, add up the individual wattage of all the fixtures. The total wattage of your fixtures must not exceed output capacity of the 300 Watt transformer.

INSTALLATION



1. Prepare the Cable

Be careful when splitting the landscape cable. Do NOT expose the copper cable. Remove 1/2 inch of insulation from both cables and twist the ends.




2. Connect the cable to the Transformer

Lay the transformer on a flat, stable surface and use screwdriver to connect the stripped ends of the cable under the terminal clamping plate.




Note: Gently pull on the landscape cable to verify if the connection is strong.



3. Place Your Fixtures and Route the cable

Lay your fixtures (not included) to your desired location. Be sure they do not exceed the 120-watt rating of the transformer. Coil the rest of the cable after connecting the last fixture.




4. Attach Your Fixtures

Turn the transformer on. Use the cable connectors to attach your fixtures with the cable. Then it will light up.

5. Mount the Transformer

Use the screw to mount the transformer directly on a wall. 12 inch to 48 inch (0.3 m to 1.2 m) high from the ground would be suggested.



CABLE SELECTION CHART

12 VOLT TAP	Cable Length		
Total Fixture Wattage	0-50 feet	51-100 feet	100-150 feet
0-60 Watts	16 AWG	16 AWG	14 AWG
61-120 Watts	16 AWG	14 AWG	12 AWG
121-180 Watts	14 AWG	12 AWG	Not Recommended
181-240 Watts	14 AWG	12 AWG	Not Recommended
241-300 Watts	12 AWG	Not Recommended	Not Recommended

14 VOLT TAP	Cable Length		
Total Fixture Wattage	0-50 feet	51-100 feet	100-150 feet
0-60 Watts	16 AWG ¹	16 AWG	16 AWG
61-120 Watts	16 AWG ¹	16 AWG	12 AWG
121-180 Watts	14 AWG ¹	14 AWG	12 AWG
181-240 Watts	14 AWG ¹	14 AWG	12 AWG
241-300 Watts	12 AWG ¹	12 AWG	Not Recommended

AWG¹ Not recommended for Halogen Landscape.



NOTE: This data is provided as a general guideline. Actual performance will depend on the installation layout, the fixtures, and the condition of the cable. If the wire diameter you use is thinner than the wire diameter recommended in the table, it may cause the flickering of the end lamps.

Specifications

Input Voltage: 120VAC, 60Hz

Output: 12VAC

Max Power Rating: 300W

Package List

- 1 x Low-Voltage Transformer
- 2 x Screws
- 2 x Wall Anchors
- 1 x Instruction Manual

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy , if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The use distance should be greater than 20cm.

ISED Warning:

This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure statement for ISED

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance. The minimum distance from body to use the device is 20cm.

Le présent appareil est conformeAprès examen de ce matériel aux conformité ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes. La distance minimale du corps à utiliser le dispositif est de 20cm.

One Year Limited Warranty

Supported by our professional R&D team and QC team, we provide One Year Warranty for materials and workmanship from the purchase date. Please note that the warranty does not cover damage caused by personal misuse or improper installation.

Please attach your Order ID and Name so that our dedicated customer service team can help you better.

