

Bluetooth Audio Receiver with Built-in Microphone

Quick Start Guide



model AISM01F

aluratek.com

qsg Q10444 Copyright © 2021 Aluratek, Inc. All Rights Reserved.

Package Contents

Your order has been carefully packaged and inspected. The following accessories should be included in your package. Please inspect the contents of the package to ensure that you have received all items and that nothing has been damaged. If you discover a problem, please contact us immediately for assistance.



USB Charging Cable



3.5mm Audio Cable



Registration Card

Product Highlights



Multi Function Button

ON / OFF and pairing


Music:
Press button to play and pause songs (Use your device to change the volume and track)

Phone Calls:
Press button to answer, reject hang up calls, redial last number and cancel dialing

Micro USB Charging Port

Charging Port Cap

Product Application



Connect to stereos, speaker docks and car stereos with an AUX IN (3.5 mm)

Stream audio up to 33 feet

3.5 mm cable

OR
Connect to wired headphones and earbuds

*Bluetooth enabled

Operation

Control Functions

Function	Operation
Power ON	When OFF, press and hold the multi-function button for 2 seconds until the blue LED flashes
Power OFF	When ON, press and hold the multi-function button for 3 seconds until the red LED flashes
Pairing	When OFF, press and hold the multi-function button for 2 seconds until blue and red LED flashes
Answer Call, Hang up Call, Cancel Dialing	Short press multi-function button
Reject Call	Press and hold the multi-function button for 1 second
Redial Last #	Short press multi-function button twice
Play / Pause Song	Short press multi-function button

Operation

LED Indicators

LED Indicator	Status
Solid Red LED	Charging
Flashing Red and Blue	Pairing Mode
Flashing Red	Low battery
Flashing Blue (Once every 5 seconds)	Connected to a device (when not connected to a power source)

Operation

Pairing

Please make sure the device supports A2DP profile. The pairing procedure will vary depending on the actual device. Please refer to the user guide of your device for detail instruction. The general pairing procedures are as follows:

1. Make sure AISM01F is turned OFF
2. Active AISM01F pairing mode by press and hold the multi-function button for 2 seconds.
3. Activate your device's Bluetooth function and set your device to search for Bluetooth device. Select AISM01F when it is found.
4. For transmitter with Bluetooth version 2.1, you will not need to input a code. If you are prompted for PIN, please enter "0000".
5. If prompted by your device to connect, please select "Yes".
6. After connecting successfully, the blue LED with flash once every 5 seconds.

Note: Please make sure the audio output of your device is set to Bluetooth for audio streaming.

Operation

Charging The Battery

The battery is not fully charged and it is highly recommended that you charge AISM01F before you begin using it.

Note: Using AISM01F "out of the box" will not harm the device.

You will experience reduced battery life as the unit will not be fully charged. Connect the larger USB end of the cable provided to your PC or USB power adapter (not included) and the smaller Micro USB to the charging port of AISM01F. Please charge the battery for a minimum of (2) hours. When charging is complete, the blue LED will turn on.

Operation

Using AISM01F With Power Connected

Here are the steps to follow if you want to use AISM01F with power connected. AISM01F will stay in standby mode as long the power is connected so your Bluetooth device can reconnect automatically after you are within range.

1. Make sure AISM01F is turned OFF.
2. Connect the larger USB end of the cable provided to your PC / power adapter / TV's USB port and the smaller end to the charging port of AISM01F.
3. Follow the pairing instruction to pair your device.

Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

Warranty

Aluratek warrants this product against defect in material or workmanship for **1 YEAR** from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or "warranty void" sticker has been removed or altered on the product.

- This warranty does not cover:
- A) Cosmetic damage or damage due to acts of God
 - B) Accident, misuse, abuse, negligence or modification of any part of the product.
 - C) Damage due to improper operation or maintenance, connection to improper equipment, or attempted repair by anyone other than Aluratek.
 - D) Products sold AS IS or WITH FAULTS.

IN NO EVENT SHALL ALURATEK'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, IT'S ACCOMPANYING SOFTWARE, OR IT'S DOCUMENTATION.

Aluratek makes no warranty or representation, expressed, implied, or statutory, with respect to it's products, contents or use of this documentation and all accompanying software, and specifically disclaims it's quality, performance, merchantability, or fitness for any particular purpose. Aluratek reserves the right to revise or update it's product, software or documentation without obligation to notify any individual or entity.

Technical Support

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: support@aluratek.com

Web: www.aluratek.com/helpdesk

Local (Irvine, CA): **714-586-8730**

Toll free: **1-866-580-1978**