



AT66
HD Binoculars

User Manual

Register Warranty



Activate it Now »

Scan the QR code to extend your warranty to 3 Years!

you will get:

- Free replacement within **12 months**

- **3 years** warranty

- Up to **50%** off your next Usogood order

- **24-hour** customer service

Email: support@usogood.co Website: www.usogood.co



Register Warranty



Activate it Now »

Scan the QR code to extend your warranty to 3 Years!

you will get:

- Free replacement within **12 months**

- Up to **50%** off your next Usogood order

- **3 years** warranty

- **24-hour** customer service

Email: support@usogood.co

Website: www.usogood.co



CONTENTS

1. Package List	1
2. Glossary of Terms	2
3. Attentions	3
4. Directions for Use	3
4.1 How to focus the binoculars	3
4.2 How to use with smartphone adapter and tripod.....	6
4.3 How to attach the neck strap	9
5. Specifications	10
6. Care of the Optics	10
7. FAQ	11

1. Package List



- | | |
|--------------------------|-----------------------|
| 1) Neck Strap | 7) Smartphone Adapter |
| 2) Binoculars | 8) Tabletop Tripod |
| 3) Carrying Case | 9) Tripod Head |
| 4) Package | 10) Tripod Adapter |
| 5) Eyepiece Cover | 11) User Manual |
| 6) Objective Lens Covers | 12) Lens Cloth |

2. Glossary of Terms



- | | |
|----------------------------|---------------------------|
| 1) Eyepiece Cover | 6) Center Focus Ring |
| 2) Right Eyecup (Twist-up) | 7) Neck Strap Lug |
| 3) Left Eyecup (Twist-up) | 8) Tripod Adapter Socket |
| 4) Eyepieces | 9) Objective Lens |
| 5) Diopter Adjustment Ring | 10) Objective Lens Covers |

3. Attentions

- **Never use the binoculars to look directly at the sun, bright light, or laser.** Otherwise, it may seriously harm your eyes or cause blindness.
- Please **place the included plastic bag out of reach of children** to avoid suffocation.
- Amazon is responsible for shipping. If you receive a **damaged package or missing parts, please contact us to get a replacement.**
- The binoculars can resist water splashing, but can not be used in heavy rain or submerged in water for a long time.
- Please use binoculars in a well-lit environment for a clearer viewing experience.
- This binocular' s shell is made of upgraded ABS material, which is harmless to humans. Long-term sealed in the package may give off odors. Please leave the binoculars in a ventilated place for at least 2 weeks. If you still **feel the odor is unbearable, you can contact us for a replacement or return.**

4. Directions for Use

4.1 How to focus the binoculars

Step 1. Adjust the height of the eyecups as needed.



With glasses



Without glasses

Step 2. Look through the binoculars with both eyes and bend the binoculars slowly until you see a single circular view.



Step 3. Close your right eye (or close the right objective lens cover). Slowly adjust the center focus ring until you get a clear view with your left eye.



Step 4. Close your left eye (or close the left objective cover). Slowly adjust the diopter adjustment ring(under the right eyepiece) until your right eye gets a very clear picture.



Tips:


- It is normal to have difficulty in obtaining a round field of view when using binoculars for the first time. Please adjust slowly and try several times until getting a round field of view.
- It is recommended to take off your glasses when using binoculars in order to obtain the best viewing experience.
- If you need to view different targets afterward, please just adjust the center focus ring.
- Please scan the QR code to watch the video to learn how to focus directly.




Operation Video

4.2 How to use with smartphone adapter and tripod

Step 1. Assemble the smartphone adapter



Step 2. Assemble the tabletop tripod and attach it to the binoculars



360° Adjustable

Turn the latch to the right to adjust the angle, and to the left to secure it.



Step 3. Attach the smartphone adapter to the binoculars, and adjust the height of the tripod. (5.9 ~ 7.5 inches adjustable)



Tips:

- If your phone has more than one camera, please cover the lenses in order to find the main camera, which it won't capture pictures if blocked. Then aim the round hole of the phone holder at the phone's main camera.
- Method 1 to adjust the height of the tripod: You can turn the top wheel to change the groove first to adjust the height of the tripod.



Groove 1



Groove 2

- Method 2 to adjust the height of the tripod: You can press the button and slide to stretch the length of the tripod leg to adjust the height of the tripod.



- Please scan the QR code directly to learn how to use the binoculars together with your smartphone.



Installation Video

4.3 How to attach the neck strap



5. Specifications

Model	AT66
Prism System	Roof Prism
Magnification	12x
Eyepiece Diameter	18 mm
Object Diameter	42 mm
Eye Relief	15.5 mm
Product Weight	1.1 lb
Close Focus Distance	8.2 ft
Field Of View	374 ft/1000 yds
Prism Glass	BAK4
Lens Coating	Fully Multi-coated
Eyecups Type	Twist-up
Focus System	Center Focus & Diopter Adjustment Ring

6. Care of the Optics

- Please use the supplied lens cloth to wipe the binoculars lens. Do not use a coarse cloth (including tissue) to avoid scratching the surface of the lens.
- Please add some water to the cleaning cloth for more thorough cleaning of the binoculars - do not add it directly to the lens.
- Always protect binoculars from vibration shock. If the binoculars fall down and you can't get a proper view, please contact us immediately via email to get a solution.
- Please keep binoculars in a clean, well-ventilated place for long-term storage. Also isolate them from the bag, as they are susceptible to moisture.

7. FAQ

Q: Is my eyepiece cover broken?

A: In order to use the shoulder strap of binoculars easily, the eyepiece cover is designed with an open section on the left side. Please refer to the picture below for the specific usage method.



Q: Why do I get a double image?

A: If you get a double image, please first adjust the distance between the two barrels of your binoculars. It is normal to have difficulty in obtaining a round field of view when using binoculars for the first time. Please adjust slowly and try several times until getting a round field of view.



Q: Why do I have black edges, shadows or debris on my view?

A: If you get a view with black edges or debris inside the binoculars, please take a picture of the view and send it to us via official email (support@usogood.co). We have highly trained staff to help you solve the problem.

Q: Any other issues not mentioned above.

A: Please contact our after-sales support team for assistance. **Email:** support@usogood.co

Explore Your Exclusive Nature