

BLK BOX

WALL MOUNTED


MONKEY BAR ASSEMBLY





M10 HARDWARE

1.

Assemble x2 Squat bays of the rig ensuring that all bolts are facing inwards.



Stand both squat bays upright and align as shown.





*You must ensure the BLK BOX logo and feet are facing out to the side of the rig.


Do not fully tighten hardware until assembly is complete.

2.

Before fitting the back brace, ensure all bolts are inserted as shown.





Insert and secure spacers as shown




Add front brace/pull-up bar

3.

Insert remaining monkey bars



Once assembled, use a spirit level to align the rig before fully tightening all hardware and using the brackets provided to secure to the wall.



Repeat this process to expand the rig as needed.