

User Guide

Content

Introduction.....	1
Compatible Phone Models	2
In the Box	2
Specifications	3
Kind Reminders.....	4
Display Related Clarifications	6
Troubleshooting.....	9
Safety Information	13
Handling Information	14
Support & Warranty.....	16

Introduction

Lafos is a smartphone display designed to improve your smartphone viewing experiences. By simply plugging in your phone, Lafos will automatically wake up within seconds and display your phone content onto a much bigger screen.

Lafos works in both portrait mode and landscape mode. You could manually switch modes by rotating its screen. Its customised shaft allows easy tilt adjustment. Lafos also charges your phone when connected, and automatically turns off when you disconnect.

Compatible Phone Models

Lafos is compatible with all iPhone models from iPhone 5 to iPhone 14 Pro Max and all Android phone models with Android 5 and above installed. Please note that they are physically two different models of Lafos supporting iPhone and Android phone separately, one for each type.

In the Box

- Lafos
- Power adapter
- Connection cable

Specifications

- **Product:** Lafos Smartphone Display
- **Model:** DL2302
- **Resolution:** 1920 x 1080 pixels
- **Size:**
Portrait orientation (tilt 0°, rotation 0°): 21.6 cm x 43.93 cm x 13.2 cm
Landscape orientation (tilt 0°, rotation 90°): 36.66 cm x 36.4 cm x 13.2 cm
- **Weight:** 1.8 kg
- **Stand Adjustment:**
Tilt: -5.5° to +70°
Rotation: 0° to +90°

Kind Reminders

Volume control

Simply adjust the volume on your phone, the volume of Lafos will change accordingly.

Connecting Bluetooth audio

You can use Bluetooth headphones or speakers while your phone is connected to Lafos. If your Bluetooth device is connected but there is no sound, please manually switch the audio to it. For example, On iPhone you can open the Control Center on your phone, touch and hold the audio card in the upper right corner of Control Center to control audio, then tap and select the device you need from the list (such as Bluetooth headphones or speakers).

Components

The connection cable, power adapter, and other components of this product are designed specifically for use with Lafos and are not compatible with other similar products. Please do not mix them with other cables/adapters/power sources, and do not use them in any other scenarios, as this may cause unexpected device malfunctions or other damages.

Brightness adjustment

As for now, Lafos does not have a brightness adjustment function. Adjusting your phone's brightness will not change the brightness of the screen.

Display Related Clarifications

Why do I see black bars on both sides of the screen?

Lafos uses a 16:9 screen. However, different phone models come with screens of different aspect ratios, so it's hard to fit them all. If your phone display is also 16:9 or the content you are streaming is in 16:9 aspect ratio, Lafos will display in full size with no black bars. For phones of different display aspect ratios, Lafos will try to maximize the display area automatically, and there will be some black unused display area. For example, iPhone 14 uses 19.5:9 display, in full size it won't fill the entire 16:9 screen. If we stretch or crop the image, we may have it displayed at full-size, but the content will distort and look strange. To provide the best large-screen viewing experience, we keep the content as it is, so for some

phones, black bars may appear.

Why does the screen suddenly become smaller when I view my photo album?

Album output on iPhone is fixed on landscape mode, even for portrait photos. This means the phone will automatically output all photos into landscape mode by adding black bars to all portrait photos to make them wider. We recommend turning Lafos into landscape orientation when viewing photo album. And a kind reminder: you can always enlarge your photo to make use of the full screen.

Why is the content not displayed at full-screen sometimes when casting video?

There can be multiple reasons for this problem. First, please try clicking the full-screen option in the app. If the video itself is not full screen, it may not appear in

full screen on Lafos. Some apps automatically display vertical content with black borders on the left and right, turning a vertical video into a horizontal video. In that case, we recommend also turning Lafos into landscape mode for the best viewing experience.

Why can't I watch movies and TV shows?

Due to content protection some videos may not be able to be streamed to Lafos. As for the moment these apps include: Netflix, Amazon Prime Video, Max, Disney+ and some others.

Troubleshooting

No Image

- Make sure there is an image displaying on your phone.
- Make sure the connection cable is plugged into the connection cable port (You will hear a click when the plug is fully inserted).
- Make sure the power adapter is connected to the power adapter port (You will hear a click when the plug is fully inserted).
- Make sure the power adapter is connected to power.
- Press the sleep/wake button twice to turn the screen off and on again.

If there is still no image after completing the above steps, you may:

- Unplug the connection cable from your phone, and unplug the power

adapter. Wait for 10 seconds, then plug the power adapter back in. When you see the Lafos Logo, you can reconnect the connection cable to your phone.

- This should restart the system entirely.

No sound

- Make sure the video or audio on your phone is not muted, paused, or has no sound in the first place.
- Lift the base of Lafos, and check the speaker opening to see if it's blocked or dirty. Putting Lafos on soft surfaces such as a thick carpet or fluffy bed sheets may cause the speaker to be blocked.
- Unplug the connection cable and continue playing content on your phone. If you hear sound, wait for a few seconds, then plug the connection cable back into your phone (You will hear a click when the plug is fully inserted).

- If the above still doesn't work, restart your phone, and try playing the content again.

Screen is black or frozen

- Make sure your phone is not locked.
- Lafos will display the last frame of the image on your phone screen when your phone goes to sleep. Simply tap your phone screen to wake your phone, and Lafos will resume display.
- The display will turn off when you press the sleep/wake button. You can press the button again to resume display.
- Unplug the connection cable from your phone, wait for 10 seconds and reconnect.
- If the above still doesn't work, restart your phone.

Cannot rotate or tilt the screen

- Make sure the rotation direction is correct (clockwise for landscape mode to portrait mode, counterclockwise for portrait mode to landscape mode).
- Make sure there is no obstruction or blockage in the back that's jamming the revolving shaft of Lafos.

Safety Information

- Lafos is not waterproof. To prevent liquid damage, please keep the device or any of its components away from sources of liquids, and do not spray or splash the device or any of its components with any liquid.
- When switching between landscape and portrait modes or adjusting the screen tilt, please avoid exceeding the adjustment limit (there will be noticeable resistance when the limit is reached) as this may cause damage to the device that is not covered under the warranty.
- When moving the device, please firmly hold the stand with one hand and lift its base with the other hand. Incorrect gripping positions (for example, holding the screen alone) may cause damage to the device.

Handling Information

Connecting power

- When the device is connected to a power source, please do not place the device, power adapter, connection cable, or power adapter under a pillow, blanket, bedding, or under your body.
- Please avoid prolonged skin contact with the power adapter or connection cable to avoid injury or discomfort.

Cleaning

- Please use only a soft, dry, lint-free cloth to clean Lafos.
- Please do not use aerosol sprays, solvent, or abrasives to clean Lafos.
- Please avoid getting any moisture in openings or near any connector on the

device or components.

Operating conditions

- Please avoid operating Lafos outside the suggested temperature ranges.
- Please do not expose Lafos to extreme humid conditions.

Other handling information

- Please do not try to repair, modify, or disassemble Lafos yourself.
- None of the components of this device are edible.

Support & Warranty

Please visit **www.lafos.com** for the latest support and warranty information. You may also send an email to **support@lafos.com** for technical support.

The hardware product and accessories of Lafos are warranted against defects, malfunctions, and failures for one year from the date of delivery. This warranty does not apply to defects caused by normal wear and tear or due to normal aging of the product, or damage caused by accident, abuse, misuse, liquid contact, fire or other external cause. Proof of purchase details may be required for submitting a valid claim under this warranty. International shipping charges may apply depending on location.

@2023 Dexta Electronics Ltd. All rights reserved.