



SilvioMondinoStudio

Mickey
Installation Guide - Rev. 02/20


COMPONENTS




SAFETY INFORMATION

IMPORTANT: DO NOT LIFT OR MOVE THE LAMP HOLDING IT FROM THE STEM.
THE LAMP MUST BE PLACED ON A STABLE SURFACE TO AVOID ANY DAMAGE OR FALLS.
UNDER NO CIRCUMSTANCES CAN GRANDINE FIXTURE BE MOUNTED ON NORMALLY FLAMMABLE SURFACES.
SUITABLE FOR DRY, INDOOR USE ONLY.
MAXIMUM AMBIENT TEMPERATURE: 30°C

LAMP STRUCTURE ASSEMBLY



1 - JOIN THE TWO PART OF THE ROD. SCREWING THE PART A WITH PART B.





2 - CONNECT THE 24VCC WIRES. PAY ATTENTION TO THE POLARITY. **WRONG CONNECTION WILL DAMAGE IRREPARABLY THE LED MODULE.**

3 - GENTLY SLIDE THE LED MODULE JOINT INTO THE LAMP ROD.

NOTE

PLEASE CONTACT A LICENSED ELECTRICIAN.
USE NITRILE GLOVES TO HANDLE THE COMPONENTS TO AVOID FINGERPRINTS.
ALL BRUSHED BRASS SURFACES ARE SEALED TO SLOW DOWN THE PATINA DURING THE TIME.
POLISHED BRASS SURFACES ARE "LIVE" AND CAN BE RE-POLISHED USING A POLISHING CREAM.
UNEVEN SURFACES ON OXIDIZED FINISHING ARE A CHARACTERISTIC OF UNICITY, REVEALING THE CRAFTSMANSHIP PROCESS.

LAMP STRUCTURE ASSEMBLY



4 - CONNECT THE 24VCC WIRES. PAY ATTENTION TO THE POLARITY. **WRONG CONNECTION WILL DAMAGE IRREPARABLY THE LED MODULE.**


5 - SCREW THE STEM INTO THE BASE, PUSHING THE FIXTURE WIRES INSIDE THE BASE. DO NOT TURN 360° THE LED MODULE DURING THIS OPERATION.

6 - BLOCK THE LED MODULE TO THE LAMP ROD IN POSITION USING THE PROVIDED ALLEN-KEY AND SET SCREW.


NOTE

PLEASE CONTACT A LICENSED ELECTRICIAN.
 USE NITRILE GLOVES TO HANDLE THE COMPONENTS TO AVOID FINGERPRINTS.
 ALL BRUSHED BRASS SURFACES ARE SEALED TO SLOW DOWN THE PATINA DURING THE TIME.
 POLISHED BRASS SURFACES ARE "LIVE" AND CAN BE RE-POLISHED USING A POLISHING CREAM.
 UNEVEN SURFACES ON OXIDIZED FINISHING ARE A CHARACTERISTIC OF UNICITY, REVEALING THE CRAFTSMANSHIP PROCESS.

GLASS ASSEMBLY



7 - SLIDE THE GLASS INTO THE ROD. DO THE SAME FOR EACH GLASS.




8 - SLIDE THE RING INTO THE ROD.
DO THE SAME FOR EACH RING.

NOTE

PLEASE CONTACT A LICENSED ELECTRICIAN.
USE NITRILE GLOVES TO HANDLE THE COMPONENTS TO AVOID FINGERPRINTS.
ALL BRUSHED BRASS SURFACES ARE SEALED TO SLOW DOWN THE PATINA DURING THE TIME.
POLISHED BRASS SURFACES ARE "LIVE" AND CAN BE RE-POLISHED USING A POLISHING CREAM.
UNEVEN SURFACES ON OXIDIZED FINISHING ARE A CHARACTERISTIC OF UNICITY, REVEALING THE CRAFTSMANSHIP PROCESS.

GLASS ASSEMBLY



9 - BLOCK THE RING IN POSITION USING THE PROVIDED ALLEN-KEY.
DO THE SAME FOR EACH RING.

10 - TOUCH THE SOFT TOUCH HORSEHAIR CONTROL FOR A SHORT TIME, TO SWITCH THE LAMP ON /OFF

11 - HOLD FOR A SECOND THE SOFT TOUCH HORSEHAIR CONTROL, TO DIM THE LIGHT

NOTE

PLEASE CONTACT A LICENSED ELECTRICIAN.
USE NITRILE GLOVES TO HANDLE THE COMPONENTS TO AVOID FINGERPRINTS.
ALL BRUSHED BRASS SURFACES ARE SEALED TO SLOW DOWN THE PATINA DURING THE TIME.
POLISHED BRASS SURFACES ARE "LIVE" AND CAN BE RE-POLISHED USING A POLISHING CREAM.
UNEVEN SURFACES ON OXIDIZED FINISHING ARE A CHARACTERISTIC OF UNICITY, REVEALING THE CRAFTSMANSHIP PROCESS.