



Congratulations on your new Delux Medium X Vertical Ergonomic Mouse!

This ergonomic mouse is designed specifically for medium hands – we hope you enjoy it as much as we do!

CONTACT US

- **www.nomorepainergonomics.com.au
- ☑ info@nomorepainergonomics.com.au





Product Content:

1 x Delux Medium X Vertical Ergonomic Mouse

1 x USB Receiver (stored in the battery compartment at the base of the mouse)

System Requirements:

- Windows 7, 2000, XP SP2, 10 or higher
- Mac OS X (10.28+)



Laser (this will shine a red light when the mouse is switched on and active)

Installation (USB Receiver)

- 1. Insert 1x AA battery
- 2. Switch the on/off switch to 'on' at the base of the mouse
- 3. Wait for the computer to recognise your new mouse (usually up to 10 seconds)
- 4. Enjoy all the comfort the Delux Medium X Vertical Ergonomic Mouse has to offer!

Troubleshooting

At times you might lose connection with the mouse to the computer. If this occurs please try the below troubleshooting steps:

Click and ensure the mouse is in an 'active' state (the mouse will go into 'sleep' mode after a period of inactivity, clicking the left button and moving the mouse will reactivate the mouse)

- Ensure the on/off switch at the base of the mouse is switched 'on'
- Replace the AA battery with a new battery
- Try a different USB port
- Try a different computer
- Restart your computer, then replug into the USB port
- Try a different mouse surface
- Ensure the USB receiver is close by to the mouse to stop any interference
- Ensure the sensor and surrounding area is clean from dirt or food that could be blocking the sensor connection

Usually these above tips assist in regaining the connection for the mouse.

If the above does not fix the issue, please contact us on the below: info@nomorepainergonomics.com.au

FOR INFORMATION ABOUT:

Warranty Policy Good Ergonomics Other Products

