

X2

Tranya Sports Earbuds

User Manual

V20220803




15-MONTH WARRANTY
ACTIVATE WITHIN 14 DAYS


tranya.com/pages/register-product

Email: support@tranya.com

PACKAGE LIST



Wireless Earbuds*1




Carry bag*1



User Manual*1



Wire Clip*1




Ear Tips*3



Type-C Charging Cable*1

IMPORTANT NOTES

- 1 Register your product on tranya.com to get an EXTRA three-month warranty for free.
- 2 Before using the X2 wireless earbuds, please fully charge the earbuds first.
- 3 If both earbuds don't sync together, please reset the earbuds.
- 4 To avoid damaging the earbuds, please use the original charging cable provided by manufacturer for charging, and choose USB port of computer or regular brand mobile phone charger which is in accord with 5V voltage, 100mAh-1A or less than 100mAh-1A current to charge.
- 5 If the sound becomes low without control, please use tweezers to take out/remove the net inside the earbuds.



PHYSICAL BUTTON CONTROL

Note: There is only one MFB (Multi-function button) which is on the right earbud.

Play/Pause		Press 1 time (MFB)
Next/Previous track		Press and hold for 1 second (+/-)
Volume up/down		Press 1 time (+/-)
Activate Siri/Other voice control software		Press and hold for 1 second (MFB)
Answer/End a call		Press 1 time (MFB)
Reject a call		Press and hold for 1 second (MFB)
Game Mode on/off (Automatically Game mode off when power off)		Press 2 times (MFB)

POWER ON/OFF



Power on: Long press and hold the MFB for 4 seconds



Power off: Long press and hold the MFB for 4 seconds

Note: When the earbuds are at low battery, there is the automatic voice prompt "battery low" and the indicator light will flash every 5 seconds.

WEARING


- 1 Put the earbuds into your ears.
- 2 Rotate the earbuds to auricle side to fit snugly.

CONNECT THE EARBUDS



- 1 Power on the earbuds and turn on the Bluetooth in your phone.
- 2 Select "X2" and confirm.

CHARGING



Charging: Red indicator light is on
Fully Charged: Blue indicator light will be on


HOW TO RESET THE EARBUDS

- 1 Turn off the earbuds;



Long press and hold for 4 seconds

- 2 Long press and hold the MFB for 8 seconds until the blue/red light blinks 3 times;



- 3 Reset successfully (Note: the pairing record will be automatically removed after reset).

FAQ


Q: Why does signal interruption occur in some places, such as along the railway and the airport?

A: There are usually lots of underground cable lines along the places mentioned above, which might cause electromagnetic interference and result in the signal interruption.

Q: My earbuds don't charge, what can I do?

A: Please try to follow below steps:

1. Clean the charging port of the earbuds by alcohol swab
2. Change a Type-C cable to see whether it works




FAQ

Q: Why can't my earbuds connect to my phone?

A: Our earbuds will automatically connect to the last-paired device for convenient using. Please make sure you have turned off the Bluetooth function of your last-paired device before changing a device to connect. If it still doesn't work, please contact our support team for help.

Q: Will the Bluetooth mouse cause the signal interference?

A: Perhaps. When your Bluetooth mouse and earbuds are connected to the same device, it might happen.



For more information, please visit:

tranya.com

For any assistance, email us:

support@tranya.com

Manufacture:
Name: Shenzhen Ocen Technology Co.,Ltd.
Address: Building 1, Jinshengtao Industrial Park, No.242
Hongmian 3rd Road, Henggang Street, Longgang District,
Shenzhen, China.

EU REP Skylimit Service GmbH
Roedingsmarkt 20
20459 Hamburg

UK AR

HUA TENG LIMITED
3 Glass Street, Hanley,
Stoke On Trent, ST1 2ET
United Kingdom

FC CE RoHS Made in China