

X3

Tranya Sports Open Earbuds


User Manual

V2020916



15-MONTH WARRANTY
 ACTIVATE WITHIN 14 DAYS
tranya.com/pages/register-product
 Email: support@tranya.com


PACKAGE LIST



Wireless Earbud * 2
 Magnetic Charging Case * 1




User Manual * 1



Type-C Charging Cable * 1

IMPORTANT NOTES

- 1 Register your product on tranya.com to get an EXTRA three-month warranty for free.
- 2 Before using the X3 wireless earbuds, please charge both the case and earbuds.
- 3 If both earbuds don't sync together, please reset the earbuds.
- 4 If the earbuds don't charge, please clean the charging slot on the case and the contact surface on the earbuds.




- 5 If the sound becomes low without control, please clean the inside mesh of the earbuds by needle or cleaner kit for earbuds.


SMART TOUCH CONTROL

Play/Pause		Tap one time(L/R)
Previous/Next track		Tap 3 times(L/R)
Volume down/up		Tap twice(L/R)
Activate Siri/other voice control software		Press and hold for 1 second (L/R)
Answer a call		Tap one time(L/R)
Reject/End a call		Press and hold for 1 second(L/R)
Game Mode <small>(Automatically return to normal mode after power off)</small>		Tap 4 times(L/R)

POWER ON



POWER OFF



Note: When the charging case is at low battery or out of power, the earbuds will not automatically power on/off, please turn them on/off manually.

WEARING


- 1 Put the earbuds into your ears.
- 2 Rotate the earbuds till the end of the ear hook is inserted behind the ear.

CONNECT THE EARBUDS

- 1 Power on the earbuds and turn on the Bluetooth in your phone.
- 2 Select "X3" and confirm.


CHARGING

1 Case Power Display



2 Charging the Earbuds


Charging: White indicator is on;
Fully charged: White indicator is off.



3 Charging the Case

Charge it with the included Type-C cable.

Charging: Red indicator light is on;
Fully charged: Green indicator light will be on.




HOW TO RESET THE EARBUDS

If your earbuds stop syncing with each other, please follow below steps to reset the earbuds:

- 1 Turn off the earbuds and put them back to the charging case, then you will see both indicators light.



- 2 Press and hold the button on the case up to 8-10s until the white lights on the earbuds and case flash 3 times at the same time.



- 3 The earbuds will sync together and enter the pairing mode automatically.


FAQ

Q: Why does signal interruption occur in some places, such as along the railway and the airport?

A: There are usually lots of underground cable lines along the places mentioned above, which might cause electromagnetic interference and result in the signal interruption.

Q: My earbuds don't charge, what can I do?

A: Please try to follow below steps:
 1. Clean the charging slot on charging case.
 2. Clean the charging connector on earbuds.



Q: Why won't my earbuds power on/off automatically?

A: The earbuds would not power off automatically when the case is at low battery or out of power. Please recharge the case. And you can long press for four seconds to power on and long press for four seconds to power off the earbuds.

Q: Will the Bluetooth mouse cause the signal interference?

A: Perhaps. When your Bluetooth mouse and earbuds are connected to the same device, it might happen.