



**2020 + L5P DURAMAX
CAN COMMUNICATION HARNESS
INSTALL INSTRUCTIONS**



**THANK YOU FOR PURCHASING THE MOTOR OPS CAN COMMUNICATION HARNESS.
PLEASE BE SURE TO INSTALL THIS **AFTER** YOU HAVE YOUR TUNING INSTALLED INTO
THE VEHICLE.**

**INSTALLING THESE HARNESSES BEFORE TUNING COULD RESULT IN A
COMMUNICATION ERROR WITH THE ECM OR YOUR ON BOARD DIAGNOSTICS.**



CAN COMMUNICATION HARNESS CONTENTS:


- 2 - NOx Sensor Plugs (your kit may have 3 in the package, only two will be used)
- 1 – DEF Harness Plug

LOCATION OF INSTALLATION:

1. Install the DEF Harness Plug. This is located on the driver-side of the vehicle on the frame rail just behind the driver's door.



2. Install the NOx Sensor Plug in the engine bay. This plug will be located on the driver-side of the engine bay.



3. Install the NOx Sensor Plug on the passenger-side of the frame rail. This plug will be located on the frame rail behind the passenger door.



4. Leave the NOx Sensor behind just in front of the rear axel plugged into the main harness.



In some jurisdictions, depending on the manner that you are operating our product(s) it may be an offense to use the products for sale on this site. We do not condone the use of our products for any illegal purpose whatsoever. By purchasing any of our product(s) you acknowledge and approve the following:

1. You represent that the product(s) will be used exclusively in a lawful manner. If you're in doubt as to the legality of your planned usage you should consult with a lawyer and obtain independent legal advice.
2. You acknowledge that you are solely responsible for complying with all relevant laws in your area and the area(s) where our product(s) are being used.
3. You acknowledge that neither Motor Ops, nor any of its agents, affiliates, directors, employees, and associates may be held responsible or accountable for any type of damage, litigation or other legal action, which may arise either from your legal or illegal use of our product(s).

