




## Rockford Chimney Supply: Traditional Open Fireplace Chimney Liner Measurements Guide

If you're installing a chimney liner for a traditional open fireplace, this guide will help you tremendously! We've narrowed in on all of the measurements you'll need to gather. With these measurements, you can put together a parts list on our website or send the measurements off to us and one of our Certified Technicians will send you a parts list! Just follow the guide below and let us know if you have any questions along the way - we're here to help.

One more thing to keep in mind before you move on to the guide - this particular guide is for a traditional open fireplace chimney liner installation. Like the picture to the left. If you are looking for a different installation setup, please visit our [Measuring Guide page](#) and choose the correct setup.

Once this form is completed, please email it to [emogan@rockfordchimneysupply.com](mailto:emogan@rockfordchimneysupply.com) or call us at 866-708-2446



1. What is the **Height and Width** of the face opening of the fireplace? (If your fireplace has glass doors, measure the opening of the door when they are in the open position)
2. What are the exact **INSIDE** measurements of the existing flue?
3. What is the height of the chimney from the top of the Smoke Shelf to the top of the chimney? If you have an existing clay chimney flue, you can measure from the first clay flue (just above the Smoke Shelf) to the top of the clay flue at the top of the chimney. If you do not have a clay flue, the top of the Smoke Shelf is where the chimney starts to get smaller and more narrow.
4. **Extra Notes**  
Every installation is different and nothing is standard in the chimney world! Please provide any additional information about your setup here if needed.

**Note:** When ordering, please be sure to allow an extra 1-1/2" for overlap wherever liner sections will be joined together.

\*IRC, NFP 211, building codes, and local jurisdiction codes are ever changing. It is the installer's responsibility to be sure they are installing their components properly. Any questions about our products can be phoned in to one of our Certified Technicians.\*

Mesh Bottom Plate Before



Mesh Bottom Plate After



Use the mesh bottom plate to parge/cement the liner in above the smoke chamber and damper with Chamber Safe parging material or refractory cement.

