


PRO Skills Trainer

ASSEMBLY INSTRUCTIONS

Copyright © 2022 Football Flick | All Rights Reserved



IMPORTANT: REVIEW CAREFULLY AND KEEP FOR FUTURE REFERENCE

Developed in the UK by iControl Sport Limited / Football Flick.
Assembled in India.

SAFETY AND CARE:

When not in use, always store the unit in a dry place.
Prolonged exposure to sunshine, rain, snow etc. will cause deterioration of the unit.

The Football Flick PRO Skills Trainer has been designed to be used with standard weight footballs of any size. It has not been designed to be used with heavier adaptations or any other objects. Do not sit, stand or apply pressure to the unit with any other object other than a standard weight football. Assembly should be carried out by an adult. After assembly, regularly check all fastenings are secure.

The Football Flick PRO Skills Trainer should be used responsibly and under the supervision of adults where children may be using the unit.



SCAN ME



















POINTS TO REMEMBER FOR ASSEMBLY AND USE.






- Adult supervision is required at all times when the PRO Skills Trainer is used by children.
- To reduce risk of entanglement, keep small children away from the PRO Skills Trainer at all times.
- Never let children climb on the PRO Skills Trainer as this could result in the PRO Skills Trainer falling over causing serious injury or product failure
- Inspect the PRO Skills Trainer before each use. Make sure all parts are correctly and securely positioned and attached. Tighten any loose hardware. Replace any worn, defective, or missing parts.
- Only use after full assembly is completed.
- Adequate overhead clearance is essential. Provide clearance for wires, tree limbs, and other possible hazards.
- Lateral clearance is essential. Place the PRO Skills Trainer away from walls, structures, fences, and other play areas. Maintain a clear space on all sides of the PRO Skills Trainer. A minimum of 3m from frame edge is recommended.
- Place the PRO Skills Trainer on a level surface before use.
- Secure the PRO Skills Trainer against unauthorized and unsupervised use.
- Use provided weight bags to secure the positioning of the PRO Skills Trainer.

PARTS.


PRO Skills Trainer

A		x1
B		x1
C		x1
D		x1
E		x2
F1		x1
F2		x1
G		x2


H		x1
I		x2
J		x80
K		x2
L		x1
M		x1
N		x1
O		x1

P		x6
Q		x4
R		x4
S		x2
T		x2



4




5




6





7




8




9






10




11





12





x2





14







15



16



17





footballflick.com