




---

SPORTS & OUTDOORS



## **PREMIUM AIR BED**

---

**INSTRUCTION MANUAL**

**IMPORTANT INSTRUCTIONS  
- RETAIN FOR FUTURE USE.**

# CONTENTS

<b>EN</b> Safety Guidelines.....	Page 3
Specifications .....	Page 6
Operating Instructions .....	Page 7
Frequently Asked Questions.....	Page 8
Storage .....	Page 9
Cleaning and Maintenance .....	Page 9
Important Note.....	Page 9
Recycling and Disposal .....	Page 10
Symbols Explained .....	Page 11



PREMIUM AIR BED  
MODEL AE-ABD01

Thank you for choosing to purchase a product from Active Era. Please read the entire manual carefully prior to first use and keep in a safe place for future reference.

## SAFETY GUIDELINES

---

### PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS


When using electrical appliances, basic safety precautions should always be followed to reduce risk of fire, electric shock, and injury to persons, including the following:

**⚠ WARNING: To avoid the risk of electrical shock, fire or injury to people, always make sure the appliance is unplugged from the electrical outlet before relocating, servicing, or cleaning it.**

**⚠ WARNING: Not a flotation device.**

- Use this product only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Children must be supervised not to play with the appliance.
- Do not let children use the air pump.
- The air pump is for indoor household use and similar applications only.
- Do not immerse the electric air pump in water.
- Keep away from fire.
- Do not operate or expose the air pump to wet environments such as rain or water.
- Do not leave the air pump unattended whilst in use.
- Ensure the air pump suction and exhaust openings remain free of dust and debris.

- Never insert fingers or metal objects into the air pump suction and exhaust openings.
- Do not obstruct the air passage opening or insert any objects into the air passage opening.
- Do not use the power cord or operate the air pump with wet hands to prevent electric shock.
- Store the air bed and air pump indoors in a safe, clean and dry place, away from sunlight when not in use.
- Do not operate the air pump if there are signs of damage.
- Do not get flocked surface wet. If this becomes wet, remove any bedsheets or cloths and allow to air dry.
- Never move, carry or hang the air bed by the mains power cable.
- Ensure that the mains supply (including voltage, frequency and power) complies with the rating label of the appliance.
- Do not use the air pump for more than 5 consecutive minutes at a time. Allow the air pump to cool down for 20 minutes before each repeated use. The air pump is designed to fully inflate your air bed within 2-3 minutes. The pump will automatically turn OFF if overheating occurs. This is designed for your safety.
- Do not place an infant to sleep on the mattress.
- This product is not a toy. Children must not be left unattended when using the air bed.
- Do not use flammable liquids or sprays with the air bed, such as aerosol tire repair products, as it may ignite or explode.
- Use the air bed only as a mattress. Do not walk, stand or jump on the air bed.
- This air bed is not a buoyancy aid, lifebuoy or life saving device. Do not use it on or near water.
- Do not set up bed near stairs, doors, sharp edges or breakable objects. Provide adequate space between bed and objects to avoid entrapment. Make sure the area is flat, smooth, even and free of sharp 3 objects that could puncture the bed.
- Keep pets away from the air bed. Pets may puncture the surface of the bed.

- Avoid sleeping on the edge of the air bed. Edges produce less support than the middle of the bed.
- Infants have suffocated on inflatable mattresses. Never place infant aged birth to 15 months to sleep on this inflatable air mattress/ air bed. Infants can suffocate on an under-inflated or deflated mattress, on bedding, by co-sleeping with another person, and by entrapment between the mattress and bed frame or between the mattress and a vertical surface.
- Children can be entrapped between the inflatable mattress and an adjacent vertical surface. Provide at least a shoulder width space between the inflatable mattress/air bed and adjacent vertical surfaces such as walls, dressers, or other objects.
- Always keep the inflatable mattress fully inflated when in use.
- Do not attempt to repair or adjust any electrical or mechanical elements in the appliance. Doing so may be unsafe and will void your warranty.
-  **⚠ WARNING: RISK OF SUFFOCATION.** Infants have suffocated on inflatable air beds. Never place an infant 15 months or younger to sleep on this inflatable air bed. Infants can suffocate on an under-inflated or deflated air bed, on bedding, by co-sleeping with another person, and by entrapment between the air bed and a vertical surface. Children can be entrapped between the inflatable air bed and an adjacent vertical surface. Provide at least a shoulder width space between the inflatable air bed and the adjacent vertical surfaces such as walls, dressers, or other objects. Always keep the inflatable air bed fully inflated when in use.
- Keep the appliance out of reach of children and pets.
- Do not leave children alone or unattended in the area where the appliance is in use.
- Cleaning and user maintenance shall not be made by children unless continuously supervised.
- The appliance must have a minimum 50cm clearance around all sides.
- Always turn the appliance off and disconnected from the power

supply when not in use.

- Avoid placing the appliance in areas where it can become a tripping hazard.
- Avoid placing the power cord in areas where it can become a tripping hazard. Do not place the power cord under carpeting or cover it with rugs, runners or similar.
- There may be trace of odour during the first few minutes of initial use. This is normal and will quickly disappear.
- Do not use the appliance near petrol, paints, flammable gases, ovens, or other heating sources.
- Always plug the appliance directly into a wall socket. Avoid using extension leads where possible as they may overheat and cause a risk of fire.
- Do not operate the appliance if there are signs of damage to the appliance, power cord, or any of the accessories supplied. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.

## SPECIFICATIONS

Dimensions: 137 x 195 x 46cm

Weight: 6.8kg

Power: 120W

Voltage: AC 220-240V

Frequency: 50Hz

## OPERATING INSTRUCTIONS

### Inflation

1. Choose a flat, indoor surface large enough to accommodate the inflated airbed
2. Remove any sharp or pointy objects on or near the surface
3. Lay the airbed out with the bottom surface touching the floor
4. Open the cover at the top of the bed where the power cord is stored
5. Make sure the manual inflation valve is closed
6. Plug the power cord into an electrical outlet
7. Turn the control dial clockwise until the arrow points to INFLATE (image 1)
8. The single airbed will take up to 1.5 minutes to inflate. The queen size airbed will take up to 3 minutes to inflate
9. When the airbed is fully inflated, turn the control dial one click anti-clockwise until the arrow points to OFF (image 2)
10. Lie down on the airbed to test the firmness. If too soft, repeat steps 7 – 9 as necessary
11. Unplug the cord and store in the power cord compartment



Image 1



Image 2

### Inflation Option

If electrical power is not available, then a conventional foot or manual operated air pump can be connected to the airbed

### Deflation

1. Open the cover at the top of the bed where the power cord is stored
2. Make sure the manual inflation valve is closed
3. Plug the power cord into an electrical outlet
4. Turn the control dial anti-clockwise until the arrow points to DEFLATE (image 3)
5. The airbed will take up to 3 minutes to deflate
6. When the airbed is fully deflated, turn the control dial one click clockwise until the arrow points to OFF
7. Unplug the cord and store in the power cord compartment



Image 3

## FREQUENTLY ASKED QUESTIONS

---

### Why is my air bed deflating?

There are a few reasons your air bed may be losing air:

- **First Uses:** During its first few uses, your Active Era Air Bed may sag and require additional inflation to maintain its desired firmness. This is because stretching is a natural characteristic of new vinyl and is normal for the first few days of use. Inflate your air bed at least 30 minutes prior to first use and top up as required to allow the air bed to stretch to its natural shape.
- **Normal Use:** All air beds are designed to lose a small amount of air through their seams during use to reduce the risk of tears and bursting when pressure is added. This also helps to prevent over-inflation.
- **Increased Pressure:** Your air bed may be deflating because the weight limit has been exceeded. Most of our air beds have a weight limit of 250 kgs or 550 lb. Please check the product page or the specifications in your instruction manual for product specific weight limits.
- **Varying Temperatures:** Air inside the air mattress can expand or contract when exposed to hot or cold temperatures. At cold temperatures, air naturally contracts inside the air bed and can lead to sagging. If deflation occurs, pump some more air into the mattress. At hot temperatures, air can expand inside the air bed and it will become hard and in extreme circumstances, burst. Release air to avoid damage to your air bed. Where possible, aim to keep surrounding temperatures consistent during use.
- **Puncture:** Your air bed may be deflating because it has a puncture.

### How do I find a puncture?

To find a puncture, please follow these steps:

1. Fill a spray bottle with soapy water e.g. washing up liquid.
2. Inflate your air bed fully and unplug the power cord from the mains power supply.
3. Spray the surface of the inflated air mattress, avoiding the air pump and electrical components.
4. Visually inspect the air bed. If there is a puncture, bubbles will start to form over the puncture as air starts to leak out.
5. Wipe your air bed dry with a soft dry cloth.
6. Repair your puncture with the provided puncture kit.

## STORAGE

---

1. Deflate the airbed following the 'deflation' instructions.
2. Make sure the airbed is clean and dry.
3. Lay bed flat with sleeping surface facing upwards. Fold the airbed loosely and avoid sharp bends, corners and creases which can damage the airbed.
4. Store the appliance in a safe, clean and dry place, out of reach of children when not in use.

## CLEANING AND MAINTENANCE

---

- ⚠ **WARNING:** Always turn the appliance OFF and unplug the power cord from the electrical outlet before handling or cleaning it.
- ⚠ **CAUTION:** Do not allow water or other liquids to run into the interior of the air pump, as this could create a fire and/or electrical hazard.
- ⚠ **CAUTION:** Do not use any abrasive cleaners or solvents, as this will damage the air bed.
- Do not attempt to clean the appliance in any other way than that detailed by the manufacturer.
- Clean the exterior surface of the appliance by wiping it with a soft, damp cloth. Dry the appliance with a soft, clean cloth.
- Clean the vents and openings of the appliance regularly with a vacuum cleaner, using the brush attachment to avoid any dust build-up.
- To store your product, we recommend using the original or a similar-sized box.
- Store the appliance in a safe, clean and dry place, away from direct sunlight and out of reach of children when not in use.
- To extend the lifespan of the filter, a vacuum cleaner, using the brush attachment can be used to remove dust from the surface of the filter.
- Use soapy water to clean the surface of the airbed. Do not use any chemicals.
- No air pump maintenance is required.
- To repair punctures to the airbed, use only common PVC repair glue and patches. Do not use flammable aerosols on the surface of the airbed.

## IMPORTANT NOTE

---

The ambient temperatures of air have an effect on the airbed internal pressure. At low ambient temperature the air will contract within the airbed and the airbed will feel softer: add air as necessary. At high ambient temperature the air within the airbed will expand significantly and the airbed will become hard and may burst: release air to avoid damage to the airbed or to soften the feel. Do not expose the airbed to extreme temperatures.

Air inside of bed may expand and contract with varying temperatures leading to reduced pressure inside of bed. If this occurs, simply add more air issuing the pump to achieve desired firmness.

Stretching is a natural characteristic of new vinyl. During initial use, the airbed may become soft and require additional inflation to maintain desired firmness. This is normal for the first few days of use.

Under no circumstances will Active Era be liable for damages to the airbed caused by negligence, ordinary wear and tear, abuse and carelessness or external forces.

## RECYCLING AND DISPOSAL

Waste electrical and electronic products (WEEE), batteries, accumulators and packaging should not be disposed of with general household waste. This is to prevent possible harm to the environment and human well-being, and to help conserve our natural resources. Most electrical products with a plug, battery, or cable can be recycled. Contact your local council, household waste disposal service, or the store where you purchased the product for information regarding the collection schemes in your area.



### Waste Electrical and Electronic Equipment (WEEE)

This symbol on the product and/or packaging indicates that Waste Electrical products (WEEE) under Directive 2012/19/EU which governs used electrical and electronic appliances, should not be disposed of with general household waste.



### The Mobius Loop





This symbol indicates that the product or packaging is capable of being recycled.

### Take-Back Scheme

Waste electrical products (WEEE) can be sent to One Retail Group for recycling and disposal when you purchase a new product from One Retail Group, on a like-for-like basis. For more information on how to recycle this product please visit [www.activeera.com](http://www.activeera.com).

The end-user of electrical and electronic products (WEEE) is responsible for separating old batteries and lamp bulbs before they are handed over to a designated disposal and recycling service. Waste batteries can also be disposed of in collection bins, which can be found in most local supermarkets and household waste recycling centres.

## SYMBOLS EXPLAINED

	For indoor use only.		Please read instruction manual and retain for future use.
	Equipment complies with the applicable UK safety requirements and regulations.		Equipment complies with the applicable EU safety requirements and regulations.



One Retail Group, Ryland House,  
24a Ryland Road, London, NW5 3EH, UK

EU Authorised Representative: Brandrep Limited,  
The Black Church, St Mary's PI N, Dublin, D07 P4AX, Ireland

© Copyright 2023