In many states it is unlawful to tamper with your vehicle's emissions equipment. Haltech Off-Road Usage Policy

(ASU and in state by state by state details in the USU). specific regulatory exemption exists (more information can be found on the SEMA Action Network Using Haltech products for street/road use on public roads or highways is prohibited by law unless a non-emissions controlled vehicles only and may never be used on a public road or highway. Haltech products are designed and sold for sanctioned off-road/competition, non-registered or

before purchasing, using or installing any Haltech product. applicable local and federal laws and regulations. Please check with your local vehicle authority It is the responsibility of the installer and/or user of this product to ensure compliance with all

incorrect installation of Haltech products are totally the responsibility of the installer. that particular application. Any damage to parts or consequential damage or costs resulting from the is clearly on the installer to ensure that both their knowledge and the parts selected are correct for No responsibility whatsoever is accepted by Haltech for the fitment of Haltech Products. The onus Installation of Haltech Products

Haltech Limited Warranty

liable for special or consequential damages. implied, including any implied warranty of merchantability or fitness. In no event shall Haltech, be foregoing is exclusive and in lieu of all other warranties or representations, either expressed or of purchase. This shall constitute the sole liability of Haltech. To the extent permitted by law, the be defective as mentioned above, it will be replaced or repaired if returned prepaid along with proof the warranty period, must be presented to obtain warranty service. If the Haltech product is found to coby of the original purchase invoice, receipt or bill of sale which indicates that the product is within workmanship for a period of 12 months from the date of purchase. Proof of purchase in the form of a Unless specified otherwise, Haltech warrants its products to be free from defects in material or

Product Returns

nıl retund. accept these terms please return the sensor in its original unopened packaging within 30 days for a been opened or tampered with. This will be clearly noted on the product packaging. If you do not accessory that is supplied in sealed packaging is strictly non-refundable if the sealed packaging has Haltech will not be held responsible for product returns lost during transit. The sale of any sensor or must be sent via a freight method with adequate tracking, insurance and proof of delivery services. packaging will incur extra charges to return the item to a re-saleable condition. All product returns undamaged product and its original packaging. Any product returned with missing accessory items or Please include a copy of the original purchase invoice, receipt or bill of sale along with the unused,

for credit or full refund. (Any sealed packaging must not have been opened or tampered with) Returning a sensor or accessory product within 30 days of purchase: Product may be returned

tor creationly (no returds given) and is subject to a 10% Restocking ree. (Any seared packaging Returning a sensor or accessory product after 30 days of purchase: Product may be returned

unar nor nave been opened or tampered with)



2.) To calibrate the pedal, click on the calibrate button with the pedal not depressed. Then click calibrate again with the pedal fully depressed. 3.)To calibrate the throttle, click on the calibrate button for

the throttle to initiate the automatic calibration procedure.

1.) After wiring the electronic throttle body and pedal assembly, connect the ECU to the tuning software (NSP) and go to the calibration section under Drive By Wire.

Haltech ECU Calibration Information

Pinout and Wiring Information

Please take care when wiring this electronic throttle body as incorrect wiring will damage it. Refer to your ECU's wiring diagram for specific wiring information.


3 +5V in +5V 4 Motor + DBW Motor Output or HBO 5 TPS 2 Analogue Voltage Input 6 TPS 1 Analogue Voltage Input


ECU connection Pin Function DBW Motor Output or HBO 1 Motor -2 Signal Ground Signal Ground

Used to electronically control the throttle and provide throttle position to the ECU. This device is used together with an Accelerator Pedal Position (APP) sensor and an ECU that supports Drive By Wire throttle control.

1 2 3 Looking into connector on electronic throttle body

4 5 6





in its original unopened packaging for a full refund.

If you do not accept these terms please return this device

and is sold "as is" and without any further warranty.

been individually electronically tested before packaging

has been opened or tampered with. This device has

This device is strictly non-retundable if this packaging

(suid & guld oni)

Throttle Body

Bosch 60mm Electronic

008110-TH

7.5mm