

INSTRUCTION MANUAL

IMPORTANT: READ ALL INSTRUCTIONS BEFORE REMOVING/INSTALLING THE DOORBELL BUTTON.

FOLLOW ALL NATIONAL AND LOCAL ELECTRICAL CODES.

CONTACT A QUALIFIED ELECTRICIAN IF THERE ARE ANY QUESTIONS AS TO THE SUITABILITY OF THE SYSTEM.

Recess mount for stucco or brick

***If this is a new install, go the section “INSTALLING THE NEW DOORBELL BUTTON” on page 2.**

REMOVING AN EXISTING DOORBELL BUTTON

Step 1: WARNING: Turn the power off at the fuse or circuit breaker before removing the doorbell button.

Step 2: Remove the screws from the existing doorbell. If the doorbell is caulked, use a utility knife to cut through the caulk before removing the button. If the button is an exact replacement of one the models in this manual, then place a flat head screwdriver underneath the button housing and gently pry it loose and remove the button.

Step 3: Loosen the two screws holding the doorbell wires to the button on the back and disconnect the wires. It doesn't matter which wire goes to which screw terminal.


INSTALLING THE NEW DOORBELL BUTTON

Step 1: WARNING: Turn the power off at the fuse or circuit breaker before installing the doorbell button.


Step 2: If necessary, drill a 7/8" diameter hole approximately 1.5 inches deep where the button will be installed.

Step 3: If necessary, use needle-nose pliers to bend a J-loop in the ends of the bare wires. Slip one wire loop around a loosened screw on the back of the new doorbell button and tighten the screw to hold the wire in place. Do the same for the second wire and check that both are solidly attached (see image below).

It doesn't matter which wire goes to which screw terminal.



Step 4: Squeeze the retaining bracket together and insert button (see image below).



Contact us at cs@adamaxinc.com or via our website at newhousehardware.com with any questions.