

APP OPERATIONS GUIDE

Multifunctional Alarm Clock

A 29



Scan for Product info and How-To Videos

✉ : FansbeTech_services@outlook.com

🌐 : www.fansbetech.com

☎ : (1)887-355-7380

Download the App

Download “**Fansbe**” from the App Store / the Google Play.





Connect Device to the APP

Note:


- 1) Turn on Bluetooth on your smartphone before connecting device to the APP.
- 2) Please make sure the device is powered on

1) Open the “**Fansbe**” app and tap “**+Add.**”


2) Select your purchased device.



3) After successful addition, go to “My Device”.



4) Tap the added device to enter the Bluetooth connection screen (you can rename the device). Tap “Start” to connect Bluetooth.



5) Enter the device’s main page.



App Usage

Home Screen Overview



1.Back Button

2.Device Name: Rename your device in the "My Device" screen.

3.User Guide: Access "My Device", adjust font, update app version, view the manual, learn about Fansbe and new products.

4.Adjust Screen Brightness

5.Night light brightness

(cannot adjust two built-in multicolor lights)

6.Set Clock Time


7.Alarm Function

8.Lighting Function

9.White Noise Function

10.Bluetooth Status Icon

11.Child Lock: Prevents children from accidentally changing settings.



Back Button: Returns to “My Device” screen where you can swipe left to delete devices, long press to rename devices, add new devices, and switch between added devices.

Set Clock Time

Tap the time edit button to enter the time setting screen


Exit Button: Exits without saving the time settings.

Sync with Phone Time: Automatically syncs device time with phone time when enabled.


Time Edit Area: Manually set the time here when “Sync with Phone Time” is disabled.

24H Time Switch: When on, the device displays time in 24-hour format.


Save Button: Saves the time settings and exits the screen.



Alarm Function

Tap  to access the alarm settings

- 1) Back button
- 2) Alarm list
- 3) Alarm date
- 4) Breathing light status
- 5) Edit alarm
- 6) Toggle alarm on/off
- 7) Add new alarm button



Set Alarms

1) Add Alarms

a. Tap the “+” icon to enter the alarm setup screen.

b-1. Set the time, ringtone, and initial volume (only for alarm 1 and alarm 2).

b-2. Set the time, ringtone, wake-up light, initial volume, and active day (for alarm 3 to alarm 10).

c. Save the alarm.



Note:

1) Alarms 1 and 2 can be set on the device or through the app, but the app only allows setting/modifying the time, ringtone, initial volume, and toggling the alarm on/off.

2) For Alarms 1 and 2, you cannot delete the alarms, turn off the wake-up light, or set the date in the app.



3) Alarms 3–10 can only be set using the app.

4) The “🕒...” on the device screen represents alarms 2–10. It will remain on if any of these alarms are active; it turns off only when all are disabled.




2) Delete Alarms

- a. Alarms 1 and 2 are built-in and cannot be deleted. You also cannot turn off the wake-up light or edit the active days.
- b. Long press the desired alarm (3-10) in “My Alarms”.
- c-1. Tap the red icon and select “Yes” to delete.
- c-2. Or tap the right icon to edit the alarm



Light Function

Tap  to access the light settings



- 1) Back button.
- 2) Light timer.
- 3) Light on/off switch.
- 4) Alarm screen brightness adjustment.
- 5) Night light brightness (cannot adjust two built-in multicolor lights).
- 6) Six light effects.





Light Timer Settings


Tap  and select the auto-off time.


Note:


- 1) Tap  to discard changes.
- 2) Tap  to save changes and exit.




Night Light Settings


Tap  to choose the color


Tap  to revert to the default color.

Tap  to save and exit.





Rainbow Settings





Tap  to customize the color using the color palette and toggle the breathing light.


Tap  to revert to the default color.

Tap  to save and exit.






Colorful light, Breathing, Wave, Vortex Settings


Tap     to customize the color using the color palette.



Tap  to revert to the default color.

Tap  to save and exit.



White Noise Function



Tap  to access the white noise settings.





White Noise Timer Settings

Tap  and select the auto-off time.

Note:

- 1) Tap  to discard changes.
- 2) Tap  to save changes and exit.



Bluetooth Status Icon


 : Shows Bluetooth is connected.

 : Shows Bluetooth is disconnected.


Reasons for Bluetooth Disconnection:


If the app is downloaded on your phone:

- 1) Your phone's Bluetooth might be off. Turn it on and try connecting again.
- 2) The distance between your phone and the device may be too far. Move closer for automatic reconnection.



Child Lock

Tap  to activate child lock, disabling device buttons to prevent accidental changes by children.

Tap  to deactivate child lock, enabling device buttons for settings adjustments.

