

SPECIFICATION DATA

1-on-1 Conversations \cdot TV Listening \cdot Listening in the Car \cdot Small Groups and much more

PKT 2.0 Pocketalker® Personal Amplifier





The Pocketalker® 2.0 amplifies sound clearly and easily for better understanding.

Pocketalker® 2.0 Personal Amplifier

Personal Amplifier Model PKT 2.0:

Dimensions:	4.9" L x 2.0" W x 1.0" H. (124mm x 51mm x		ifications (1 kHz Sine Wave reference) Typical	
	25mm) (Not including clip or microphone	Power output:	52 mW (max) into 32 ohms (Stereo)	
Weight:	assembly) 3.1 oz. (88 grams) (with batteries)	ALC:	Automatic Level Control; Limits maximum out level	
	White ABS/Polycarbonate molded plastic case.	Distortion:	1% THD (max)	
Battery Type:	Two 1.5V (AAA size), Alkaline or NiMH rechargeable*		63 dB @ 2.5 kHz (Tone=High)	
	(Williams Sound BAT 010-2 Alkaline or BAT 022-2 NiMH recommended)	Frequency resp Tone Control		
Alkaline batteries:	Battery life: Up to 105 hours (typical usage) with the BAT 010-2. Low Battery Indicator: Power "On" Green light	position:		
NiMH	on front panel flashes.	Tone Control at mid position:	0.6dB cut at 5 kHz, 2.9dB cut at 400 Hz.	
	Red LED blinks when charging.	Tone Control	2.0dB cut at 5 kHz, 3.0dB boost at 400 Hz.	
Microphone:	Internal, omnidirectional MEMS microphone (micro-electro-mechanical system). Optional External, omnidirectional, plug-in electret microphone with foam windscreen and 3.5mm mono plug (MIC 014-R).	SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE. *Battery switch must be in correct position for battery type be used. **Charging requires optional charging kit BAT KT7 (Internation		
T-Coil:	Internal with on/off switch and LED indicator.		mono earphones, headphones or neckloop, th	
Tone Control:	External rotary control knob allows user to adjust high/low frequency to optimize hearing.	balance control on the Pocketalker must be turned fully cour clockwise (to the "mono" position) for best volume and batte life.		
***Balance Control:	Adjusts Left/Right Volume Balance		er is not sold, advertised, or intended for use a	
Control:	External rotary volume control knob with integrated power ON-OFF switch.	a personal hea	aring aid. Williams Sound recommends that any eriencing hearing loss be examined by a physic	
Jack:	3.5 mm, stereo mini plug. Tip=Mic signal, Ring=NC, Sleeve=Gnd.	audiologist to	determine the cause before using an amplifica s the Pocketalker.	
Jack:	3.5 mm, stereo mini plug. Tip=Left/Mono, Ring=Right, Sleeve=Gnd. Clip: CLP 014; Allows the user to clip MIC 014 to		ifications for Headphones recommended for us	
Accessories:	clothing such as a lapel or shirt pocket. Lanyard: RCS 003; Allows user to wear unit around the neck, or as a wrist strap. 3.5mm-3.5mm Extension Cord: WCA 007 WC; extends an external microphone to 12 ft. Stereo Earphones / Headphones / Neckloop: EAR 042 / HED 024, HED 036 / NKL 001-S	with the Pocketalker are published on our website. Note 1: CE approval does not apply if product does not dispute CE mark. Note 2: RoHS3: Directive 2011/65/EU + 2015/863/EU Note 3: WEEE: Directive 2012/19/EU		
	(stereo) Neckloop Mono Earphones / Headphones / Neckloop***: EAR 013, EAR 008, EAR 022, EAR 041 / HED 021, HED 027 / NKL 001 (mono) Neckloop Charging Kits: BAT KT7 (International)	This product is covered by the European directives above, including amendments, concerning Waste Electrical and Electronic Equipment (WEEE). Recycle the product and its accessories according to national regulations.		
	RoHS, WEEE, FCC, IC, CE 5 years, parts and labor (90 days on			
vvaiidiity:	accessories)			

1 ower output.	ver output. 32 mvv (max) mto 32 omns (stereo)		
ALC:	Automatic Level Control; Limits maximum output		
	level		
Distortion:	1% THD (max)		
Max gain:	63 dB @ 2.5 kHz (Tone=High)		
Frequency resp	oonse		
Tone Control			
at high	2.7dB boost at 5 kHz, 6.7dB cut at 400 Hz.		
position:			
Tone Control			
at mid	0.6dB cut at 5 kHz, 2.9dB cut at 400 Hz.		
position:			
Tone Control			
at low	2.0dB cut at 5 kHz, 3.0dB boost at 400 Hz.		
position:			

FICATIONS ARE SUBJECT TO CHANGE WITHOUT

- ry switch must be in correct position for battery type being
- ging requires optional charging kit BAT KT7 (International). en using mono earphones, headphones or neckloop, the e control on the Pocketalker must be turned fully countervise (to the "mono" position) for best volume and battery


ocketalker is not sold, advertised, or intended for use as onal hearing aid. Williams Sound recommends that any ual experiencing hearing loss be examined by a physician/ ogist to determine the cause before using an amplification such as the Pocketalker.


Pocketalker® 2.0 Personal Amplifier

Acoustic Specifications: Typical values in dB SPL (ANSI S3.22-1987)

Lightweight stereo headphone, HED 024: (with 6cc coupler)


Test	Tone High	Tone Mid	Tone Low
SSPL90 (Max)	132.2	132.1	131.9
HF Ave (SSPL90)	124.0	124.0	123.9
HF Ave full on gain (60 dB)	45.2	41.7	38.6
Ref test gain	45.2	417	38.6






Wide range stereo headphone, HED 036: (with 6cc coupler)


Test	Tone High	Tone Mid	Tone Low
SSPL90 (Max)	128.5	125.7	130.0
HF Ave (SSPL90)	123.4	123.1	124.6
HF Ave full on gain (60 dB)	44.2	40.6	39.3
Ref test gain	44.2	40.6	39.3






Mini stereo headphone, EAR 042: (with 2cc coupler)

Test	Tone High	Tone Mid	Tone Low
SSPL90 (Max)	124.5	124.5	124.4
HF Ave (SSPL90)	118.9	118.9	118.9
HF Ave full on gain (60 dB)	39.0	35.7	32.8
Ref test gain	39.0	35.7	32.8





Note: The Pocketalker® 2.0 is not sold, advertised or intended for use as a personal hearing aid. Williams Sound recommends that any individual experiencing hearing loss be examined by a physician/audiologist to determine the cause before using this device.

NOTE: SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

U.S. | 800.843.3544 info@williamsav.com