

Turn Signal And License Plate Relocated Kit For Sportster (VLSPRK):



Parts List:

A	Mounting Bracket	x1	I	6mm Collar Nut	x4
B	Mounting Strip	x1	J	8mm Spring Washer	x2
C	5/16" x 2a4" Allen key Bolt	x2	K	4mm Nut	x2
D	8mm x 15mm Plain Washer	x4	L	Butt Connector 32 #	x16
E	5/16" x 1.5" Allen Key Bolt	x2	M	4mm Spring Washer	x2
F	6mm x 20mm Allen Key Bolt	x4	N	Wires (Red, Blue, Yellow) 36"	x3
G	5/16" Nut	x4	O	SS Tear Drop Filler	x2
H	4mm x 12mm Allen Key Bolt	x2			

Installation Instructions:

Step 1:

Securely, place motorcycle on a motorcycle jack and unbolt the lower bolts on the rear shocks on both sides. Next, lower the tire.

Step 2:

Remove the seat and disconnect the turn signal and license plate light connectors. Remove the rear reflector from the underside of rear fender. Remove license plate from the motorcycle.

Step 3:

Remove the turn signals and license plate light.

Step 4: (Optional)

Mark the bottom of the fender on the stock mounting bracket using a silver marker. Remove the stock mounting plate by drilling the rivets located at the inside of the fender. Once removed, cut at the marked point to remove the license plate mount and reinstall the mounting plate. Using the provided 4mm x 12mm Allen Key Bolt. If you opted to keep the stock mounting plate, you can still clear the section by removing the license plate flap.

Step 5:

Assemble the relocation bracket by attaching the mounting strip to the mounting bracket using the attached bolts and nuts.




Fig (A)

Step 6:

Once assembled, push the turn signal relocation assembly under the fender with the arms of the bracket inside the fender walls. Once in place, attach the mounting strip to the T-end of the rear fender support using the attached bolt and nut. (Figure A).

Step 7:

Next, use the supplied 5/16" x 1.5" Allen Key Bolt to install the bracket to the fender and tighten securely. It is recommended that you use flat washers between the bracket and the fender rail. Note that fillers have been provided to be installed to fill the recess left by the turn signal removal.

Step 8:

Install the license plate and the license plate frame onto the bracket using the 6mm x 20mm Allen Key Bolt.

Step 9:

Extend the turn signal wires and license plate wires as required using the supplied wires and butt connectors. Test to make sure all lights are working properly. Install the turn signals onto the newly installed bracket using the supplied Allen Key Bolts.

Step 10:

Install the filler on the fender rail at the stock turn signal location. Reinstall the shock.




Fig (A)

Note:

- You will need to cut the wires in order to extend them to reach the new position of turn signals and license plate.
- Make sure that no wire hangs loose as they may get caught up in the wheel while riding which can result in accidents.

Warnings!

- It is highly recommended that you seek guidance from a professional mechanic before installation.
- Before cutting any wires, make sure that the bike is switched off. It is recommended that you remove or disconnect battery while working with the wires.