
User Manual



WINIX AIR CLEANER



O_{Model}

ZERO+ (AUS-1250AZPU)

O Use & Care Guide



• Please read and follow all safety rules and instructions in this manual before operating.


• The product warranty is printed on the back of this guide, so please keep it in a safe place for future use.

CONTENTS


5-STAGE AIR PURIFICATION 3
CONTROLS 4
WHERE TO USE 5
INSTALLING THE FILTERS 6
SAFETY AND CAUTIONS ·······8
INITIAL OPERATION 9
AUTO AND SLEEP 10
MANUAL MODE, TIMER AND PLASMAWAVE [®] · · · · · · · · · · · · · · · · · · ·
CHILD LOCK, AIR QUALITY LED LIGHT
FILTER CARE 13
CLEANING THE DUST SENSOR 17
CLEANING CARE 18
FREQUENTLY ASKED QUESTIONS 19
UNIT SPECIFICATIONS 21
SAFETY INSTRUCTIONS 22
PRODUCT WARRANTY 23


► This product is suitable for 220 - 240 V only.

5-STAGE AIR PURIFICATION



CONTROLS





Detects the amount of ambient light within the environment, to adjust the brightness of the LED indicators. Every time the Mode button is pressed, the Mode LED light will cycle through the settings. (Auto, Sleep, Low, Medium, High, Turbo) Press to cycle through and set desired length of operation (1hr, 4hr, 8hr, [NO TIMER]).

Press and hold for 3 seconds to enable or disable the Air Quality light.


WHERE TO USE

Allow 30 ~ 45 cm of space between TVs, radios, and other electronic products electromagnetic interference from certain electronics may cause product malfunction.

Place indoors away from direct sun light direct exposure may cause product malfunction or failure.

Only place on hard, flat surfaces

flimsy or slanted surfaces may result in abnormal noise and vibrations.



WARNING Follow these instructions to reduce the risk of serious injury or death and to reduce risk of damaging the unit.

Do not use around mist or fumes from Do not place around heating elements Δ 41 industrial oil or around large quantities of metallic dust Do not install in any sort of motor or Do not place in an area with excessive Α А transport vehicle (trucks, boats, ships, etc.) amounts of noxious gases Do not place near any flammable Do not have unit facing into wind or draft Λ Λ materials (aerosols, fuel, gases etc.) Do not place in excessively humid areas Λ Do not place below any electrical outlet Λ where unit may become wet

INSTALLING THE FILTERS


This product comes with all of the required filters. The protective plastic wrap must be removed from the filters before use.

X Operating the unit without removing the plastic wrap may result in product failure.

X Unplug and make sure the unit is turned off before installing filters.

X The unit will automatically power off when front panel is opened.


- Remove the front panel by grasping its upper edge and gently pulling towards yourself.
 - To remove the front panel, the latch at the lower edge of the panel must be released from its position.



② Remove the filters from the unit, they are protected inside a plastic wrap.



- ③ Remove filters from protective plastic wrap.
 - Operating the unit without removing filters from plastic may cause abnormal noise, deformation, or fire as a result of overheating.




 Refer to pages 13 - 16 for detailed information on filter care and how to replace them.


INSTALLING THE FILTERS

④ Install the filters until they fit securely in place.

Filters must be installed in this order:

- 3 True HEPA filter (rear)
- 2 Deodorization filter (middle)
- 1 Pre-filter (front)
- To install the pre-filter, insert bottom tabs into the slots on either side of the lower part of the unit, then rotate upward to insert the upper tabs into the slots at the top part of the unit until both sides audibly click into place.
- (5) Replace the front panel by first inserting the latch at the bottom edge into the base of the unit, then rotate the panel upward toward the top of the unit until it magnetically snaps closed.





6 When to service and replace filters:

Filter	Indicator Light	When to service	When to replace
1 Pre-filter	none	Clean once every 14 days	Permanent
2 Deodorization filter	€]	Can NOT be	Lasts up to
3 True HEPA filter	Check Filter	WASHED	12 months

X Intervals between filter replacement may vary depending on environment.

※ For optimal use, Pre-filter can be cleaned every 14 days which can extend the life of other filters.

X Pet filter replacement guide separately mentioned on the Pet filter package board.

To purchase replacement Winix filters : contact our authorized distributor 'Ausclimate' or visit the below web site.

- TEL: 1800 122 100
- www.ausclimate.com.au
- www.winixaustralia.com.au



SAFETY AND CAUTIONS

Before operating this equipment, carefully read and follow these safety cautions and instructions to avoid damage and ensure safe use.

Ensure filters are inserted before running unit

running unit without filters can shorten the units life and cause electric shock or injury.

Be sure foreign objects are NOT inserted into the vents on the unit objects can include pins, rods, and coins.

Do not touch any part of the interior of the unit with wet hands the high voltage may cause electric shock.

Ensure unit intake and outlet vents do not become blocked

blockage may lead to increased internal temperatures causing product failure and deformation.

Do not use the unit as a step stool or place heavy objects on it

personal injury may occur or product failure and deformation.

4	WARNING		 ons to reduce the risk of serious oreduce risk of damaging the unit.
▲	Do not pull on the pow unplugging the unit	er cord when	Do not tie or knot power cord when unit is in operation
	If the unit becomes sub unplug it and contact c	J ,	Do not unplug or move the unit while in operation
	Do not plug additional the same outlet or pow		Do not touch the plug with wet hands
4	Unplug unit when not i extended periods of tin		Cord can become damaged by forcefully bending, pulling, twisting, bundling, pinching or placing heavy objects on it


If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.

This appliance is not intended for use by a person (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

X Children should be supervised to ensure that they do not play with the appliance.

INITIAL OPERATION

- ① Insert the unit plug into an electrical outlet.
 - The Control Panel lights will turn on and off.



2 Press the 'Power' button.



- During the first 4 minutes of power up, the Air Quality light will flash as the Smart Sensors measure the air quality in the environment, after which normal operation will begin.
- ③ By default, when the unit first powers on, the mode will be set to Auto with PlasmaWave[®] enabled.
 - When in Auto Mode the fan speed will be automatically adjusted according to the environments air quality.
 - PlasmaWave[®] works to remove harmful airborne contaminants.

Sleep Auto	PLASMAWAVE®
Low Med High Turbo	

- In Auto mode, as the indoor air quality improves, the fan speed will automatically be reduced to Low.
- When the unit is running, you may hear a chirping or buzzing sound. The sound is from large particles passing through PlasmaWave[®], it is normal and does not signify product failure. To disable PlasmaWave[®], see page 11.


AUTO AND SLEEP

Every time the Mode button is pressed, the Mode LED light will cycle through the settings. (Auto, Sleep, Low, Medium, High, Turbo)

1. Auto Mode

Enables Auto operation based on the unit's air quality Smart Sensors.


- ① Press the Mode button to select Auto mode.
 - The mode LED light will indicate when 'Auto' mode has been selected, and operation will begin.
 - Each time the Mode button is pressed, the modes will be cycled. (Auto, Sleep, Low, Medium, High, Turbo).



- When in Auto Mode the fan speed is automatically adjusted according to the indoor air quality. As the indoor air quality improves, the fan speed will automatically be reduced. If the indoor air quality decreases the fan speed will automatically be increased.
 - When unit is first started, Auto Mode is enabled and set to Low fan speed.

2. Sleep Mode

- 1 Press the Mode button to select Sleep mode.
 - The mode LED light will indicate when 'Sleep' mode has been selected, and operation in that mode will begin.



- When Sleep mode is selected, the fan speed is automatically set to Low. Fan speed can be changed by pressing the Fan Speed (Mode) Button.
- When Sleep Mode is enabled, the Air Quality light is disabled.


MANUAL MODE, TIMER AND PLASMAWAVE®

Every time the Mode button is pressed, the Mode LED light will cycle through the settings. (Auto, Sleep, Low, Medium, High, Turbo)

3. Manual Mode (setting fan speed)

Users can opt to manually set the fan speed to Low, Medium, High, or Turbo.

- ① Press the Mode button to select the desired fan speed.
 - The mode LED light will indicate the selected fan speed, and operation will begin.




 When Manual Mode is in use, Auto and Sleep modes are automatically disabled.

4. Timer

The timer can be set for when you want the unit to run for a specified period of time.


- ① Select the desired period by pressing the Timer button.
 - The Timer LED light will indicate the selected length of operation.
 - Every time the Timer button is pressed the Timer LED light will cycle through the settings. (1hr, 4hr, 8hr, [NO TIMER]).



5. PlasmaWave®

By default, PlasmaWave® is enabled whenever the unit is powered on.

① Press the Plasma button when the power is on to enable or disable this feature.



CHILD LOCK, AIR QUALITY LED LIGHT

6. Child Lock

This feature prevents children from tampering with the control panel.


- Press and hold the Child Lock button for 3 seconds to enable or disable the feature.
 - When the Child Lock indicator is lit, the feature is enabled.
 - When Child Lock is enabled, the control panel is locked and the settings cannot be changed.
 - To disable, press and hold the Child Lock button again for 3 seconds.



7. Air Quality LED Light

The Air Quality LED light may be turned on or off.

- To turn the Air Quality LED light on or off, press and hold the Timer button for 3 seconds.
 - When on, the LED light will indicate the current indoor air quality according to three levels BLUE/GREEN/AMBER/RED







- When Auto Mode is enabled the Air Quality LED light may or may not be on, depending on the amount of ambient light in the room.
- When Sleep Mode is activated, the Air Quality Indicator light is turned off.

1. Changing Filters

When the Check Filter indicator LED is on, it is time to replace both the True HEPA and Deodorization filter.

Filter	Indicator Light	When to service	When to replace
1 Pre-filter	none	Clean once every 14 days	Permanent
2 Deodorization filter	€]	Can NOT be	Lasts up to
3 True HEPA filter	Check Filter	WASHED	12 months

X Intervals between filter replacement may vary depending on environment.

- % For optimal use, Pre-filter can be cleaned every 14 days which can extend the life of other filters.
- X Pet filter replacement guide separately mentioned on the Pet filter package board.

To purchase replacement Winix filters : contact our authorized distributor

'Ausclimate' or visit the below web site.

- TEL: 1800 122 100
- www.ausclimate.com.au
- www.winixaustralia.com.au




2. Removing Filters


- Remove the front panel by grasping its upper edge and gently pulling towards yourself.
 - To remove the front panel, the latch at the lower edge of the panel must be released from its position.



Press the tabs on the top edge to remove the 1 Pre-filter.



③ First remove the 2 Deodorization filter and then the 3 True HEPA filter by pulling on the numbered tags at the top of each filter.



- For optimal performance, only genuine Winix filters should be used with this unit.

3. Filter Assembly and Replacement


Filters should be re-installed in the reverse order of their removal.

① Insert the replacement

3 True HEPA filter (rear)

2 Deodorization filter (middle)

 Remove the protective plastic wrap from new filters. Operating the unit without removing the protective plastic wrap may cause abnormal noise, deformation, or fire as a result of overheating.





2 Insert the 1 Pre-filter (front).

 To install the pre-filter, insert bottom tabs into the slots on either side of the lower part of the unit, then rotate upward to insert the upper tabs into the slots at the top part of the unit until both sides audibly click into place.



③ Replace the front panel by first inserting the latch at the bottom edge into the base of the unit, then rotate the panel upward toward the top of the unit until it magnetically snaps closed.






Reset

Latch

4. Cleaning the Pre-filter

Intervals between filter cleanings may vary depending on the air quality.

- ① Use a vacuum cleaner or soft brush to clean the Pre-filter. If it is excessively dirty, wash with room temperature water.
 - Use only water, do not use volatile substances such as alcohol or acetone.



% If the pre-filter becomes damaged or in any way needs replacement: Please contact your local dealer


 Do not use benzene, alcohol, or other volatile fluids, which may cause damage or discoloration.
 The Pre-filter is reusable after cleaning, ensuring it has completely dried.
 Do not use hot water over 104°F or volatile fluids such as paint thinner.
 After washing the pre-filter, allow it to dry completely in a wellventilated area. Otherwise, it may develop a bad odor.

CLEANING THE DUST SENSOR

Cleaning the Dust Sensor

For optimal performance of the Dust Sensor, which detects airborne dust and ultrafine particles, clean it every two months. Clean it more frequently when the unit is running in a place with high dust levels.

① Open the Dust Sensor cover.



- Lens Cotton swab


② Use a damp cotton swab to wipe the lens and intake area of the Dust Sensor.

alcohol or acetone.


• To clean the sensor area, use only water.

Do not use volatile substances such as

③ Wipe away any remaining moisture with a dry cotton swab.



- ④ Close the Dust Sensor cover.
 - The Dust Sensor cover may be cleaned using a vacuum cleaner.




CLEANING CARE

Cleaning the exterior and interior

Cleaning the exterior

Wipe with a soft damp cloth using room temperature water. Afterwards, wipe it down with a clean dry cloth.


• For optimal performance, clean the front panel 1-2 times a month.



Cleaning the interior

Open the front panel and clean the interior with a vacuum cleaner.

• For optimal performance, clean the interior 1-2 times a month.



- When cleaning the unit, always unplug the power cord first and then wait until the unit has cooled off.
- Never disassemble, repair or modify this unit yourself.
- Do not use flammable sprays or liquid detergents.
- Do not allow children to clean or maintain the unit.
- Before cleaning or maintaining, ensure unit is off and unplugged.

FREQUENTLY ASKED QUESTIONS

Problem	Check / Actions to take		
It does not turn on at all.	 Is there a power outage? Check to see if other lights and electrical equipment are working and try again. 		
It doesn't work in Auto mode.	 Has Auto mode been selected? Press the Mode button until Auto mode is selected. Is the sensor blocked or clogged? Clear the sensor using a vacuum cleaner. view page 17. 		
It vibrates and makes a lot of noise.	 Is it running on a slanted surface? Move the unit to a hard, flat area of the floor. 		

FREQUENTLY ASKED QUESTIONS

Problem	Check / Actions to take
The power plug and outlet feel hot.	 Is the plug securely plugged in? Make sure the plug is properly plugged into the outlet.
There is a strange smell.	 Is it being used in a place with a lot of smoke, dust, or odors? Clean the air intakes on the front sides of the unit and clean the pre-filter. Contact customer service to confirm the exact cause. Replace the Deodorization filter and True HEPA filter.
The product is not purifying the air enough.	 Is the Check Filter indicator light on? – Replace the filters as required.

UNIT SPECIFICATIONS

Model Name	AUS-1250AZPU	
Power Voltage	220 - 240 V, 50 / 60 Hz	
Power Rate	50 W	
Recommended room capacity	49.5 m ²	
Weight	8.5 kg	
Dimensions	415 mm(W) x 245 mm(D) x 600 mm(H)	
Replacement Filter	FILTER GU, item : 1712-0095-01 FILTER GJ, item : 1712-0092-01	

% The exterior, design, and product specifications may be changed without prior notice to improve product performance.

SAFETY INSTRUCTIONS

Thank you for purchasing a Winix air purifier. This product is for household use only.

IMPORTANT CAUTIONS FOR USING YOUR AIR PURIFIER

WARNING : Follow the instructions in this manual to reduce the risk of electric shock, short circuit, and/or fire.

- Do not repair or modify the unit unless specifically recommended in this manual. All other repairs should be completed by a qualified technician.
- Do not use if the power cord or plug is damaged or the connection to the wall outlet is loose.
- Use AC 220 240 V only.
- Do not damage, break, forcefully bend, pull, twist, bundle, coat, pinch, or place heavy objects on the power cord.
- Periodically remove dust from the power plug. This will reduce the risk of shock due to humidity build up.
- If the power plug is damaged, it must be replaced by the manufacturer or a qualified technician.
- Remove the power plug from the outlet before cleaning the unit. When removing the power plug, grasp by holding the plug itself, never hold by the cord.
- Remove the power plug from the outlet when not in use.
- Do not handle the power plug with wet hands.
- Do not operate the unit when using indoor smoke-generating insecticides.
- Do not clean unit with benzene or paint thinner. Do not spray insecticides on the unit.
- Do not use the unit where it is humid or where the unit may become wet, such as the bathroom.
- Do not insert fingers or foreign objects into air intake or outlet.
- Do not use the unit near flammable gases.
 Do not use near cigarettes, incense, or other spark-creating items.
- Unit will not remove carbon monoxide emitted from heating appliances or other sources.

IMPORTANT PRECAUTIONS FOR USING YOUR AIR PURIFIER

- Do not block the intake or outlet vents.
- Do not use near hot objects, such as a stove.
- Do not use where the unit may come into contact with steam.
- Do not use the unit on its side.
- Keep away from products that generate oily residue, such as a deep fryer.
- Do not use detergent to clean the unit.
- Do not operate without a filter.
- Do not wash and reuse the True HEPA Filter or the Deodorization filter.
- Hold the handle on the back of the unit to transport.
- Do not hold by the front panel.

PRODUCT WARRANTY

Product Name		Air Purifier
Model Name		AUS-1250AZPU
Purchase Date		
Warranty period		Two (2) years
Place of purchase		
Place of purchase Tel.		
	Address	
Customer	Name	
	Tel.	

X After purchase, be sure to complete all of the above information.





2610-0208-00 Rev.00

O Contact for product related inquiries and customer service

> Distributed by Ausclimate Pty Ltd

To expedite service, please specify the model name and number, the nature of the problem, your contact information, and your address.

After sales and warranty enquiries, visit website or call 1800 122 100 Website : www.ausclimate.com.au / www.winixaustralia.com.au