

The logo for Verve design, featuring the word 'verve' in a lowercase, rounded sans-serif font, with 'design' in a smaller, lowercase sans-serif font below it.

# SMART WALL LIGHT

A photograph of the Emily wall light, a square, white, minimalist fixture mounted on a grey wall in a bedroom setting.

AWL121WHHA

## Safety Instructions

Do not run this light un-attended.

This appliance is not intended for use of persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance.

Do not look directly into the light source to prevent eye discomfort.

Do not attempt to disassemble, repair, or modify this appliance for the warranty will be void if repair is carried out by unauthorized person/services.

Do not use this unit for functions other than those described in this instruction manual.

Do not use the unit in the presence of inflammable substances or vapour such as alcohol, insecticides, petrol etc.

Do not immerse the light in any liquid.

Do not conduct repairs on this unit. It has been built in accordance with relevant safety and performance standards. An electrical specialist must carry out all repairs.

**ALWAYS** turn **OFF** the unit when not in use.

## NOTE

This product is intended for permanent connection to fixed wiring of the 230/240V mains electrical supply system.

Installation must be carried out by a licensed contractor.

Installation must adhere to local wiring rules and requirements of standard AS/NZS3000 Electrical Installations.

The product is for indoor use only.

## To Fit/Change Globe

Before changing globe, switch light off and wait till completely cool.

To remove globe, once cool, and with product still off, unscrew from the globe holder.

Replace it with a recommended globe type.

To fit new globe, screw globe into globe holder. Do not overtighten.

## Smart Globe (GLD320HA)

The wall light includes a 10W B22 smart globe. Follow the GRID Connect pairing instruction manual located inside the globe packaging for instructions on pairing your globe with the GRID Connect App.

## Installation Instructions

**IMPORTANT:** ENSURE THAT THE POWER IS TURNED OFF TO THE CIRCUIT BEING WORKED ON.

1. Select a mounting position.
2. Screw the mounting bracket into a solid member such as a wall stud or noggin. If this isn't possible, consideration should be given to installing a supporting batten, or other suitable fixings that will support the weight of the light safely and adequately in the wall material.
3. Remove the packing material and dispose correctly according to markings. You may want to leave a plastic bag on the shade to protect it during installation.
4. Fit the mounting bracket at the chosen location and check it is secure.
5. Complete the wiring of the cord to the mains power supply using the terminal block provided.
6. Check all connections.
7. Fix the lamp by slipping the mounting cover over the mounting bracket, then tighten the two screws to hold it in position.
8. Remove any remaining protective covering or packaging material, and install a globe. Ensure to use the globe provided with the product.
9. Restore power to circuit and test.
10. Download the free Grid Connect App to your iOS or Android device.

## Care & Cleaning

Ensure fixture is turned off when replacing globes or cleaning.


Allow to cool completely.

Clean the shade with a duster brush or vacuum cleaner.

Do not use harsh abrasives or solvents on any part of the fixture.

Clean only using diluted mild detergent on a damp cloth.

Do not insert any object into lampholder during cleaning.



# WARRANTY

Arlec guarantees this product in accordance with the Australian Consumer Law and all other applicable Australian and New Zealand laws that are unable to be excluded.

Arlec also warrants to the original first purchaser of this product ("you") from a retailer with which this document is given that this product will be free of defects in materials and workmanship for a period of 12 months from the date of purchase; provided the product is not used other than for the purpose, or in a manner not within the scope of the recommendations and limitations, specified by Arlec, is new and not damaged at the time of purchase, has been maintained in accordance with the recommendations specified by Arlec, has not been subjected to abuse, misuse, neglect or damage, has not been modified or repaired without the approval of Arlec and has not been used for commercial purposes ("Warranty").

If you wish to claim on the Warranty, you must, at your own expense, return the product, and provide proof of original purchase and your name, address and telephone number, to Arlec at the address below or the retailer from whom you originally purchased the product within 12 months from the date of purchase.

Arlec will (or authorise the retailer to) assess any claim you may make on the Warranty in the above manner and if, in Arlec's reasonable opinion, the Warranty applies, Arlec will at its own option and expense (or authorise the retailer to) replace the product with the same or similar product or repair the product and return it to you or refund the price you paid for the product. Arlec will bear its own expenses of doing those things, and you must bear any other expenses of claiming on the Warranty.

## For goods purchased in Australia (only):

The Warranty is in addition to other rights and remedies you may have under a law in relation to the product to which the Warranty relates.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

## For goods purchased in New Zealand (only):

The Warranty is in addition to, and does not affect, other rights and remedies you may have under a law in relation to the product to which the Warranty relates.

Our goods may come with guarantees that can only be excluded under the New Zealand Consumer Guarantees Act 1993 to the extent you are acquiring the product for a business purpose and it would be fair and reasonable for Arlec to contract out of those guarantees.

Arlec Australia Pty. Ltd. ACN 009 322 105 gives the Warranty for goods purchased from a retailer in Australia by you and Arlec New Zealand Limited NZBN 9429030738294 gives the Warranty for goods purchased from a retailer in New Zealand by you (collectively Arlec). Arlec's telephone number, address and email address for purposes of giving the Warranty are:

**Telephone Number:** 1800 826 859 (in Australia)  
0800 003 329 (in New Zealand)

**Street Address:** Caribbean Park, 36 Lakeview Drive,  
Scoresby, Victoria, 3179, Australia

**Postal Address:** P.O. Box 2596, Rowville, Victoria,  
3178, Australia

**Email:** [custservice@arlec.com.au](mailto:custservice@arlec.com.au)