




# Renaissance

## Cooking Systems

If you are experiencing any issues with your REFR3 ice maker, please check the water supply orifice as per the simple steps, below. We also recommend an in-line water filter for best results.


The ice maker will need to be unplugged and water shut off. If your ice maker is below the drain, you'll need a condensate pump.

[Click here for the RPUMP.](#)




**Step One**

Inside the ice maker on the left side you will see the water line coming down, that will need to be unscrewed and inspected to make sure the line is clear.



**Step Two**

Once that is removed, you will see three screws that need to be removed and you will have access to the orifice to make sure that is clear.



**Orifice Image**

After cleaning out the orifice, reassemble the parts, plug the ice maker in and turn the water on, you should see and hear the water flowing into the unit.