

How Much Heat Do You Need?

CUBIC FEET OF SPACE TO BE HEATED**	TEMPERATURE RISE REQUIRED (°F)*			
	20°	30°	40°	50°
5,000	14,000	20,000	27,000	34,000
7,000	19,000	28,000	38,000	47,000
10,000	27,000	40,000	54,000	67,000
15,000	40,000	60,000	80,000	100,000
20,000	54,000	80,000	107,000	133,000
30,000	80,000	120,000	160,000	200,000
50,000	133,000	200,000	266,000	333,000

BTU CAPACITY REQUIRED

* Temperature rise required is the difference between the actual temperature and the desired temperature.

** To determine cubic footage: length x width x height of structure.

Note: This chart is only a guide. Buildings vary according to construction materials, insulation, humidity, etc.