

Hansen's

FIND
the **RIGHT FIT** SKI
equipment
GUIDE

SKI LENGTH SHOULD REACH:

- mid forehead for advanced/ aggressive skiers - - - - -
- nose for intermediate skiers - - - - -
- chin for beginner/cautious skiers - - - - -



WIDER SKIS:

provide more float in powder



NARROW SKIS:

generally more at home on groomed snow



ROCKER:

especially in the nose, provides more float in powder and allows for easier turn initiation



CAMBER:

under foot provides more grip on groomed/ hard pack snow



STIFFER SKIS:

especially with metal, perform better at high speeds



SOFTER SKIS:

easier to handle at slower speeds

SKIS

1. Fit on face and with helmet is paramount



2. Dual lens and lots of venting will help eliminate fogging.

3. Spherical lens is more optically correct than a flat lens.



1. Toes should touch front of toe pocket for proper fit.



2. When flexing forward in your ski boot you should have very little or no heel lift.

3. Stiffer flex for advanced ski and softer flex for beginner/intermediate skier.



GOGGLES

BOOTS