

### **Instruction Sheet**



## Aqua TROLL 500/600 BGA-PE Sensor Overview

The In-Situ blue-green algae/phycoerythrin sensor measures BGA-PE levels in natural water, surface water, groundwater, produced water and aquaculture applications.

### **Getting Started**

# Install sensor.



Rinse sensor with clean water before use.



Install sensor. Do not twist.





Remove restrictor from the instrument.



Place instrument in








Remove sensor port plug if installed. Do not twist.

Lubricate o-ring at bottom of sensor.



When using BGA-PC and BGA-PE sensors together, install in non-adjacent sensor ports.



Sensor installation - End view

For detailed calibration instructions, see the instruction manual or quick start guide for your In-Situ instrument.



Connect to the instrument with VuSitu or Win-Situ software.

🛃 Logging	A Barometric Pressure	
▲ Calibrations	A Rhodamine WT	
Instrument Settings	Calibration Report	
Ø Disconnect		
Select Calibrations from the menu.	Choose the BGA-PE option and follow the	Flip tl deplo

option and follow the instructions.



the restrictor into deployment mode after calibration

## **Preparing Calibration Standards**

Calibrate the Chlorophyll sensor using one of three methods:

1. Deionized Water: Reset the zero point by performing a calibration in deionized water.

2. Rhodamine Standard: Calibrate with a Rhodamine WT standard to adjust readings of higher

concentrations based on known equivalency. Follow the instructions below to prepare a Rhodamine WT standard.

3. Custom Standard or Reference: Use a reference or a custom calibration standard.

# Preparing Rhodamine WT Calibration Standard



1. Start with a 2.5% Rhodamine WT solution. Pipette 1.0 mg/L of the solution into a 250 mL Class A volumetric flask.



Use an opaque container to store the 100 mg/L solution in a cool, dark place for up to six months.



2. Bring the flask to volume with deionized water. The resulting solution is 100 mg/L Rhodamine WT.



3. To obtain a 200 µg/L concentration, pipette 2.0 mL of the 100 mg/L solution into a 1000 mL flask.



4. Bring the flask to volume with deionized water.



Prepare the 200  $\mu$ g/L solution immediately before use and discard after calibration. If desired, use the procedure described above to make a different concentration of Rhodamine WT, such as 400  $\mu$ g/L. Alter the volume in Step 3 according to the table below to achieve the target concentration.



Use caution when deploying in direct sunlight or environments with highly-reflective surfaces. Ambient light can interfere with sensor readings.

#### **Concentration Guide & Expected Calibration Values**

Target Concentration	100 mg/L Rhodamine WT	Expected Calibration Value at 25° C	Expected RFU Value at 25° C
0 μg/L (deionized water)	none	0	0
100 μg/L	1.0 mL	270 μg/L (ppb)	27.0
200 µg/L	2.0 mL	546 μg/L (ppb)	54.6
400 μg/L	4.0 mL	1045 μg/L (ppb)	105

\* These values are for reference only. Actual values may vary based on user-prepared standards.