

Installation Instructions

RIMLESS WALL FACED TOILET SUITE

JUNIOR

UNIVERSAL INLET

Installation of Toilet Seat and Cleaning

It is recommended that toilet seat and cover be installed after all trades are finished

Note:

Installation to be in accordance with AS/NZS 3500 series of Standards and/or local regulations.

All measurements for roughing-in should be taken from finished wall/floor. It is strongly recommended by the manufacturer that installation is carried out by a licensed plumber.

Cleaning Recommendations

The high quality vitreous china finish on all sanitary ware can be maintained by simply using mild soapy water and wiping over.

Sanitary ware should not be cleaned with abrasive materials e.g. steel wool/scourers. Do not use any corrosive or abrasive cleaning agents containing acids or scouring agents as this may lead to surface damage.

Bleaches can also discolour seats and hinges and therefore should not be used.

If your toilet has metal hinges they should only be cleaned with a mild liquid domestic cleaner, with soft soapsuds or Steel & Chrome cleaner

After cleaning, rinse with clean water and polish with a clean soft cloth.

INSTALLATION INFORMATION

S-Trap

1

Important 25mm approx projection from wall 1/2" B.S.P Nipple

86mm

700mm

180mm

75-165mm

1. Rough in position of water inlet, waste outlet and floor fixing bracket holes. Ensure inlet connection extends 60mm from finished wall. Drill holes for floor fixing bracket then fix brackets to floor.

2

2. Lubricate the fins of the pan bend and position into waste pipe. The knuckle bend must be secured to the wall to avoid leak.

If cut is needed, please make sure cut the right proportion according to the ring, clean the trap after cutting, the bits may cause leaking.

75-165mm

3

3. Lubricate rubber on the exposed connector end

P Trap

4

min of 50mm onto spigot

4. Align and push fully assembled toilet back to the wall

5

180mm

5. Set up waste pipe so that the end of the pan collar extends 180mm from the finished wall.

6

min of 50mm onto spigot

6. Align and push fully assembled toilet back to the wall, connecting pan spigot to pan collar. Bucket flush and check for leaks. Due to the design, weight, and stability of the toilet, a silicone adhesive is recommended and accepted by manufacturer for floor based Fixing. Please ensure all wet area are completely sealed.

7


7. Place rubber seal into pan recess (Sealant can be used if necessary). Place cistern screws into holes on the inside of cistern, making sure washers are located correctly. Gently lower cistern onto pan locating fixing screws into matching pan screw holes. Secure cistern to pan. Before tightened fully make sure cistern sits square and straight to pan.

8

Stop Tap

Flexible Hose

8. Fit off stop tap then connect rear water inlet valve to stop tap. Fill cistern and ensure correct water level.



Make sure inlet valve flow are free from side of cistern wall.

If inlet valve been jam on the cistern wall, it will cause inlet valve keep filling.