


## REPAIR OF DELAPIDATED OR SEPARATING MASONRY IN A RUBBLE FILLED OR SOLID WALL USING GROUT TIES



### Method Statement:

1. Mark the positions for the holes on the outer face of the wall.
  2. Drill 14mm clearance hole (16mm if the Grout Tie is longer than 450mm) at the required location and to the specified depth.
  3. Clean out all dust from the hole and thoroughly flush with water. Ensure the slot is damp prior to commencing step 7.
  4. Attach the required length of the Grout Tie Pinning Nozzle to the gun.
  5. Mix StrucSol HSGrout using a power mixer and load into the Grout Tie Pointing Gun.
  6. Pump grout to fill the nozzle.
  7. Wind the Grout Tie into the nozzle and ensure that it is fully covered in grout.
  8. Insert the nozzle to the full depth of the drilled hole and pump the grout.
  9. Make good all the holes at the surface and cracks using StrucSol TE resin or StrucSol Crack Filler and leave ready for decoration. To achieve a near perfect look, use StrucSol Stain Colour Matching mortar.
  10. Clean tools with clean, fresh water.
- ☞ *Pointing may be carried out as soon as is convenient after the StrucSol HSGrout has started to gel.*

### Recommended Tooling

- ☞ For drilling: SDS rotary hammer drill 650 / 700w.
- ☞ For mixing StrucSol HSGrout: SDS Rotary percussion 3-jaw chuck drill with mixing paddle.
- ☞ For insertion of Grout Ties: Grout Tie Pointing Gun.
- ☞ For Injection of the StrucSol Crack Filler: A 400ml Mastic Gun is required.
- ☞ PPE Clothing and Protection.

### General Notes

If you require specific advice on your project, please call the StrucSol technical help line 0116 2375082. We can supply a full support service which includes:

- ☞ Advice and assistance on all structural matters.
- ☞ Preparing repair proposals for specific projects.

### SPECIFICATION NOTES

The following criteria are to be used unless specified otherwise.

- |          |  |
|----------|--|
| <b>A</b> | Grout Ties are to be installed at a density of 2.5 ties / m <sup>2</sup> (i.e. 900mm horizontal and 450mm vertical spacing with alternate rows staggered).   |
| <b>B</b> | The density is increased around openings with ties placed at 300mm vertical spacing and 225mm back from the opening.   |
| <b>C</b> | Depth of hole to be Grout Tie length +25mm.  |
| <b>D</b> | In hot conditions, ensure the masonry is well wetted or primed to prevent premature curing of the StrucSol HSGrout due to rapid de-watering.   |
| <b>E</b> | Do not use StrucSol HSGrout when the air temperature is 4°C and falling, or apply over ice. In all instances, the hole MUST be thoroughly damp or primed prior to injection of the StrucSol HSGrout. |

The above specification notes are for general guidance only and StrucSol reserve the right to amend as necessary.