

CURVE BACK ASSEMBLY INSTRUCTIONS



(717) 354-8998 • (877) 560-5966
New Holland, PA

#110 Curve Back Glider



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16 wrench

Included Hardware

A		4	1/4" x 2 1/2" Carriage Bolt
B		2	1/4" x 3" Carriage Bolt
C		8	1/4" x 3 1/2" Carriage Bolt
D		14	1/4" Nut
E		8	1/4" x 3" Lag Bolt

Instructions:

1. Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
2. To begin, set the seat upright. Set the back into the seat. Fasten using 2 (A) 1/4" x 2 1/2" Carriage Bolts & 2 (D) 1/4" Nuts. (Illustration 2) Repeat on the other side.
3. Fasten the arm and leg combo. Fasten the arm to the back using 1 (B) 1/4" x 3" Carriage Bolt & 1 (D) 1/4" Nut. Then fasten the legs using 2 (B) 1/4" x 3" Carriage Bolts & 2 (D) 1/4" Nuts on each leg. (Illustration 3) Repeat on the other side.
4. Now attach the rails to the glider base using 4 (E) 1/4" x 3" Lag Bolts. (Illustration 4) Repeat on the other side.



Illustration 2



Illustration 3



Illustration 4