

CURVE BACK
ASSEMBLY INSTRUCTIONS



(717) 354-8998 • (877) 560-5966
New Holland, PA

#301 Curve Back Rocker



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16 wrench

Included Hardware

A		4	1/4" x 2 1/2" Carriage Bolt
B		6	1/4" x 3" Carriage Bolt
C		8	1/4" x 3 1/2" Carriage Bolt
D		18	1/4" Nut
E		2	2 1/2" Screws

Instructions:

1. Unpack items from box(es). Be sure to match any numbers & letters that you find on the pieces.
2. To begin, set the seat upright. (Illustration 2)
3. Set the back into the seat. Align the pre-drilled holes. Fasten using 2 (A) 1/4" x 2 1/2" Carriage Bolts & 2 (D) 1/4" Nuts. (Illustration 2)
4. Lay the chair on its back and fasten the arm of the arm/leg combo to the back using 1 (B) 1/4" x 3" Carriage Bolt & 1 (D) 1/4" Nut. (Illustration 3) Repeat on the other side.
5. Then using 2 (C) 1/4" x 3 1/2" Carriage Bolts & 2 (D) 1/4" Nuts, fasten the leg of the arm/leg combo to the leg. (Illustration 3) Repeat on the other side.
6. Now turn the chair upside down, so it is resting on the arms. Fasten the legs using 2 (C) 1/4" x 3 1/2" Carriage Bolts & 2 (D) 1/4" Nuts. (Illustration 4) Repeat on the other side.
7. Then using 1 (E) 2 1/2" Screws fasten the leg to the back of the chair. (Illustration 5) Repeat on the other side.
8. With the rocker still upside down, fasten the rocker runners using 2 (C) 1/4" x 3" Carriage Bolts & 2 (D) 1/4" Nuts. (Illustration 6)




Illustration 2




Illustration 3




Illustration 4




Illustration 5




Illustration 6