

Assembly Instructions For The Bent Oak Glider & Glider Chair

Parts List

Seat Assembly (1)
Back Assembly (1)
Right Leg Assembly (1)
Left Leg Assembly (1)
Glider Feet (2)
1"x4" Glider Braces (2)

4' & 5' Glider Hardware

1/4" x 2" Bolts (7)
1/4" 1-1/2" Bolts (4)
1/4" 1-1/4" Bolts (8)
Glider Hangers (4)
1-1/2" Wood Screws (8)

Glider Chair Hardware

1/4" x 2" Bolts (6)
1/4" x 1-1/2" Bolts (4)
1/4" x 1-1/4" Bolts (8)
Glider Hangers (4)
1-1/2" Wood Screws (8)

Tools Needed For Assembly

Phillips Head Bit Power Screwdriver

- Step 1** Attach the back assembly to the seat assembly. Align the predrilled holes in the bottom back support strip with the threaded inserts in the back support strip of the seat assembly. Insert the 2" bolts & semi-tighten only. (The 4' & 5' glider need 3 bolts, the glider chair only needs 2 bolts here). **Do not fully tighten any bolts until Step 3 is completed.**
- Step 2** Take a leg assembly & align the holes in the legs with the threaded inserts in the side of the seat. Attach with two 2" bolts. **NOTE:** The back of the arm rests on top of the middle back support strip. Note that there is a left & a right leg assembly. Repeat on other side.
- Step 3** Fasten the top & center back support strips to the back of the legs. Align the predrilled holes in each end of the strips with the 4 threaded inserts in the legs & fasten with four 1-1/2" bolts. Tighten with the Allen wrench & now tighten all other bolts but do not over tighten.
- Step 4** Take the glider feet and set them upright on the floor to assemble the base. (The slight arch is on the bottom, the long flat edge with the cut corners is the top). Take the 1x4 braces and attach them to the 1" x 2" blocks on the inside of the glider feet. The braces go on the front & back of the blocks, flush with the top edge of the feet. (See photo below). Attach with four 1-1/2" screws in each brace in the predrilled holes. Screws are self drilling.
- Step 5** Now attach the glider hangers to the leg assemblies. Put the hanger on the inside of the leg & align the hole in one end of the hanger with the threaded insert on the bottom of the leg assembly. Put a 1-1/4" bolt through the glider hanger & turn into the insert in the leg. Tighten with the Allen wrench. Attach the other hangers the same way.
- Step 6** Set the glider on top of the frame. Now align the other hole in the glider hanger with the threaded insert on the top edge of the glider foot. Put another 1-1/4" bolt through the glider hanger, turn into the insert & tighten with the Allen wrench. Attach the other hangers the same way.

