



#### Required Tools:


- Cordless Drill
- #2 Square Drive Bit
- Tape Measure
- $\frac{7}{16}$ " Socket

#### Hardware:

- (8) 1/4"x3" Lag Bolts
- (8) 1/4" Washers
- (6) 1-3/4" Screws
- (16) 2-1/2" Screws

#### Parts:

- A = (1) Left Side Frame
- B = (1) Right Side Frame
- C = (2) Stretcher
- D = (1) Backrest
- E = (1) Headrest
- F = (1) Seat
- G = (2) Armrests
- H = (2) Runners



**Step 1:** On a soft surface, place the left side frame (A) onto its side as pictured. Position one of the stretchers (C) in the notch inside of the frame as shown, making sure it is centered and straight with the back leg, fasten with (1) 2-1/2" screw from the outside thru the hole provided.



**Step 2:** Next, place backrest (D) into position, as shown, lining it up with the notch on the frame. Note: Do not place it at the top of the frame, that notch is for the headrest. Using (4) 2-1/2" screws, fasten the backrest to the frame thru the four holes provided.



**Step 3:** Place the headrest (E) into position at the top of the frame as shown and attach with (2) 2-1/2" screws thru the two holes provided.



**Step 4:** Place seat (F) into position up against the frame and in the notches on the legs, turning it so the flush end of the seat goes towards the back of the rocker, as shown. Place (1) 1/4" washer onto (1) 1/4"x3" lag bolt and thread thru the front leg into the seat, tighten, then repeat on the back leg.



**Step 5:** Next, position the remaining stretcher (C) into place as shown, making sure it is centered and straight with the front leg, fasten with (1) 2-1/2" screw from the outside thru the hole provided.



**Step 6:** Attach the right side frame (B) to the other side of the rocker in the same manner as shown in Steps 1 thru 5.



**Step 7:** Stand the rocker up. Place one of the armrests into position as shown, turning it so the curved side faces outward and the straight side of the armrest is flush with the rail on the back side of the frame.



**Step 8:** Then on the front side, under the armrest measure out 2" from the rail on the frame to establish how far out the armrest should be positioned when attaching it in the next step.



**Step 9:** Attach the armrest to the frame from underneath at the back, middle and front using (3) 1-3/4" screws.



**Step 10:** Attach the remaining armrest (G) to the other side of the rocker in the same manner as shown in Steps 7 thru 9.



**Step 11:** Turn the rocker upside down. Place a runner (H) into position, as shown, onto the front and back legs by turning it so the notch on the runner faces downward and is up against the back leg.



**Step 12:** Fasten the runner to the front and back legs. Place (1) 1/4" washer onto (1) 1/4"x3" lag bolt and thread thru the runner into one of the legs, repeat on other leg. Repeat with the remaining runner (H) on the other side of the rocker.



**Step 13:** Your rocker is now complete.

*Thank you for purchasing from Wildridge.*