

Required Tools:

- Mallet/Non-Marring Hammer
(DO NOT Use Metal Headed Hammer)

- #2 Square Drive Bit
- Cordless Drill
- 7/16" Wrench or Socket



Hardware:

(4) 2 1/2" Screws
(8) 1/4" x 2 1/2" Bolts
(8) 1/4" Flange Nuts
(2) 1/4" x 3" Lag Bolts
(2) 1/4" Washers
(4) 2" Screws



Parts:

A = (1) Seat
B = (1) Backrest
C = (1) Right Facing Arm Assembly
D = (1) Left Facing Arm Assembly
E = (1) Stretcher




Step 2

Fasten the back onto the seat through the two pre-drilled holes provided, using (2) 2 1/2" screws, repeat on the other side of the chair.



Step 1

Place the seat (A) on a level surface. Set the backrest (B) onto the seat, making sure the back rest slides up against the stop on the seat on both sides of the chair.



Step 3

Lay the backrest/seat on its left side. Place the right facing arm assembly (C) onto the side as shown, line up the holes, and tap a 1/4" x 2 1/2" bolt through each of the four holes, repeat on the other side with the left facing arm assembly (D).



Step 4
On the underside of the chair, add a 1/4" flange nut to each of the bolts, and tighten. Do this for both arm assemblies.



Step 5
Place a 1/4" washer onto a 1/4" x 3" lag bolt and fasten the backrest to the arm assembly through the hole provided, repeat with the other arm assembly.



Step 6
Slide the stretcher (E) into the slots on the inside of the front legs. Fasten from the outside, through the holes provided with (4) 2" screws, two per leg.



Your chair is now complete.... enjoy!

Thank you for purchasing from Wildridge.