



#### Required Tools:


- 1/2" Wrench or Socket
- 9/16" wrench or socket
- #2 Square Drive Bit
- Cordless Drill

#### Hardware:

- (8) 5/16" x 3" lag bolts
- (8) 3/8" Locknuts
- (4) 3/8" x 2 1/2" machine bolts
- (4) 3/8" x 1 3/4" machine bolts
- (12) 1 1/4" screws
- (8) 5/16" washers
- (4) Glider Brackets
- (16) 3/8" Washers


#### Parts:

- A = (2) Base Pieces
- B = (2) Support Pieces
- C = (1) Footrest
- D = (2) Long Legs
- E = (2) Short Legs



#### Step 1


Stand the two base pieces (A) up side by side and place the two support pieces (B) upright in between them as shown. To fasten them together, slide a 5/16" washer onto a 5/16" x 3" lag bolt and insert it through the hole on a base piece, and into the pre-drilled hole in the support piece, as shown. Repeat with the remaining seven holes. **NOTE: Before tightening the bolts completely make sure it is sitting level.**




#### Step 2

Using the pictures as a reference, fasten the hardware through the top holes on the two base pieces, using (1) 3/8" x 2 1/2" machine bolt, (2) 3/8" washers, (1) glider bracket and (1) 3/8" locknut, per hole.

Note: The glider bracket should be on the outside of the base so you can attach it to the leg in step 4.



For it to glide correctly the hardware must be placed in the order that is pictured above and with the curve on the glider bracket facing away from the base. You will be doing this for all four glider brackets.



#### Step 3

Lay the footrest (C) on side as shown, noting the slant. On the inside place a long leg (D) to the right as far as it allows, staying up against slats as shown. Fasten with (3) 1 1/4" screws per leg through the pre-drilled holes. Then fasten a short leg (E) to the left side in the same manner. Repeat on the other side of the footrest with the remaining two legs.



#### Step 4

Now place the footrest assembly over the base assembly and fasten the legs onto the glider brackets using (1) 3/8" x 1 3/4" machine bolts and (2) 3/8" washers, per leg, making sure to slide one washer onto the bolt, then through leg, then add another washer before inserting it through glider bearing, once through add a 3/8" locknut.



Your gliding footrest is now complete.

*Thank you for purchasing from Wildridge.*