

Required Tools:


- Mallet/Non Marring Hammer
(Do not use Metal Headed Hammer)
- 7/16" socket or wrench
- Cordless Drill
- #2 Square Drive Bit

Hardware:

- (10) 1/4" x 2 1/2" Bolts
- (2) 1/4" x 3" Bolts
- (12) 1/4" Flange Nuts
- (2) 2 1/2" Screws
- (8) 1 1/4" Screws
- (8) 2" Screws


Parts:

- A = (1) Seat
- B = (1) Back
- C = (2) Outside Legs
- D = (1) Middle Leg
- E = (2) Leg Supports
- F = (2) Left Arm Rest
- G = (1) Right Arm Rest




Step 1

Position seat (A) and back (B) as shown and fasten with (4) 2 1/2" bolts and flange nuts, two on either side.




Step 2


On the back side of the seat, fasten the lower back support to the middle seat support with (2) 2 1/2" Screws through the pre-drilled holes as shown.





Step 3
Place outside legs (C) as shown and fasten with (4) 2 1/2" bolts and flange nuts, two on each side.



Step 4
On the underside of the seat, fasten the middle leg (D) as shown on the right side of the middle seat support with (2) 2 1/2" bolts and flange nuts.



Step 5
Between the middle leg and the outside leg, place one of the leg supports (E) into the groove and fasten with (4) 2" screws. NOTE: The screws in the middle need to be screwed in from the underside as shown in the picture on the right. Repeat with the other leg support.



Step 6
Fasten the left arm rest (F) to side rail in the back with (1) 3" bolt and flange nut. Now measure 1" from inside of leg as shown and fasten on outside with (4) 1 1/4" screws. Repeat with right arm rest on other side.



Complete!

Thank you for purchasing from Wildridge.