



#### Required Tools:

- Mallet or Non-Hammer  
*(DO NOT Use Metal Headed Hammer)*
- 7/16" Socket Or Wrench
- Cordless Drill
- #2 Square Drive Bit

#### Hardware:

- (6) 1/4" x 3" Bolts
- (4) 1/4" x 4" Bolts
- (4) 1/4" x 2 3/4" Bolts
- (14) 1/4" Flange Nuts
- (2) 2 1/2" Screws

#### Parts:

- A = Chair Back
- B = Chair Seat
- C = Right Arm Assembly
- D = Left Arm Assembly
- E = Foot-Rest Support




#### Step 1

Note: This is a two person assembly. On a soft surface, place the chair seat (B) on it's side and position the chair back (A) inside as pictured.




#### Step 2

Next, lay the right arm assembly (C) onto the top of the chair seat/back assembly, with the narrow part of the arm-rest facing towards the seat back as pictured.




#### Step 3

Match up the five pre-drilled holes on the right arm assembly with the chair seat/back assembly. Using a mallet or non-marring hammer, tap the bolts through the holes, using two 3" bolts on the front leg, two 4" bolts on the back leg, and one 3" bolt on the arm-rest. Add flange nuts to the end of the bolts but do not tighten completely.



#### Step 4

Repeat step 3 with the left arm assembly (D) on the other side.



#### Step 5

Position the foot-rest support (E) between the two arm rest assemblies (C & D).




#### Step 6

Align the pre-drilled holes and using a mallet or non-marring hammer, tap the bolts through the holes, using two 2 3/4" bolts to fasten the foot-rest support to the left arm assembly. Add flange nuts to the end of the bolts but do not tighten completely. Repeat on the other side.



#### Step 7

Turn the double Adirondack onto its feet. Adjust the chair so it sits square. Once the chair is square, tighten all 14 flange nuts.



#### Step 8

On the back side, screw the chair back to the chair seat (into the middle seat support) through the pre-drilled holes with two 2 1/2" screws.



#### Step 9

Your double adirondack is now complete.

*Thank you for purchasing  
from Wildridge.*