

#### Required Tools:

- Cordless Drill
- 6" #2 Square Drive bit
- Tape Measure

#### Hardware:


- (16) 2" Screws
- (4) 1 1/4" Screws

#### Parts:

- A = (1) Seat
- B = (1) Backrest
- C = (2) Front Legs
- D = (2) Leg Supports
- E = (1) Stretcher (Note: Identical to Leg Supports)


#### Step 1

On a soft surface, lay seat (A) upside down. Place a leg (C) with the pocket holes facing inward up against the apron on the seat as shown, and fasten with (2) 2" screws through the pocket holes and into the seat brace. Fasten the other leg (C) on other side, in the same manner.



#### Step 2

Lay seat (A) and backrest (B) on its side. Measuring 14" from the bottom of the leg to the bottom of the seat and fasten them together with (2) 2" screws thru the pocket holes provided. Repeat on other side.



#### Step 3

Lay chair on its back. Fasten a leg support (D) between the front and back leg, keeping it flush on the inside and 2 3/4" up from the bottom (use one of the other leg supports as a guide for height). Fasten with (4) 2" screws. REPEAT on the other side.



Use the extra leg support as your measurement for the placement of the leg support you are installing.



#### Step 4

Now fasten the stretcher (E) in the center between the two leg supports, as shown, measuring so its centered and fasten with (4) 1 1/4" screws, 2 on each side.

**NOTE: DO NOT USE 2" SCREWS.**



#### Step 5

Your chair is now complete.

*Thank you for purchasing from Wildridge.*